

# Instruction book

# ALBIN AD-2

## List of Contents

	Introduction . . . . .	3
Running	Run-in gear . . . . .	7
	Preparation . . . . .	7
	Before starting . . . . .	9
	Starting . . . . .	9
	After Starting . . . . .	9
	Manoeuvring . . . . .	9
	Finning . . . . .	9
	Stopping . . . . .	10
	Frost precautions . . . . .	10
Description and Maintenance	General . . . . .	10
	Fuel system . . . . .	12
	Lubricating system . . . . .	15
	Cooling system . . . . .	17
	Electrical system . . . . .	18
	Reverse gear . . . . .	20
	Reduction gear . . . . .	21
	Anti-corrosion treatment . . . . .	21
	Maintenance schedule . . . . .	22
Installation	General . . . . .	25
	Engine bed . . . . .	25
	Engine casing . . . . .	25
	Propeller equipment . . . . .	26
	Fuel system . . . . .	28
	Cooling system . . . . .	29
	Exhaust system . . . . .	50
	Electrical system . . . . .	31
Technical Data	. . . . .	32

The specifications and design information given in this book are not binding. We reserve the right to carry out modifications without previous notice.

## Introduction

The ALBIN AD-2 is a compact, short-stroke, modern and easy-to-install marine diesel with comprehensive standard equipment. Direct injection ensures excellent cold starting and low fuel consumption. These are some of the facts which make boating enthusiasts choose the ALBIN AD-2.

The engine is a 2-cylinder, 4-stroke diesel with overhead valves and direct injection. The fully balanced crankshaft, supported in three main bearings, together with the short stroke design, ensure smooth and vibration-free running whilst the specially designed inlet channels and multi-hole injection nozzle provide maximum fuel economy. Fuel to the injection pump is supplied by a feed pump which can also be operated by hand.


The standard 12 volt electric equipment consists of a 1.3 h.p. starter and a 90 watt (1.1 amps) generator. Alternatively, a 450-watt (3.8 amps) alternator which charges at idling speed can be fitted in lieu of the standard generator.

The convenient position of the starting handle, coupled with the decompression device and high inertia flywheel, ensures easy hand starting.

The engine and reverse gear are pressure-lubricated from a common lubrication system. The oil is supplied through drilled channels to the various lubrication points, eliminating the need for vulnerable external oil pipes.

Both the engine and the exhaust pipe are raw sea water cooled. The sea water cooling pump and automatic bilge pump are of the constant type and are fitted with rubber impellers which are capable of handling solids. The bilge pump can also be used for cleaning the cockpit. The built-in thermostat maintains the coolant working temperature.


The engine has a closed crankcase ventilation system, replaceable bearing shells and, giving the unit all the characteristics of the legendary Volvo. Behind the AD-2 construction lies more than 80 years' experience in the marine engine field.



3

Fig. 1

1. Lubrication oil filter
2. Fuel pump and fuel valve with fuel pump lever
3. Fuel filter and injection pump
4. Injection pump
5. Charging water pump
6. Automatic bilge pump
7. Compression device for starting by hand
8. Flywheel
9. Decompression device
10. Decompression lever
11. Ignition switch
12. Oil filler cap
13. Fuel injection nozzle
14. Sea water cooling pump
15. Sea water cooling pump
16. Sea water cooling pump
17. Bilge pump
18. Reduction gear (the engine can be supplied with or without reduction gear)
19. Oil filler cap and venting for reduction gear






Fig 2

- 21 Reverse gear
- 22 Gearbox operating lever
- 23 Venting valve for reverse gear
- 24 Inlet strainer with oil filter
- 25 Oil mesh gear mesh
- 26 Inlet manifold
- 27 Generator
- 28 Starter

5


#### AD-2 Lifeboat version

The ALBIN Model AD-2 is approved as a lifeboat engine. Its design varies to meet the regulations of different countries.

Fig 3

This engine has

- 1 Vent pipe nipples with high-class pipe opening
- 2 Inlet manifold intake placed above the engine
- 3 Start alert
- 4 Lengthened handstart shaft
- 5 Generator (can be supplied as optional extra)
- 6 Screws and oil cocks with special seals



6

# Running

## Running-in

When an engine leaves the factory it is partly run-in and has been carefully checked and bench-tested up to the speed of operation. It is recommended, therefore, that the engine be run for about 24 hours at each 1/3 of the full speed and speed in order to complete the running-in process. Afterwards the oil in the engine and reduction gear must be changed when the engine is warm. Fueling oil should not be used (see "Maintenance Schedule" Page 27).

## Preparation

1. Fill the engine with oil through the oil filler cap in the valve cover (see Fig. 1, No. 12). Crank the oil lever in the direction on the top side of the engine (Fig. 1, No. 3). (The reverse gear is always lubricated from the engine.)
2. Fill the reduction gear with oil through the filler cap (Fig. 4, No. 1). Check the level with the dipstick (Fig. 4, No. 7).
3. The governor lever for the auto start is lubricated with the same oil as for the engine and reduction gear. The oil is fed through the oil filler cap No. 1 and oil flows from the oil level glass No. 2 (Fig. 5).
4. Bleed the fuel system. This should be done even if the engine has not been used for a long time or if the fuel tank has been emptied. Pump down the hand pump (Fig. 8, No. 4) on the fuel filter and pump fuel with the hand pump (Fig. 8, No. 4) until a stream of fuel free from air bubbles flows from the tap. Then tighten the bolt. Loosen the bleed screws No. 5 on the injection pump and repeat the operation, tightening the cover screws when fuel flows free from air bubbles. Air in the fuel system is the main cause of starting troubles on regular running. If the fuel system needs frequent bleeding, check fuel pipes, pipe fittings and tank connections for leaks.



Fig. 4 1 Oil filler cap  
2 Oil dipstick  
3 Oil outlet



Fig. 5 1 Governor cap  
2 Oil level glass  
3 Bleed screw  
4 Hand pump  
5 Bleed screws



Fig. 6 1 Governor lever (mounted between the injection pump and the engine block)  
2 Hatch for extra starting fuel  
3 Stop lever

## Before Starting

1. Check the oil level in the engine and reduction gear.
2. Check the fuel level in the tank and open the fuel tank.
3. Open the sea cock and adjust the three-way cock on the exhaust pipe for direct discharge overboard.
4. Grease the proper shaft bearings.

## Electrical Starting

1. Put the reverse gear lever in neutral.
2. Insert the ignition key in the instrument panel.
3. Set the governor lever in the centre position (Fig. 6, No. 1).
4. Press the button on the pump for extra starting fuel (Fig. 6, No. 2).
5. Press the starter button on the instrument panel.

## Hand Starting

1. See Nos. 1, 3 and 4 above under the heading "Electrical Starting".
2. Set the decompression lever (Fig. 7, No. 1) in vertical position.
3. Insert the starting crank (Fig. 7, No. 2).
4. Crank the engine as quickly as possible with the starting crank and return the decompression lever to the horizontal position while cranking.

## Start Pilot

If the engine has to be started in very cold weather, it may be fitted with a "start pilot" (see Fig. 3). Remove the plug on the lower side of the intake pipe and fit the connection pipe for the start pilot. Start the engine at the same time as starting fuel is injected.



Fig. 7 1 Decompression lever  
2 Starting crank

### After Starting

1. When the engine has started, set the governor to full rating speed (about 100 rpm).
2. Check the oil pressure. The needle of the gauge should register in the green sector.
3. If the engine is electrically equipped, check that the charging control light goes out when the engine starts to be supplied.
4. Set the three-way cock on the exhaust pipe in the middle position and check the cooling water circulation by seeing that the water is exchanged overboard.

### Manoeuvring

Move the operating lever forward for running ahead and aft for running astern. When manoeuvring, keep the engine speed at about 90 rpm. Avoid sharp movements of the lever as this will cause unnecessary stress on the engine and machinery. Also, excessive slow movement of the lever will cause the engine to stall. There is no risk of the engine racing when manoeuvring from ahead or astern to neutral as the engine is equipped with a centrifugal governor.

### Running

As regular intervals when running, check the oil pressure, the cooling water temperature and what air the cylinder is charging. The needle of the oil pressure gauge and cooling water thermometer should register in the green section of a scale. The charging control light should glow only when the engine is running at low revolutions, but should extinguish when the revolutions are increased. This is a note that the dynamic charging is taking place. The engine is constructed to allow continuous running at maximum revolutions (about 120 rpm) but, as shown on the operating table, the consumption is increased considerably when the engine is run at maximum revolutions. This not only applies to the AD-2, but to all engines, and is dependent on the increased resistance of the water at higher speeds.




Fig. 9 Heat consumption for AD-2 with 2 1/2 inch bore for gear and 3 inch diameter propeller. The curves are for 2 1/2 inch bore and 3 inch diameter propeller. The curves are for 2 1/2 inch bore and 3 inch diameter propeller. The curves are for 2 1/2 inch bore and 3 inch diameter propeller.



Fig. 10 1. Operating lever  
2. Adjusting screw




Fig. 8 Instrument Panel

1. Start/stop switch
2. Starter button
3. Charging control light
4. Oil pressure gauge
5. Cooling water thermometer
6. Stop control button

### Key positions in switch box

	Key inserted	Key pulled out
1	Start current switched on	Start current switched off
2	Start current and instrument panel lighting switched on	Instrument panel lighting switched on
3	Start current and instrument panel lighting and other lighting switched on	Instrument panel lighting and other lighting switched on

### Stopping

1. **IMPORTANT!** Before stopping the engine, move the three-way cock on the exhaust pipe to the height of the cooling water manifold. It is also to be seen in the manual before stopping the engine that the exhaust pipe is to be drawn free from water and elements the risk of water entering the cylinder.
2. Stop the engine by moving the stop lever (Fig. 6 No. 3) aft.
3. Switch off the electrical circuit by pulling out the key in the instrument panel. The engine must not be stopped by using the stop button as severe mechanical damage will result.

### First Precautions

1. After the engine has stopped, open the drain cocks on the cylinder block and exhaust pipe. Stop at the bottom end of the screw down there is a connection to the huge pump inlet. It is also to be closed alternately in the same order as the water line.
2. When the cooling water has been drained, start the engine and run it for 10-15 minutes. Test to see that moisture in the pump is burned into the cylinder as the first oil film on the piston will be evaporating during severe work. Running with closed cocks on the water pipe does not cause damage to the water pump bearings. The above caution time is not to be exceeded.

## Description and Maintenance

### General

The cylinder block is cast in one piece with oil-lubricated areas which considerably lengthens the life of the engine.

The cylindrical head is fastened to one side and has replaceable exhaust valve seats.

The decompression device is built into the valve cover. By moving the cover (Fig. 10, No. 1) to the vertical position, two adjusting screws, No. 2, are pressed against the exhaust valve rocker arms; the exhaust valves open and the engine is decompressed. (See "Hard Starting," Page 8.) To adjust the decompression device, both the exhaust valves should be closed. Tighten the adjusting screws against the rocker arms and then screw them down  $\frac{1}{2}$  to  $\frac{3}{8}$  turn, locking the screws with the lock nuts.

The crankcase ventilation is used to prevent the escape of unburned fumes. The fumes are sucked back into the engine from the valve cover to the manifold inlet pipe through the reinforced plastic hose. A filter is fitted on the upper side of the valve cover.

The filter (Fig. 11, No. 1) should be changed after about 300 hours.

The valves should be adjusted when the engine is cold. The valve clearance should be 0.3 mm (0.012") for both the inlet and exhaust valves.

The exhaust valves have sealing faces. The face is a very hard metal between 500 and 600 Hv which has excellent resistance to corrosion at high temperatures. The valve spindles are hard chromium plated.

The inlet valves are fitted with rubber sleeves to stop wear caused by friction leaking down the valve spindle into the cylinder.

The pistons are of light alloy and are fitted with three compression rings and two scraper rings. The top compression ring is hard chromium plated.

The crankshaft is manufactured from nodular iron, a material which is excellent for crankshafts as nodular iron combines the strength of steel with the low weight and cost of the parent cast iron.

The main bearings consist of bearing shells of babbitt metal.

The connecting rods are drop-forged and equipped with lead-bronze bushings and bearing shells of babbitt metal.



Fig. 11. Filter for crankcase ventilator



Fig. 12. Valve adjustment



Fig. 13. Reinforced plastic hose for connecting to manifold

Fig. 14. Injection pump

1. Oil filler plug
2. Oil drain plug
3. Oil level plug
4. Fuel warning handover
5. Connection for turbocharger
6. Adjusting screws for timing and fuel injection
7. Pressure gauge for fuel injection pump
8. Pressure gauge for oil
9. Speed sensor
10. Fuel injection pump and air filter
11. Oil level gauge and oil level indicator


The camshaft is made of nodular iron and hardened cam.

The engine is fitted with a large inlet silencer (Fig. 7) which should be replaced after about 200 hours running.

### Fuel system

The injection pump is mounted on the left side of the engine and is driven by the crankshaft gears.

The pressure gauge is connected with the fuel injection pump and the pressure controller and prevents the engine from starting in the event of the fuel pump suddenly failing.






Fig. 15 Fuel passage




Fig. 16 Fuel filter

1. Filter retaining bolt
2. Cover base
3. Filter cartridge
4. Bleed screw
5. Cover for return line

#### Fuel filter

The fuel filter cartridge cannot be cleaned but has to be replaced. By loosening the retaining bolt (Fig. 16) No. 1 cover (2) can be removed and the filter cartridge (3) replaced by a new one. For bleeding the fuel system, use screw (4). This must be done each time the filter cartridge is changed to extract air from the system. Needle (5) is for the return excess fuel from the injectors. Normally the filter should be replaced after about 500 hours running. If a fuel filter is used then the filter cartridge will require changing more frequently.




Fig. 17 Injector in section



Fig. 18 Injection timing and T.D.C. are marked on the flywheel. By removing the cover to which the rear eye ball is fixed, an edge of the flywheel bell housing, these marks are easily visible.

#### Injector

The injector is required to inject fuel at exactly the right moment in spite of the high pressure in the cylinder. The fuel flow which is adjusted by the fuel pump is forced through a hole in the nozzle holder down to the nozzle. When the correct pressure is reached, the needle rises and allows the fuel to pass through four very fine holes. These carefully calibrated nozzle tips, together with the well-designed jet channels, ensure perfect atomisation of the fuel and compressed air in the cylinder.

**NOTE: NO SERVICING OR ADJUSTMENT TO THE INJECTION EQUIPMENT MUST BE CARRIED OUT BY ANYONE OTHER THAN A DIESEL SPECIALIST.**

The fuel filter cartridge can be replaced by the user but for other parts we recommend that a diesel workshop be contacted.

#### Fuel

The Midget AD-2 is a light running diesel and requires a fuel with cetane index 40 which is suitable for fast running engines. If you use the same fuel as is used on trucks, buses and all high speed automotive diesel engines, there is a great risk of the injectors malfunctioning resulting in imperfect combustion if unsuitable fuel is used.

## Lubricating system

The engine and reverse gear are lubricated by means of a full-flow lubricating system. This is different to full-flow since the oil level in the engine that lubricates the reverse gear is also lubricated. In this oil pump there is a strainer through which the oil passes before it is sucked up into the circulating oil pump. This is a gear pump with a relief valve. The oil is then forced through an oil filter of the full-flow type. Consequently all circulating oil passes through the filter and dirt etc. is removed before it reaches the different parts to be lubricated. If the filter is clogged, then the relief valve becomes replacing but a relief valve will open and the engine will be lubricated direct from the oil pump. Should the oil pressure fall, it could mean that the lubricating oil is too thick.

### Checking of oil level

Before starting, check the oil level every day with the dipstick at the end of the engine (fig. 1, No. 2). If the oil level does not reach the lower mark on the dipstick, additional oil must be poured into the oil filler pipe on the valve cover of the engine (fig. 1, No. 12).

The oil consumption will be exceptionally high if the oil level is above the top mark on the dipstick.

The oil capacity of the engine/reverse gear including that of the lubricating oil filter is 3.3 litres (3.8 imp. pints, 7.0 US pints).

### Engine and reverse gear oil change

The oil should be changed every 100 hours or once per season. If shorter, slow over during the running-in period, the oil should be changed every 25 hours and it should always be done while the engine is hot. During the running-in period (about 100 hours) the lubricating oil consumption is higher than normal and therefore has to be checked more often. The oil is removed by being sucked out through the oil sump hole by means of the oil sump pump supplied in the tool kit with the engine.

**NEVER TUBE FILLING OIL**



Fig. 19 Replacing of the filter

### Replacing of the filter cartridge

The lubricating oil filter cartridge (with an element) must be replaced (fig. 19) every 300 hours or once every season.

1. Remove the old filter cartridge.
2. On the basket of the new filter cartridge and check that the bearing surfaces are clean and undamaged!
3. Tighten the filter cartridge quickly by hand and wash off any oil around the filter.
4. Run the engine and check that the filter has not clogged.

### Reduction gear oil change

The reduction gear, if fitted, is lubricated separately. Oil should be filled up to the dipstick mark. Check the oil level each time the oil level in the engine is checked. Change the oil every 300 hours, but during the running-in period, it should be changed after the first 20 hours. Change the oil while the engine is warm. Drain the oil through the plug at the lower part of the gearbox (fig. 4, No. 1). Use the same oil as for the engine. The reduction gear contains 0.95 litres (1.04 imp. pints, 0.63 US pints).

### Injection pump and governor oil change

The governor and injection pump have the same oil supply. Change the oil while the engine is warm every 100 hours or once every season, by draining it through the plug (fig. 14, No. 2), fitted under the pump. Fill up through the oil filler plug on the top of the pump (fig. 14, No. 1), until the oil flows from the oil level plug (fig. 14, No. 3) using the same oil as for the engine.

### Suitable oils

Quantity	Service DM
Viscosity at temperatures between -10°C and +10°C (14°F and 50°F)	SAE 90
at temperatures above +10°C (50°F)	SAE 80
BP	Engrail Diesel S1
Cabot	RPM Delo Super Special
Castrol	Deasol CF 80
Fawn	Fawnlub HDX
Gulf	Gulfube Multi 100 HD
Mob. Oil	Mob. DTE Marine O. No. 8132
Shell	Rotella T 80
Valvolina	Super HDX



## Cooling system

The engine is cooled sea water cooled. The cooling water pump is mounted on the forward end of the engine and is coupled to the catalytic bridge pump. They are both "low" pumps with rubber impellers which are capable of handling acids.

The catalytic bridge pump has a capacity of approximately 15 litres (40 imperial pints, 21 US pints) per minute at full speed and approximately 4 litres (10 imperial pints, 5.6 US pints) per minute at 10 rpm. If there is no water in the boat's bilge the pump will be lubricated by water entering through a hole in the hull between the cooling water pump and the bilge pump.

The pumps are fitted with Teflon impregnated ball bearings which are lubricated by water.

A damaged impeller or a clogged pump could cause the cooling water supply to stop. This can happen if the engine is run too long without a water supply or if the impeller has frozen. (See "Winter Preparations" Page 10). If damaged, the impeller must be replaced and this can be accessed most by removing the pump cover, the bilge pump and the seal between the pumps (see fig 21).

The thermostat is enclosed in the thermostat housing. By removing the housing over the thermostat is as possible for replacement (fig 22). Cooling water is distributed by the thermostat so that the engine block and cylinder head maintain the proper working temperature.

From the connection No. 9 (fig 20) a pipe must be taken to a three-way cock which should be fitted to the exhaust pipe (see installation Drawing on Page 30). The cooling system has to be checked (at least) every 400 hours or once every season. The checking should include a test thermostat, impellers and temperature gauge.




Fig. 21 Water pump impeller replacement  
1 Impeller



Fig. 22 Thermostat replacement  
1 Thermostat housing



Fig. 20 1 Inlet with non return valve — bilge pump  
2 Outlet — bilge pump  
3 Inlet — cooling water pump  
4 Outlet — cooling water pump  
5 Distributor cooling water pipe — on gland thermostat  
6 Cooling water pipe to engine exhaust manifold  
7 Cooling pipe to the motor  
8 Thermostat housing  
9 Connector for cooling water pipe to three-way cock on exhaust pipe

17

## Electrical system

The engine is fitted with a 12-volt electrical system.

It is supplied with a starter of 1.3 (hp 90 watt (17 amp) generator, voltage cut out (reg. 40) and instrument panel as standard.

If extra output is required, a 480 watt (34 amp) generator can be fitted in place of the standard 80 watt (17 amp) generator. This has the advantage of charging even when the engine is idling.




Fig. 23

Wiring diagram 2K-250 for an engine with the standard 80-watt (11 amp) generator.




Fig. 24

Wiring diagram 2K-251 for an engine with a 480-watt (38 amp) alternator and built-in rectifier.

1. Switch box
2. Charging control light
3. Starter button
4. Instrument lights
5. Lighting
6. Starter
7. Battery
8. 80-watt (11 amp) generator
9. 480-watt (38 amp) alternator. NOTE: The alternator must not be run unless it is connected to the battery and battery.
10. Voltage control cut out regulator
11. Fuse box
- Engine block

The cable cross section area should be 2.5 mm<sup>2</sup> (0.004 sq. in.) if not otherwise stated. If cable length exceeds 5 meters (16') a larger cable area should be used.

## Reverse Gear

The reverse gear is of the planetary type with a positive reverse position. It is indicated with  $\ominus$  from the engine.

### Adjustment for running ahead

Adjustment of the gear clutch for running ahead is carried out by turning the adjusting ring (Fig. 26, No. 2) clockwise after slackening the locking set bolt (No. 3). Slacken it as sufficient to turn the ring so that the locking set bolt fits into the first or second notch after the previous one used. Then tighten the locking set bolt.

NOTE: Check the adjustment after the first 50 hours running.

### Adjustment for running astern

Slacken the locking nut on the adjusting screw (No. 6). Turn the screw  $\frac{1}{2}$  to  $1\frac{1}{2}$  turn clockwise which is a normal adjustment. Tighten the locking nut.

### Adjustment of neutral position

Slacken the locking nut on screw (No. 1). Have the engine idling with the operating lever in the neutral position. Turn the screw clockwise or anti-clockwise until the propeller shaft stops rotating and tighten the locking nut. NOTE: This adjustment must be carried out when the engine has reached its normal working temperature.



Fig. 26 Adjusting screw and lock nut for reverse position

1. Adjusting screw and lock nut for reverse position
2. Adjusting ring for gear clutch
3. Locking set bolt for adjusting ring
4. Adjusting screw and lock nut for clutch band

If the engine is installed in a sailing vessel, mark clearly the position of the propeller blades on the propeller shaft casing. When sailing, turn the propeller shaft so that the propeller blades are vertical and hidden behind the stern post, then lock the propeller shaft in this position by moving the operating lever in the position for running ahead. The propeller then gives minimum drag in the water. If the propeller shaft rotates when sailing, it causes damage. The reverse gear is pressure lubricated from the engine and if the engine is not running, the reverse gear is not lubricated.

#### Reduction gear

The engine can be supplied with three different ratios:

Direct drive 1:1 ratio

Reduction gear 2:1 ratio

Reduction gear 2.7:1 ratio

By selecting the correct ratio, an engine can be supplied with the correct number of propeller revolutions suitable for your boat. A small light boat can be fitted with direct drive, but a heavier boat should have reduction gear in order to obtain good propeller efficiency.

The reduction gear is not lubricated by the engine lubricating system (see 'Lubricating system', Page 16).

#### Anti-corrosive treatment

When an engine is not run for a long period, e.g. during the winter, corrosion damage can occur in both the combustion and cooling systems. Engine life can be considerably extended by thorough anti-corrosive treatment.

#### Internal components

Run the engine until it has reached normal working temperature. Drain the oil from the engine, oil filter, governor/injection pump and reduction gear. Pour in anti-corrosive oil. Empty the fuel tank and pour in a small quantity of anti-corrosive fuel. Start the engine and run it for about 10 minutes. Stop the engine and drain the anti-corrosive oil from the engine, governor, injection pump, oil filter and reduction gear. Empty the fuel tank and fuel filter. Cover intake and exhaust pipe openings.

#### Anti-corrosive oil

Shell	Ensis Oil 30
Esso	Rust Ban 625
Gulf	Gulf NO-Rust Engine Oil No. 1
Caltex	Preservative Oil 30
BP	Energol Protective Oil 30
Castrol	Castrol Storage Oil
Mobil Oil	Mobil Kote 503
Valvoline	Tectyl 076

#### Anti-corrosive fuel

Shell	50 % Ensis Oil 150 W, 50 % white spirit
Esso	1/3 Rust Ban 625, 2/3 Autodiesel
Gulf	Gulf Calibrating Oil 45A
Caltex	Rustproof Oil
BP	Energol LM or Energol LM-C
Castrol	Castrol Calibration Oil 8327
Mobil Oil	Mobil Kote 205
Valvoline	1/3 Tectyl 875, 2/3 Autodiesel

21

#### Anti-corrosive oil — Cooling jackets

Shell	Donax C
Esso	Rust Ban 392 (not emulsifying)
Gulf	Gulf Cut 51 A
Caltex	Ran Alorax
BP	Seuba Oil EH Energol 55 4
Castrol	Dicool 5 (1/2 1/2)
Mobil Oil	Savac 2 (emulsifying) Mobil Kote 203 (not emulsifying, water dispersed 10)
Valvoline	Tectyl 91 D Base

#### Cooling jackets

Unscrew the connection between the cooling water pipe and thermostat cover and remove the cover, thermostat and cooling water pipe. Plug the openings in the pump and outlet pipe (see Page 7). Open all drain cocks and let out the water. Close the cocks and pour anti-corrosive oil into the thermostat housing until the whole system is filled. Replace the thermostat cover.

**NOTE:** The cooling water pump and bilge pump must not come into contact with the anti-corrosive oil. They are made wholly of stainless material and the rubber impellers could be damaged by the anti-corrosive oil.

#### Electrical units

The electrical units, such as the starter and generator, are preserved by lacquer so that they can be stored in damp and cold air. It is not necessary, therefore, to remove these units from the engine to be stored in a heated room. Every second year the electrical units should be overhauled by a specialised workshop.

#### When preparing the engine for use again

Draw off the anti-corrosive oil from the cooling jackets and refit the thermostat and all pipes. Fill up with lubricating oil to the required amount and ensure that there is fuel in the tank, and the engine is ready to be operated.

## MAINTENANCE SCHEDULE

		Daily	Every 120 hours <sup>1)</sup>	Every 200 hours <sup>1)</sup>	Every 336 hours	Every 420 hours	Every 1000 hours
Lubrication	Check the oil level in engine	X					
	Check the oil level in reduction gear	X					
	Change the oil in engine		X				
	Change the oil in reduction gear				X		
	Change the oil in governor and injection pump		X		X		
	Change the lubricating oil filter cartridge				X		
Fuel system	Change the fuel filter				X		
	Check the injectors					X	
Cooling system	Check the cooling system					X	
Electrical system	Check the acid level in the battery	X					
	Check the generator and starter						X
Reverse gear	Check the reverse gear		X				
General inspection and overhaul							
	Check the valve clearance			X			
	Clean the inlet silencer			X			
	Clean the oil strainer						X
	Clean the crankcase ventilation system				X		
	Decarbonate and grind the valves						X

<sup>1)</sup> or at least once every season

23

## Installation

- Operating lever. Operating power on handle: Ahead 8 kg (17.5 lb); astern 7 kg (15.5 lb). Torque max 44 kgm (32 ft. lb.)
- Connection for start pilot
- Governor lever. Length 143 mm (5 5/8"); angular movement 30°. Torque 0.6 kgm (0.5 ft. lb.)
- Injection pump stop lever. Length 46 mm (1 3/4"); angular movement 87°. Torque 0.04 kgm (0.3 ft. lb.)
- Connection for cooling water thermometer. 1/2" BSP
- Connection for exhaust pipe. 1 1/2" BSP
- Three-way cock for cooling water outlet. Connection for rubber hose with 3/4" internal diameter
- Connection for oil pressure gauge. 1/8" BSP
- Connection for fuel feed pipe. Diameter 7.5 mm (3/4")
- Connection for tachometer. SAE regular drive
- Silge pump inlet. Connection for rubber hose with 3/4" internal diameter
- Cooling water inlet. Connection for rubber hose with 3/4" internal diameter
- Bilge pump outlet. Connection for rubber hose with 1/2" internal diameter




Fig. 20

## General

To get the best out of your engine, correct installation is essential. The engine is carefully tested before leaving the factory and many faults arise due to bad installation. You are advised, therefore, to contact a boatyard to check the installation by skilled engine engineers.

## Engine bed

The engine bed should be robust and, if possible, of oak, the weight being spread over as many timbers as possible.

The bed should be fixed to the hull by through-bolts.

## Mounting

As standard, the engine is delivered with fixed mountings, but it can also be delivered with rubber mountings.




Fig. 27 Engine bed

The same engine bed can be used for fixed mounting and rubber mounting due to easily exchangeable mounting brackets.

## Engine compartment

A series of tests has been carried out and, as a result, an effective sound insulating engine case has been designed. Fig. 28 shows the recommended design which has given good test results.

To obtain optimal insulation, it is advisable to place a bulkhead on each side of the engine. These bulkheads should cover the whole space from the cabin floor down to the planking and, of course, they have to be lined with the same sound insulating material as the engine case. In order to provide the engine with sufficient air, it is necessary to fit a 2" internal diameter rubber hose through the bulkhead aft.




Fig. 28

## Propeller Equipment

A flexible propeller shaft coupling must be used for a rubber mounted engine which has fixed stern bearings. If the propeller shaft between the inner stern bearing and the coupling is shorter than 0.3 m (12") it is also necessary to use flexible mounted bearings.

## Propeller

Vibrations can be caused by too small a propeller aperture. The measurements given in Fig. 29 should not be reduced. ALBIN MOTOR will make a propeller calculation for a special installation without charge on request.




Fig. 29 Fixed mounting Measurements in mm




Fig. 30 Flexible mounting  
Measurements in mm




Fig. 31 Minimum clearance between the propeller and propeller aperture

### Alignment

Check the alignment of the engine and propeller shaft two/three days after launching. This is particularly important for engines with fixed propeller shaft couplings. Loosen the coupling bolts and separate the coupling halves slightly.

1. Check for misalignment between the centre lines by drawing the halves apart so that the guide boss and recess are free. When pressed together, the guide boss and recess should fit. See fig. 32.
2. Check the angle and centre line by inserting a feeler gauge, 0.35 mm (0.014") between the halves. Press them together so that the feeler gauge touches. This measurement check must be made both in the horizontal and vertical plane. The couplings should then be rotated and checked at 90° intervals.




Fig. 32





Fig. 33

### Fuel system installation

Fig. 34

- 1 Fuel tank
- 2 Tank filler cap
- 3 Tank filter neck
- 4 Hose clamps
- 5 Vent pipe
- 6 Skt. fitting for vent pipe with filter
- 7 Fuel cock
- 8 Fuel pipe
- 9 Flexible hose between engine and fuel pipe
- 10 Coarse filter
- 11 T-pipe



### Cooling water installation




Fig. 35


- 1 50-size
- 2 Inlet skin fitting
- 3 Sea cocks
- 4 Union
- 5 Rubber hose
- 6 Hose clamp
- 7 Inlet union for cooling water pump
- 8 Outlet skin fitting
- 9 Strainer for bilge pump
- 10 Union

29

### Exhaust system installation

Fig. 36

- 1 Exhaust pipe flange
- 2 Bend
- 3 Three-way cock for cooling water outlet
- 4 Pipe from thermostat to three-way cock
- 5 Connection at thermostat
- 6 Bend
- 7 Heat resistant rubber exhaust hose
- 8 Hose clamp
- 9 Silencer connection
- 10 Silencer of neoprene rubber
- 11 Connection to skin fitting
- 12 Exhaust pipe skin fitting




When a special heat resistant rubber exhaust hose is used, cooling water must be passed out through the exhaust system at the time of a neoprene rubber silencer is used, it must be mounted at least 90 cm (36") from the flange of the exhaust manifold and the space between the cooling water inlet and the silencer must be at least 60 cm (24"). The silencer must not be installed close to the hull, liner, etc. but must be freely suspended.

## Electrical system

Fig. 37

- 1 Generator
- 2 Voltage cut-out regulator
- 3 Starter motor with solenoid
- 4 Starter button
- 5 Connection for inspection lamp
- 6 Switch box and key
- 7 Horn button
- 8 Charging control light
- 9 Instruments with lights
- 10 Fuse box
- 11 Distribution terminals
- 12 Main switch
- 13 Battery
- 14 Stearboard light — green (10 watt)
- 15 Port side light — red (10 watt)
- 16 Mast head light — white (15 watt)
- 17 Stern light — white (15 watt)
- 18 Fog horn
- 19 Interior lighting
- 20 Search light
- 21 Engine stop



### Battery

Standard capacity 12-volt 42 amp/hr

### Electrical wires

Ensure that the wires are of the correct thickness. For all lighting a twin wire with an area of 2.5 mm<sup>2</sup> (0.004 sq in.) should be used. Should the length of wire exceed 1 m (16 ft), a thicker wire must be used. The leader cable from the battery is a single wire 6 mm<sup>2</sup> (0.01 sq in.) and the wire between the battery and starter and between the engine body and battery is a single wire 35 mm<sup>2</sup> (0.055 sq in.).

31

## Technical data

Output SAE hp/rpm .....	27/2200
Output DIN-hp/rpm .....	16/2200
Torque max. kgm/rpm (ft lb./rpm) .....	5.7/2000 (57 @ 2000)
Bore, mm (ins.) .....	90 (3.54)
Stroke, mm (ins.) .....	82 (3.23)
Swept volume, litres (cu ft) .....	1.544 (83.7)
Compression ratio .....	17.5:1
Compression pressure kg/cm <sup>2</sup> (psi) at 370 rpm .....	21 (300)
Revolutions, idling, rpm .....	550
Engine rotation (seen from the stern)	
without reduction gear .....	Anti-clockwise
with reduction gear 2:1 and 2.7:1 respectively .....	Clockwise
Maximum inclination .....	13°
Valve clearance, cold engine	
Intake, mm (ins.) .....	0.3 (0.012)
Exhaust, mm (ins.) .....	0.3 (0.012)
Decompression device, pressing down of valves (number of turns of the adjusting screws) .....	1/2 — 3/4
Weight, kg (lb) .....	235 (522)

### Fuel system

Combustion system .....	Direct injection
Injection pressure kg/cm <sup>2</sup> (psi) .....	165 (2350)
Injection timing (marked on the flywheel) .....	23° before TDC
Feed pump, suction lift m (ft) .....	1.5 (5)
Fuel: diesel oil with cetane index .....	45

### Lubricating system

Oil quantity, engine — reverse gear, litres (imp./US pints)	
excluding oil filter .....	3 (5.3/6.35)
including oil filter .....	3.3 (5.85/7.0)

Oil quantity, reduction gear, litres (imp./US pints) .....	0.25 (0.14/0.53)
Oil quality .....	Service OM
Viscosity	
Temperature —13°C up to —10°C (14°F —50°F) .....	SAE 20
Temperature +10°C and above (50°F) ..	SAE 30
O. pressure by warm engine kg/cm <sup>2</sup> (psi) ..	2—2.3 (29—43)
O. pressure, minimum, kg/cm <sup>2</sup> (psi) .....	0.5 (7)
Lubricating oil filter .....	From PH-906

### Cooling water system

Thermostat begins to open .....	77°C (170°F)
Bilge pump	
capacity at idling, litres/min (imp./US pints)	4 (7/6.5)
capacity at full load, litres/min (imp./US pints) .....	15 (26/31.5)

### Electrical system

Battery voltage, volt .....	12
Battery capacity amp/hr .....	43
Starter output, hp .....	1.3
Generator output, watt (amp) .....	90 (11)
Alternator output, watt (amp) .....	490 (38)

### Recommended torque

Cylinder head nuts, kgm (ft. lb) .....	10 (7.2)
Connecting rod bearing bolts, kgm (ft. lb) ..	5.2 (3.7)
Main bearing bolts, kgm (ft. lb) .....	10 (7.2)
Flywheel bolts, kgm (ft. lb) .....	2.6 (1.9)
Injector, kgm (ft. lb) .....	2.5 (1.8)



Effekt, SAE-skyl m .....	20,2200
Effekt, DIN-skyl m .....	16,2200
Vridmoment, kph vid 2000 r/m .....	5,1
Arbetsvakt .....	fyrsvakt
Vorstad	
Max, r/m .....	2200
Temp, °C .....	70°
Sl. vkt. Injekt., g .....	33
Rotationsvaktning (sekt. skifferfriån)	
Till reduktionsväxel .....	Uppers
Med reduktionsväxel .....	Nedörs

Vikt	
Motor med backalar, kp .....	233
Motor med backalar och reduktionsväxel	240
Reduktionsväxel, utväxlingsförhållande	2,04:1 el. 2,7:1
Bränsleförbrukning	
Full last, liter .....	3,3
Växelslart, liter .....	ca 3,5
Kompressionsförhållande .....	17,5 : 1
Kompressionscykel, $kg/cm^2$ vid 320 r/m ..	23
Cylindervolym, liter .....	1,044

**CYLINDRAR OCH KOLVAR**

Antal cylindrar .....	2
Cylindradiameter, mm .....	90
Slaglängd, mm .....	82
Kolvmaterial .....	Lättekall
Kolvspel, max, mm .....	0,12

Kolvringspel	
Kompressionsring nr 1, mm .....	0,056; 0,483
Kompressionsring nr 2 och 3, mm .....	0,219; 0,405
Oljeskräpning nr 1 och 2, mm .....	0,279; 0,405
Oljeringsspel - bredd	
Kompressionsring nr 1, mm .....	0,114; 0,063
Kompressionsring nr 2 och 3, mm .....	0,069; 0,038
Oljeskräpning nr 1 och 2, mm .....	0,089; 0,038

**VENTILER**

Ventildiameter	
Inloppsventil, mm .....	36
Avgavsventil, mm .....	32
Ventiltyp: kall motor	
Inloppsventil, mm .....	0,3
Avgavsventil, mm .....	0,3
Ventilsplidelspel	
Inloppsventil, mm .....	0,05
Avgavsventil, mm .....	0,05

Ventilsågets och gånslänk vinkel	
Inloppsventil, ° .....	30
Avgavsventil, ° .....	30
Inloppsventilen	
öppnar, ° före u.d. .....	16
stänger, ° efter u.d. .....	52
Avgavsventilen	
öppnar, ° före u.d. .....	54
stänger, ° efter u.d. .....	16

**LÅGERSPEL**

Isolagerspel, mm .....	0,03 - 0,09
------------------------	-------------

Rullagerspel, mm .....	3,06 - 0,09
------------------------	-------------

**FÖRBÄNNINGSSTREK**

Bränsleningscykel .....	Direkt- 120000717P
Inspenningpump, S1000 .....	P 401071
Insprutare, S1000 .....	N 1172 A
Spredarlöslare, S1000 .....	BE 00840
Sprenare, S1000 .....	SI 123 (4 hål)
Öppningstryck, insprenare, $kg/cm^2$ .....	105
Förinsprutningsvinkel (märke på sprut- hjul) ° före u.d. .....	25
Inspenningsslag, fulltryck (200 r/m- snurrningar vid 600 r/m), $cm^3$ .....	0,3 - 0,4
Brändlängd, S1000 .....	PH 20
Filtinsats, S1000 .....	A 18065
Waternump, A1 .....	Waternump
Waternump, max sughöjd, m .....	1,5
Regulator .....	Allysningsre- later ut- ventilsplidets

Bränsle	
Sjärlig vikt vid 15° C .....	0,8 - 0,9
Viskositet vid + 20° C, cSt .....	3,0
Flampunkt, °C .....	40
Lagsta flyttemperaturen 4,0, 1 m. vätsk, °C .....	30
förm, °C .....	- 20
Vattenhalt .....	ingen
Ashalt, max, % .....	0,00
Svavelhalt, max, % .....	0,3
Kokstäm vidret Conradson, max .....	0,03
Effektivt värdevärde, kcal/kg .....	10200
Vätsk, r/m .....	82

**OLJESYSTEM**

Oljepump, typ .....	Kugghjuls- pump	Oljetryck Värd. motr., kg/cm <sup>2</sup> .....	2 - 3
Oljefilter, Från .....	ZSI-56	Minimum, kg/cm <sup>2</sup> .....	0,5
Smörjvätska		Oljekvalitet .....	Service Oil
Motor .....	Trycksörning	Viskositet	
Bäckslag .....	Trycksörning	+ 20° C och över .....	SAE 50
		- 10° C till - 20° C .....	SAE 20
Oljebeslag			
Motor och bäckslag, liter .....	3		
Reduktionsväxel, liter .....	0,3		

**VÄSSYSTEM**

Hyväterpump .....	Pump med gummipöller	Lanspump .....	Pump med gummipöller
Jernöstat		Kapacitet	
Öppnings temperatur, °C .....	77	Vid fullvara, liter/minut .....	15
Helt öppen, °C .....	88,5	Vid tomgång, liter/minut .....	4

**ELSYSTEM**

Batterikapacitet, Ah (med likströms- generator) .....	63	<b>Alternativ utrustning</b>	
Startmotor, Bosch (effekt 1,3 kW) .....	6E(0) 12 V 1,3 PS	Växeltrostgenerator, Bosch .....	LC 028/12 J LK LR11 V 05 A 20
Generator, Bosch (effekt 90 W) .....	EH(R) 14 V 11 A 19	Belä, Bosch .....	BS,ADN 1/14/2
Belä, Bosch .....	JA 14 V 11 A	Batterikapacitet, Ah .....	130
Spänning, V .....	12	Generatoreffekt, W .....	490

**FRÖNHÖRIGT ÅTERGÅNGSMÖMENT**

Cylindlocksmotrar, kgm (f16) .....	10 (72)	Svaghjulsulnar, kgm (f16) .....	2,0 (19)
Vevstaksmotrar, kgm (f16b) .....	0,2 (37)	Insprutare, kgm (f16) .....	2,5 (18)
Radjagerbultar, kgm (f16) .....	10 (72)		

<u>Motornummer</u>	<u>Ungefärligt tillverkningsår</u>
1100	1925
1200	1926
1400	1927
1600	1928
1900	1929
2200	1930
2600	1931
2800	1932
3000	1933
3500	1934
3700	1935
4100	1936
4700	1937
5100	1938
5600	1939
6400	1940
6500	1941
7400	1942
7700	1943
8200	1944
8500	1945
8900	1946
9200	1947
14.000	1947-1948
15.000	1948
16.000	finns inga kort på dessa nummer
17.000	" " " " " "
18.000	1948
19.000	1949
20.000	1949-1950
21.000	1950-1951
22.000	1951
23.000	1951-1952
24.000	1952-1953
25.000	1953
26.000	1954
27.000	1954-1955
28.000	1955-1956
29.000	1956-1957
30.000	1957
31.000	1958
32.000	1959
33.000	1959-1960
34.000	1960
35.000	1961-1962
36.000	1962-1963
39.000	1964
41.000	1965
44.000	1966
47.000	1967
49.000	1968
52.000	1969
54.000	1970
57.500	1971
59.000	1972
59.500-	1973-1976

Efter 1973 går det ej att göra någon uppdelning.

