

YAMAHA

Marine

Water Vehicles

WaveRaider **RA760**

SUPPLEMENTARY
SERVICE MANUAL

(E)

PREFACE

This Supplementary Service Manual has been prepared to introduce new service and data for the RA760. For complete service information procedures, it is necessary to use this Supplementary Service Manual together with the following manual.

RA700, RA700A, RA1100 SERVICE MANUAL: GH1-28197-Z5-C1

410001-0*

**RA760
SUPPLEMENTARY SERVICE MANUAL
©1996 Yamaha Motor Co., Ltd.
1st Edition, January 1998
All rights reserved.**

No part of this publication may be reproduced or transmitted in any form or by any means including photocopying and recording without the written permission of the copyright holder.

Such written permission must also be obtained before any part of this publication is stored in a retrieval system of any nature.

**Printed in Japan
P/N GP2-28197-Z6-CX**

GENERAL INFORMATION

| | |
|---|---|
| IDENTIFICATION NUMBERS | 1 |
| PRIMARY I.D. NUMBER | 1 |
| ENGINE SERIAL NUMBER | 1 |
| PUMP SERIAL NUMBER | 1 |
| HULL IDENTIFICATION NUMBER (H.I.N.) | 1 |
| SPECIAL TOOLS | 2 |
| REMOVAL AND INSTALLATION | 2 |

SPECIFICATIONS

| | |
|---|---|
| GENERAL SPECIFICATIONS | 3 |
| MAINTENANCE SPECIFICATIONS | 4 |
| ENGINE | 4 |
| JET UNIT | 5 |
| ELECTRICAL | 5 |
| TIGHTENING TORQUE | 6 |
| SPECIFIED TORQUE | 6 |

PERIODIC INSPECTION AND ADJUSTMENT

| | |
|--|---|
| PERIODIC SERVICE | 7 |
| CONTROL SYSTEM | 7 |
| Throttle cable inspection and adjustment | 7 |
| FUEL SYSTEM | 7 |
| Trailing speed inspection and adjustment | 7 |
| Carburetor adjustment | 8 |

FUEL SYSTEM

| | |
|--------------------------------------|----|
| FUEL LINE | 9 |
| EXPLODED DIAGRAM | 9 |
| REMOVAL AND INSTALLATION CHART | 9 |
| CARBURETOR REMOVAL | 10 |
| EXPLODED DIAGRAM | 10 |
| REMOVAL AND INSTALLATION CHART | 10 |
| CARBURETOR | 11 |
| EXPLODED DIAGRAM | 11 |
| REMOVAL AND INSTALLATION CHART | 11 |
| FUEL PUMP | 12 |
| EXPLODED DIAGRAM | 12 |
| REMOVAL AND INSTALLATION CHART | 12 |

POWER UNIT

| | |
|--|----|
| REED VALVE | 13 |
| EXPLODED DIAGRAM | 13 |
| REMOVAL AND INSTALLATION CHART | 13 |
| SERVICE POINTS | 14 |
| Reed valve inspection | 14 |
| EXHAUST RING | 15 |
| EXPLODED DIAGRAM | 15 |
| REMOVAL AND INSTALLATION CHART | 15 |
| EXHAUST CHAMBER | 16 |
| EXPLODED DIAGRAM | 16 |
| REMOVAL AND INSTALLATION CHART | 16 |
| MUFFLER | 17 |
| EXPLODED DIAGRAM | 17 |
| REMOVAL AND INSTALLATION CHART | 17 |
| CYLINDER HEAD | 18 |
| EXPLODED DIAGRAM | 18 |
| REMOVAL AND INSTALLATION CHART | 18 |
| SERVICE POINTS | 19 |
| Cylinder head inspection | 19 |
| CYLINDER | 20 |
| EXPLODED DIAGRAM | 20 |
| REMOVAL AND INSTALLATION CHART | 20 |
| SERVICE POINTS | 21 |
| Cylinder inspection | 21 |
| PISTON | 22 |
| EXPLODED DIAGRAM | 22 |
| REMOVAL AND INSTALLATION CHART | 22 |
| SERVICE POINTS | 23 |
| Piston pin clip removal and installation | 23 |
| Piston inspection | 23 |
| Piston ring inspection | 24 |
| Piston pin and bearing inspection | 24 |
| ENGINE UNIT REMOVAL | 26 |
| EXPLODED DIAGRAM | 26 |
| REMOVAL AND INSTALLATION CHART | 26 |
| SERVICE POINTS | 27 |
| Shim removal | 27 |
| Mount bracket inspection | 27 |
| Coupling clearance inspection | 27 |


| | |
|--|----|
| FLYWHEEL MAGNETO AND BASE | 28 |
| EXPLODED DIAGRAM..... | 28 |
| REMOVAL AND INSTALLATION CHART..... | 28 |
| SERVICE POINTS..... | 29 |
| Coupling flange removal and installation..... | 29 |
| Flywheel magneto removal and installation..... | 29 |
| Coupling flange inspection..... | 29 |
| Flywheel magneto inspection..... | 29 |
| Idle gear assembly inspection..... | 29 |
| ELECTRICAL UNIT | 30 |
| EXPLODED DIAGRAM..... | 30 |
| REMOVAL AND INSTALLATION CHART..... | 30 |
| CRANKCASE | 31 |
| EXPLODED DIAGRAM..... | 31 |
| REMOVAL AND INSTALLATION CHART..... | 31 |
| SERVICE POINTS..... | 32 |
| Crankcase inspection..... | 32 |
| Crankcase installation..... | 32 |
| CRANKSHAFT | 33 |
| EXPLODED DIAGRAM..... | 33 |
| REMOVAL AND INSTALLATION CHART..... | 33 |
| SERVICE POINTS..... | 34 |
| Crankshaft inspection..... | 34 |
| INTERMEDIATE HOUSING REMOVAL | 35 |
| EXPLODED DIAGRAM..... | 35 |
| REMOVAL AND INSTALLATION CHART..... | 35 |
| INTERMEDIATE HOUSING | 36 |
| EXPLODED DIAGRAM..... | 36 |
| REMOVAL AND INSTALLATION CHART..... | 36 |
| SERVICE POINTS..... | 37 |
| Coupling removal and installation..... | 37 |
| Bearing removal and installation..... | 37 |
| Bearing inspection..... | 37 |
| Coupling inspection..... | 37 |
| Oil seal installation..... | 38 |

ELECTRICAL SYSTEM

| | |
|------------------------------------|----|
| ELECTRICAL COMPONENTS | 39 |
| IGNITION SYSTEM | 40 |
| WIRING DIAGRAM..... | 40 |
| CHARGE COIL..... | 41 |
| PULSER COIL..... | 41 |
| CDI UNIT..... | 41 |

HULL AND HOOD


| | |
|--|----|
| EXHAUST SYSTEM | 42 |
| EXPLODED DIAGRAM..... | 42 |
| REMOVAL AND INSTALLATION CHART..... | 42 |
| FLUSHING AND VENTILATION SYSTEM | 43 |
| EXPLODED DIAGRAM..... | 43 |
| REMOVAL AND INSTALLATION CHART..... | 43 |




A60700-0*

**IDENTIFICATION NUMBERS
PRIMARY I.D. NUMBER**

The primary I.D. number is stamped on a plate attached to the hull on the front of the engine hood




Starting primary I.D. number:
GP2: 800101 ~,
600101 ~ (FRA)



ENGINE SERIAL NUMBER

The engine serial number is stamped on a plate attached to the crankcase.


Starting serial number:
64X: 000101 ~



PUMP SERIAL NUMBER


The jet pump unit serial number is stamped on a plate attached to the intermediate housing.

Starting serial number:
64X: 500101 ~



**HULL IDENTIFICATION NUMBER
(H.I.N.)**

The H.I.N. is stamped on a plate attached to the rear end of the footrest floor.



**SPECIAL TOOLS
REMOVAL AND INSTALLATION**

1. Coupler wrench
P/N. YW-06546
90890-06546
2. Flywheel holder
P/N. YW-06547
90890-06547




GENERAL SPECIFICATIONS

| Item | Unit | FA760 |
|--|---|---|
| MODEL CODE: Hull Engine | | GP2 64X |
| DIMENSIONS: Length Width Height Dry weight | mm (in) mm (in) mm (in) kg (lb) | 2,860 (112.6) 1,120 (44.1) 970 (38.2) 211 (465) |
| PERFORMANCE: Maximum speed Maximum output Maximum fuel consumption Cruising range (at full throttle) | km/h (mph) kW (hp) @r/min (l/h (US gal/h, imp gal/h)) hr. | 84 (52.2) 66.2 (90) @6,350 38 (10.04, 8.36l) 1.3 |
| ENGINE: Engine type Number of cylinders Displacement Bore and stroke Compression ratio Intake system Carburetor type Number of carburetors Carburetor starting system Scavenging system Lubrication system Cooling system Starting system Ignition system Ignition timing Spark plug (NGK) Battery capacity Lighting coil | cm ³ (cu. in) mm (in) Degree V/kC (A·h) A @r/min | 2-stroke 2 754 (46.0) 84 × 68 (3.31 × 2.68l) F: 7.2, R: 6.8 Reed valve Floatless type 2 Choke Loop charged Oil Injection Water-cooled Electric starter Digital C.D.I. F: 15 - 20 BTDC, R: 15 - 18 BTDC BR8HS 12/68.4 (19) 2 ~ 4 @5,500 |
| DRIVE UNIT: Propulsion system Jet pump type Impeller rotation (rear view) Transmission Nozzle angle | Degree | Jet pump Axial flow, single stage Counterclockwise Direct drive from engine 23 ± 1 |
| FUEL AND OIL: Fuel Oil Fuel and oil mixing ratio (wide open throttle) Fuel tank capacity Reserve Oil tank capacity | l (US gal, imp gal) l (US gal, imp gal) l (US gal, imp gal) | Regular gasoline 2 stroke outboard motor oil 50 : 1 50 (13.2, 11.0) 8.8 (2.3, 1.9) 3.8 (1.0, 0.8) |



MAINTENANCE SPECIFICATIONS

ENGINE

| Item | Unit | RA760 |
|---------------------------------------|---|-----------------------------------|
| Cylinder head: | | |
| Warpage limit | mm (in) | 0.1 (0.004) |
| Cylinder: | | |
| Bore size | mm (in) | 84.00 ~ 84.02 (3.307 ~ 3.308) |
| Wear limit | mm (in) | 84.10 (3.311) |
| Taper limit | mm (in) | 0.08 (0.003) |
| Out of round limit | mm (in) | 0.05 (0.002) |
| Piston: | | |
| Piston size | mm (in) | 83.897 ~ 83.916 (3.3030 ~ 3.3038) |
| Measuring point* | mm (in) | 10 (0.39) |
| Piston clearance | mm (in) | 0.100 ~ 0.105 (0.0039 ~ 0.0041) |
| Wear limit | mm (in) | 0.155 (0.0061) |
| Piston ring: | | |
| Type | | Keystone |
| Sectional sketch |  (B × T) | 1.5 × 3.2 (0.06 × 0.13) |
| Side clearance | mm (in) | 0.02 ~ 0.06 (0.0008 ~ 0.0024) |
| End gap | (installed) | 0.2 ~ 0.4 (0.008 ~ 0.016) |
| Piston pin: | | |
| Outside diameter | mm (in) | 19.995 ~ 20.000 (0.7872 ~ 0.7874) |
| Limit | mm (in) | 19.98 (0.786) |
| Crankshaft: | | |
| Crank width | "A" | 61.95 ~ 62.00 (2.439 ~ 2.441) |
| Runout limit | "B" | 0.05 (0.002) |
| Connecting rod big end side clearance | mm (in) | 0.25 ~ 0.75 (0.010 ~ 0.030) |
| Small end free play limit | "C" "D" | 2.0 (0.08) |
| Carburetor: | | |
| Stamped mark | | 64X01 (F)/64X02 (R) |
| Main nozzle | ø mm (in) | 3.2 (0.13) |
| Main jet | (M.J.) | 135 (F)/137.5 (R) |
| Pilot jet | (P.J.) | 115 |
| Low speed screw | Turns out | 1-3/4 ± 1/4 |
| Throttle valve | (Th.V.) | 160 |
| Valve seat | (V.S.) | ø mm (in) |
| High speed screw | Turns out | 1/2 ± 1/4 |
| Trolling speed | r/min | 1.300 ± 50 |
| Reed valve: | | |
| Thickness | mm (in) | 0.4 (0.016) |
| Valve lift | mm (in) | 9.0 ± 0.2 (0.35 ± 0.01) |
| Bending limit | mm (in) | 0.2 (0.008) |



JET UNIT

| Item | Unit | RA760 |
|-----------------------|---------|-------------------------|
| Jet pump: | | |
| Impeller clearance | mm (in) | 0.3 ~ 0.4 (0.01 ~ 0.02) |
| Service limit | mm (in) | 0.6 (0.024) |
| Impeller shaft runout | mm (in) | 0.3 (0.012) |

ELECTRICAL

| Item | Unit | RA760 |
|----------------------------------|---|-----------------------------------|
| Ignition system: | | |
| Type | | CDI magneto |
| Ignition timing | at 1,200 rpm at 5,400 rpm | 15 BTDC F: 20 BTDC, R: 18 BTDC |
| Stator: | | |
| Model/Manufacturer | | F4T32371/MITSUBISHI |
| Pulser coil resistance (color) | Ω | 445.5 ~ 544.5 (W/R - W/B) |
| Charging coil resistance (color) | Ω | 316.8 ~ 387.2 (Br - L) |
| CDI unit: | | |
| Stamped mark | | 64X 00 |
| Model/Manufacturer | | F8T33671/MITSUBISHI |
| Over revolution limit | r/min | 7,000 ~ 7,400 |
| Overheat revolution control | r/min | 3,000 ~ 3,800 |
| Ignition coil: | | |
| Stamped mark | | 64X-00 |
| Model/Manufacturer | | F6T54381/MITSUBISHI |
| Primary winding resistance | Ω | 0.078 ~ 0.106 (Q - B) |
| Secondary winding resistance | k Ω | 14.3 ~ 30.5 (High tension cords) |
| Charging system: | | |
| Type | | Flywheel magneto |
| Lighting coil resistance (color) | Ω | 1.14 ~ 1.40 (G - G) |
| Rectifier/regulator: | | |
| Model/Manufacturer | | SH589-12/SHINDENGEN |
| Regulator voltage | V | 14.3 ~ 15.3 |
| Thermo sensor: | | |
| ON | $^{\circ}\text{C}$ ($^{\circ}\text{F}$) | 90 ~ 96 (194 ~ 205) |
| OFF | $^{\circ}\text{C}$ ($^{\circ}\text{F}$) | 76 ~ 90 (169 ~ 194) |
| Starter motor: | | |
| Model/Manufacturer | | SM13466/MITSUBA |
| Brush length limit | mm (in) | 6.5 (0.26) |
| Commutator undercut limit | mm (in) | 0.2 (0.01) |
| Commutator diameter limit | mm (in) | 27 (1.06) |
| Fuse: | | |
| Rating | A | 10 |


**TIGHTENING TORQUE
SPECIFIED TORQUE**


| Part to be tightened | Part name | Size | Q'ty | Tightening torque | | | Remarks | |
|------------------------------|-----------|------|------|-------------------|------|-------|---------|--|
| | | | | Nm | m·kg | ft·lb | | |
| ENGINE: | | | | | | | | |
| Electric box | Bolt | M8 | 3 | 17 | 1.7 | 12 | | |
| Mounting bolt | Bolt | M8 | 4 | 17 | 1.7 | 12 | | |
| Reed valve | Screw | M4 | 16 | 1 | 0.1 | 0.7 | | |
| Exhaust ring | Bolt | M8 | 4 | 30 | 3.0 | 22 | | |
| Exhaust ring stay | 1st | Bolt | M10 | 3 | 22 | 2.2 | 16 | |
| | 2nd | | | | 40 | 4.0 | 29 | |
| Muffler stay - Cylinder head | Bolt | M10 | 4 | 40 | 4.0 | 29 | | |
| Muffler stay - Muffler 2 | 1st | Bolt | M10 | 2 | 2 | 0.2 | 1.4 | |
| | 2nd | | | | 47 | 4.7 | 34 | |
| Muffler 2 | Bolt | M10 | 2 | 40 | 4.0 | 29 | | |
| Muffler 1 | 1st | Bolt | M10 | 8 | 22 | 2.2 | 16 | |
| | 2nd | | | | 40 | 4.0 | 29 | |
| Cylinder body | 1st | Bolt | M10 | 6 | 23 | 2.3 | 17 | |
| | 2nd | | | | 40 | 4.0 | 29 | |
| Cylinder head | 1st | Bolt | M8 | 10 | 15 | 1.5 | 11 | |
| | 2nd | | | | 36 | 3.6 | 26 | |
| Spark plug | Bolt | M14 | 2 | 20 | 2.0 | 14 | | |
| Flywheel bolt | Bolt | M10 | 1 | 70 | 7.0 | 51 | | |
| Crankcase | 1st | Bolt | M8 | 8 | 15 | 1.5 | 11 | |
| | 2nd | | | | 28 | 2.8 | 20 | |
| Mount bracket | 1st | Bolt | M10 | 7 | 23 | 2.3 | 17 | |
| | 2nd | | | | 53 | 5.3 | 38 | |
| Coupling | Nut | M27 | 1 | 37 | 3.7 | 27 | | |
| Flame arrester cover | Bolt | M6 | 6 | 2 | 0.2 | 1.4 | | |
| Starter motor terminal nut | Nut | M6 | 1 | 5 | 0.5 | 3.6 | | |
| JET UNIT: | | | | | | | | |
| Mounting bolt | Bolt | M10 | 4 | 34 | 3.4 | 25 | | |
| | | M6 | 2 | 12 | 0.7 | 9 | | |
| Ride plate | Bolt | M8 | 6 | 17 | 1.7 | 12 | | |
| Speed sensor cover | Screw | M5 | 4 | 4 | 0.4 | 2.9 | | |
| Impeller (left-hand threads) | Bolt | M20 | 1 | 18 | 1.8 | 13 | | |
| Coupling | Nut | M27 | 1 | 37 | 3.7 | 27 | | |
| Intermediate housing | Bolt | M8 | 3 | 17 | 1.7 | 12 | | |




PERIODIC SERVICE
CONTROL SYSTEM

Throttle cable inspection and adjustment

NOTE:
Before adjusting the throttle lever free play, the trolling speed should be adjusted.




1. Measure:
- Throttle lever free play (a)
Out of specification → Adjust.

 **Throttle lever free play:**
7 - 10 mm (0.28 ~ 0.39 in)

FUEL SYSTEM

Trolling speed inspection and adjustment


1. Check:
- Trolling speed
Out of specification → Adjust.

 **Trolling speed:**
1,300 ± 50 r/min

- Checking steps: (vehicle on water)**
- Start the engine and allow it to warm up for a few minutes.
 - Attach the engine tachometer to the spark plug lead.


 **Engine tachometer:**
YU-8036-A/90890-06760

- Measure the engine trolling speed.



2. Adjust:
- Trolling speed

- Adjustment steps:**
- Screw in the low speed screws (1) until they are lightly seated.
 - Back the screws out by the specified number of turns.




Low speed screw:
1-3/4 ± 1/4 (turns out)

- Start the engine and allow it to warm up for a few minutes.
- Turn the throttle stop screw ② in or out until the specified speed is obtained.

| | |
|------------|--------------------------|
| Turning in | Increase trolling speed. |
|------------|--------------------------|

| | |
|-------------|--------------------------|
| Turning out | Decrease trolling speed. |
|-------------|--------------------------|



Carburetor adjustment

1. Adjust:

- High speed screw

Adjustment steps:

- Screw in the high speed screws ① until they are lightly seated.
- Back the screws out by the specified number of turns.




High speed screw:
1/2 ± 1/4 (turns out)



▲ WARNING

Gasoline (petrol) is highly flammable and explosive. Handle with special care.

**FUEL LINE
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|------------------------------------|------|---|
| | FUEL HOSE REMOVAL | | Follow the left "Step" for removal. |
| 1 | Battery breather hose | 1 | |
| 2 | Air ventilation hose | 3 | |
| 3 | Fuel hose (ON) | 1 | |
| 4 | Fuel hose (RES) | 1 | |
| 5 | Fuel hose (carburetor - fuel tank) | 1 | |
| 6 | Fuel hose (filter - carburetor) | 1 | |
| 7 | Fuel hose (OUT) | 1 | |
| 8 | Pilot water hose | 1 | |
| 9 | Cooling water hose | 1 | |
| | | | Reverse the removal steps for installation. |



**CARBURETOR REMOVAL
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|---------------------------|------|--|
| | CARBURETOR REMOVAL | | Follow the left "Step" for removal. |
| 1 | Oil delivery hose | 2 | <div style="border: 1px solid black; padding: 5px; display: inline-block;"> Cable guide set position (A): 17 mm (0.67 in) </div> |
| 2 | Carburetor cover | 1 | |
| 3 | Choke cable | 1 | |
| 4 | Throttle cable | 1 | |
| 5 | Fuel hose | 2 | |
| 6 | Pulse hose | 2 | |
| 7 | Nut | 4 | |
| 8 | Carburetor assembly | 1 | |
| | | | Reverse the removal steps for installation. |



**CARBURETOR
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|-------------------------------|------|---|
| | CARBURETOR DISASSEMBLY | | |
| | Carburetor assembly | | Follow the left "Step" for removal! Refer to "CARBURETOR REMOVAL". |
| 1 | Diaphragm assembly | 1 | |
| 2 | Float arm | 1 | |
| 3 | Needle valve assembly | 1 | |
| 4 | Body assembly | 1 | |
| 5 | Main jet | 1 | |
| 6 | Pilot jet | 1 | |
| 7 | High speed screw | 1 | |
| 8 | Low speed screw | 1 | |
| | | | Reverse the removal steps for installation. |




**FUEL PUMP
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART



| Step | Procedure/Part name | Q'ty | Service points |
|------|------------------------------|------|---|
| | FUEL PUMP DISASSEMBLY | | |
| | Carburetor assembly | | Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL". |
| 1 | Pump cover | 1 | |
| 2 | Diaphragm | 1 | |
| 3 | O-ring | 1 | |
| 4 | Diaphragm body assembly | 1 | |
| 5 | Diaphragm | 1 | |
| 6 | O-ring | 1 | |
| 7 | Filter | 1 | |
| | | | Reverse the removal steps for installation. |

**REED VALVE
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Qty | Service points |
|------|---------------------------|-----|--|
| | REED VALVE REMOVAL | | Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL" in chapter 4. |
| | Carburetor assembly | | |
| 1 | Plate | 1 | |
| 2 | Intake manifold assembly | 1 | |
| 3 | Reed valve assembly | 2 | |
| 4 | Plate | 1 | |
| 5 | Valve stopper | 4 | Reverse the removal steps for installation. |
| 6 | Reed valve | 4 | |



SERVICE POINTS

Reed valve inspection

1. Inspect:
 - Reed valve
Crack/Damage → Replace.
2. Measure:
 - Valve bending (a)
Out of specification → Replace.




Valve bending limit:
0.2 mm (0.008 in)

3. Measure:
 - Valve stopper height (a)
Out of specification → Adjust or replace.



Valve stopper height:
9.0 ± 0.2 mm (0.35 ± 0.01 in)


**EXHAUST RING
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|-----------------------------|------|--|
| | EXHAUST RING REMOVAL | | Follow the left "Step" for removal |
| 1 | Water hose | 2 | <p>NOTE:</p> <ul style="list-style-type: none"> ● Pull and slide the exhaust joint. ● Loosen the clamp at the muffler side. <hr/> <p>CAUTION:</p> <p>Tighten the clamp, before installing the ring on the muffler.</p> <hr/> <p>Reverse the removal steps for installation.</p> |
| 2 | Exhaust joint | 1 | |
| 3 | Clamp | 1 | |
| 4 | Ring | 1 | |
| 5 | Clamp | 1 | |
| 6 | Joint | 1 | |


**EXHAUST CHAMBER
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|--------------------------------|------|--|
| | EXHAUST CHAMBER REMOVAL | | Follow the left "Step" for removal. Refer to "EXHAUST RING". |
| | Ring | | |
| 1 | Exhaust hose | 1 | |
| 2 | Bolt (muffler) | 5 | CAUTION: |
| 3 | Chamber assembly | 1 | Tighten the bolts in sequence. |
| 4 | Bolt (muffler stay) | 4 | |
| 5 | Muffler stay | 1 | |
| 6 | Bolt (with washer) | 6 | |
| 7 | Bolt (with washer) | 7 | |
| | | | Reverse the removal steps for installation. |


**MUFFLER
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART



| Step | Procedure/Part name | Q'ty | Service points |
|------|------------------------|------|--|
| | MUFFLER REMOVAL | | |
| | Exhaust chamber | | Follow the left "Step" for removal. Refer to "EXHAUST CHAMBER". |
| 1 | Water inlet hose | 1 | |
| 2 | Bolt (with washer) | 8 | |
| 3 | Muffler | 1 | |
| 4 | Gasket | 1 | |
| | | | Reverse the removal steps for installation |

**CYLINDER HEAD
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------------------------------|---------------------|------|---|
| CYLINDER HEAD REMOVAL | | | Follow the left "Step" for removal. Refer to "MUFFLER". CAUTION: Tighten the bolts in sequence and in two steps of torque. Reverse the removal steps for installation. |
| | Muffler | | |
| 1 | Spark plug | 2 | |
| 2 | Water hose | 2 | |
| 3 | Bolt (with washer) | 10 | |
| 4 | Cylinder head | 1 | |



SERVICE POINTS

Cylinder head inspection

1. Eliminate:
 - Carbon deposits
 - Use a rounded scraper ①.

NOTE:

Take care to avoid damaging the spark plug heads. Do not use a sharp instrument. Avoid scratching the aluminum.

2. Inspect:
 - Cylinder head water jacket
 - Mineral deposits/Corrosion → Clean.
3. Measure:
 - Cylinder head warpage
 - Out of specification → Resurface.




Warpage limit:
0.1 mm (0.004 in)

Warpage measurement and resurfacing steps:

- Attach a straight edge and a thickness gauge on the cylinder head.
- Measure the warpage.

**CYLINDER
EXPLODED DIAGRAM**

| | |
|-----|--------------------------------|
| 1st | 23 Nm (2.3 m • xg, 17 ft • lb) |
| 2nd | 40 Nm (4.0 m • kg, 29 ft • lb) |



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|-------------------------|-------------------------------------|------|--|
| CYLINDER REMOVAL | | | |
| 1 | Cylinder head Bolt (with washer) | 8 | Follow the left "Step" for removal. Refer to "CYLINDER HEAD". CAUTION: Tighten the bolts in sequence and in two steps of torque. |
| 2 | Cylinder | 1 | CAUTION: After installing, check the smooth movement of the piston. |
| 3 | Pin | 2 | Reverse the removal steps for installation. |



SERVICE POINTS


Cylinder Inspection

1. Eliminate:

- Carbon deposits
Use a rounded scraper ☺.

2. Inspect:

- Cylinder water jacket
Mineral deposits/Corrosion → Clean.
- Cylinder inner surface
Score marks → Repair or replace.
Use #600 - 800 grit wet sandpaper.





3. Measure:

- Cylinder bore "D"
Use cylinder gauge.
Out of limit → Replace.

NOTE:


Measure the cylinder bore "D" in parallel. Then, find the average of the measurement.



|  | Standard | Limit |
|---|--|------------------------|
| Cylinder bore "D" | 84.00 - 84.02 mm (3.307 - 3.308 in) | 84.10 mm (3.311 in) |
| Tapet "T" | — | 0.08 mm (0.003 in) |
| Out of round "R" | — | 0.05 mm (0.002 in) |

D = Maximum (D₁ - D₆)
T = (Maximum D₁ or D₂) - (Maximum D₅ or D₆)
R = (Maximum D₁, D₃ or D₅) - (Minimum D₂, D₄ or D₆)

**PISTON
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|-----------------------|-----------------------------|------|--|
| PISTON REMOVAL | | | |
| 1 | Cylinder Piston pin clip | 4 | Follow the left "Step" for removal. Refer to "CYLINDER". CAUTION: Do not allow the clip open ends to meet the piston pin slot A . |
| 2 | Piston | 2 | NOTE: Be sure the arrow D side is positioned exhaust side. |
| 3 | Piston ring | 4 | CAUTION: Align each end gap with the locating pin. Reverse the removal steps for installation. |

SERVICE POINTS



Piston pin clip removal and installation

1. Remove and install:
 - Piston pin clip

NOTE: _____
 Before removing and installing piston pin clip, cover crankcase with a clean rag to prevent piston pin clip from falling into crankcase cavity.

Piston inspection


1. Eliminate:
 - Carbon deposits
 From the piston crown and ring groove.



2. Inspect:
 - Piston wall
 Score marks → Repair or replace.
 Use #600 ~ 800 grit wet sandpaper.


NOTE: _____
 Sand in a criss-cross pattern. Do not sand excessively.




3. Measure:
 - Piston skirt diameter
 Use micrometer.
 Out of specification → Replace.

|  Piston diameter | Distance [Ⓐ] |
|---|-----------------------|
| 83.897 ~ 83.916 mm (3.3030 ~ 3.3038 in) | 10 mm (0.39 in) |

4. Calculate:
 - Piston clearance
 Out of limit → Replace piston, piston rings as a set.

| | | | | |
|-------------------------|---|----------------------|---|------------------------|
| PISTON CLEARANCE | = | CYLINDER BORE | - | PISTON DIAMETER |
|-------------------------|---|----------------------|---|------------------------|

| |
|--|
|  Piston clearance: 0.100 ~ 0.105 mm (0.0039 ~ 0.0041 in) |
|--|



Piston ring inspection

1. Measure:

- Side clearance
Out of specification → Replace piston and/or ring
Use a thickness gauge ①.



Side clearance:

Top
2nd
0.02 - 0.06 mm
(0.0008 - 0.0024 in)

2. Measure:

- End gap
Out of specification → Replace rings as a set.
Use a thickness gauge ①.



End gap:

Top
2nd
0.2 - 0.4 mm (0.008 - 0.016 in)


NOTE:

- Install the piston ring into the cylinder.
- Push the ring with the piston crown.

Piston pin and bearing inspection

1. Inspect:

- Piston pin
- Bearing
Signs of heat discoloration → Replace.



2. Measure:


- Piston pin outside diameter
Use micrometer ①.
Out of limit → Replace.

**Piston pin outside diameter:****Standard**

19.995 - 20.000 mm
(0.7872 - 0.7874 in)


Limit

19.98 mm (0.786 in)



3. Check:

- Free play (when the piston pin is in place in the piston)
There should be no noticeable free play.
Free play exist → Replace piston pin and/or piston.




4. Check:

- Free play
There should be no noticeable free play
Free play exist → Inspect the connecting rod for wear/Replace the pin and/or connecting rod as required.



**ENGINE UNIT REMOVAL
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|--------------------------------------|------|---|
| | ENGINE UNIT REMOVAL | | Follow the left "Step" for removal. |
| 1 | Battery lead | 2 | |
| 2 | Handle switch and meter lead coupler | 3 | |
| 3 | Electrical box | 1 | |
| 4 | Choke cable | 1 | |
| 5 | Throttle cable | 1 | |
| 6 | Grease hose | 1 | |
| 7 | Exhaust hose | 1 | |
| 8 | Coupling cover | 1 | |
| 9 | Water inlet hose | 1 | |
| 10 | Pilot water hose | 1 | |
| 11 | Fuel hose | 2 | |
| 12 | Engine mounting bolt | 4 | |
| 13 | Shim | * | |
| 14 | Engine unit | 1 | |
| | | | Reverse the removal steps for installation. |

*: As required



SERVICE POINTS

Shim removal


1. Remove:
 - Shim

NOTE:

Mark the engine mounting shim packs prior to the mounting bolt removal for ease of reassembly and coupling alignment.

Mount bracket inspection

1. Inspect:
 - Mount bracket
 - Crack/Damage → Replace.



Coupling clearance inspection

1. Check:
 - Clearance (a)
 - Clearance (b)
 - Out of specification → Adjust using shim.


NOTE:

- Before measuring the clearance, remove the coupling rubber.
- Attach a straight edge and a thickness gauge.




Clearance (a):
0 - 1.0 mm (0 - 0.039 in)
Clearance (b):
2 - 4 mm (0.079 - 0.157 in)

**FLYWHEEL MAGNETO AND BASE
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|--|------|---|
| | FLYWHEEL MAGNETO AND BASE DISASSEMBLY | | Follow the left "Step" for removal. |
| | Fuel tank | | Refer to "FUEL TANK" in chapter 4. |
| | Oil pump | | Refer to "OIL PUMP" in chapter 4. |
| 1 | Grease hose | 1 | |
| 2 | Flywheel cover | 1 | |
| 3 | Base assembly | 1 | |
| 4 | Coupling flange | 1 | |
| 5 | Flywheel magneto | 1 | |
| 6 | Idle gear assembly | 1 | |
| | | | : Reverse the removal steps for installation. |




SERVICE POINTS

Coupling flange removal and installation

1. Remove and install:
 - Coupling flange

| | |
|--|-------------------------|
| | Coupler wrench: |
| | YW-06546/90890-06546 |
| | Flywheel holder: |
| | YW-06547/90890-06547 |




Flywheel magneto removal and installation

1. Remove and install:
 - Bolt

| | |
|--|-------------------------|
| | Flywheel holder: |
| | YW-06547/90890-06547 |

2. Remove:
 - Flywheel magneto

| | |
|--|-------------------------|
| | Flywheel puller: |
| | YB-06117/90890-06521 |



- [A] For USA and CANADA
- [B] Except for USA and CANADA

CAUTION

To prevent damage to the engine or tools, screw in the flywheel puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel.

Coupling flange inspection

1. Inspect:
 - Coupling flange

Wear/Damage → Replace.

Flywheel magneto inspection

1. Inspect:
 - Flywheel gear


Wear/Damage → Replace.

Idle gear assembly inspection


1. Inspect:
 - Pinion gear (a)
 - Inner gear (b)

Wear/Damage → Replace.
2. Check:
 - Clutch movement

Unsmooth movement → Replace.



**ELECTRICAL UNIT
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|--------------------------------|------|--|
| | ELECTRICAL UNIT REMOVAL | | Follow the left "Step" for removal. Refer to "ENGINE UNIT REMOVAL". Refer to "FLYWHEEL MAGNETO AND BASE". Reverse the removal steps for installation. |
| | Electrical box | | |
| | Base assembly | | |
| 1 | Spark plug cap | 2 | |
| 2 | Thermo switch | 1 | |
| 3 | Starter motor negative lead | 1 | |
| 4 | Housing | 1 | |



**CRANKCASE
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|------------------------------|------|---|
| | CRANKCASE DISASSEMBLY | | |
| | Base assembly | | Follow the left "Step" for removal. Refer to "FLYWHEEL MAGNETO AND BASE". |
| | Piston | | Refer to "PISTON". |
| 1 | Engine mount bracket | 2 | |
| 2 | Starter motor | 1 | |
| 3 | Bolt (with washer) | 8 | NOTE: _____ Tighten the bolts in sequence and in two steps of torque. |
| 4 | Mount rubber | 1 | NOTE: _____ Be sure that the "F" mark ⓐ is on the fly-wheel side. |
| 5 | Crankcase | 1 | Reverse the removal steps for installation. |

**SERVICE POINTS****Crankcase inspection**

1. Inspect.
 - Contacting surface
Scratch → Replace.
 - Crankcase
Crack/Damage → Replace.

**Crankcase installation**

1. Apply:
 - Gasket Maker


NOTE:

Clean the contacting surface of crankcase before applying the Gasket Maker.

2. Check:
 - Crankshaft
Rough action → Repair.




**CRANKSHAFT
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|---|------|---|
| 1 | CRANKSHAFT REMOVAL Crankcase Crankshaft assembly | 1 | Follow the left "Step" for removal. Refer to "CRANKCASE". CAUTION <ul style="list-style-type: none"> Do not allow the bearing clip open ends to meet the crankcase contacting surface. Place the locating pins on the bearing into the crankcase body groove. |
| 2 | Dowel pin | 5 | |
| 3 | Oil seal | 3 | |
| | | | Reverse the removal steps for installation. |



SERVICE POINTS

Crankshaft inspection


1. Measure:

- Crank width **A**

Out of specification → Replace.



Crank width:
61.95 - 62.00 mm
(2.439 - 2.441 in)



2. Measure:


- Deflection **B**

Use a dial gauge.

Out of specification → Replace



Maximum deflection:
0.05 mm (0.002 in)



3. Measure:


- Big end side clearance **C**

Use a thickness gauge.

Out of specification → Replace.



Big end side clearance:
0.25 - 0.75 mm
(0.010 - 0.030 in)



4. Measure:


- Small end free play **D**

Use a dial gauge.

Out of specification → Replace.



Small end free play:
2.0 mm (0.08 in)



5. Inspect:


- Crankshaft bearing

Pitting/Damage → Replace.

NOTE:

Lubricate the bearings immediately after examining them to prevent rusting.

**INTERMEDIATE HOUSING REMOVAL
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART


| Step | Procedure/Part name | Q'ty | Service points |
|------|-------------------------------------|------|--|
| | INTERMEDIATE HOUSING REMOVAL | | Follow the left "Stop" for removal. |
| | Engine unit | | Refer to "ENGINE UNIT REMOVAL". |
| 1 | Bolt (with washer) | 3 | |
| 2 | Bearing housing assembly | 1 | |
| 3 | Pin | 2 | |
| 4 | Bolt (with washer) | 3 | |
| 5 | Housing | 1 | |
| 6 | Shim | * | |
| | | | NOTE: _____ Install the previously marked shims back into their original location. _____ Reverse the removal steps for installation. |


*: As required

**INTERMEDIATE HOUSING
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART


| Step | Procedure/Part name | Q'ty | Service points |
|------|---|------|--|
| | INTERMEDIATE HOUSING DISASSEMBLY | | Follow the left "Step" for removal. |
| | Bearing housing assembly | | Refer to "INTERMEDIATE HOUSING REMOVAL". |
| 1 | Coupling | 1 |  Distance: Ⓐ: 1.6 - 2.0 mm (0.06 - 0.08 in) Ⓑ: 14.5 - 15.5 mm (0.57 - 0.61 in) Ⓒ: 6.8 - 7.2 mm (0.27 - 0.28 in) Ⓓ: 17.8 - 17.7 mm (0.69 - 0.70 in) |
| 2 | Shaft | 1 | |
| 3 | Oil seal | 1 | |
| 4 | Oil seal | 1 | |
| 5 | Clip | 1 | |
| 6 | Bearing | 1 | |
| 7 | Clip | 1 | |
| 8 | Spacer | 1 | |
| | | | Reverse the removal steps for installation. |

**SERVICE POINTS****Coupling removal and installation**

1. Remove and install:
 - Coupling




Coupler wrench:
 YW-06546/90890-06546
Shaft holder:
 YW-38742/90890-08089

**Bearing removal and installation**

1. Remove and install:
 - Bearing




Driver rod:
 YB-06071/90890-06606
Bearing outer race attachment:
 YB-06018/90890-06626

**Bearing inspection**

1. Inspect:
 - Bearing
 - Rotate inner race by hand.
 - Rough spots/Seizure → Replace.
 - Shaft
 - Pitting/Damage → Replace.
 - Hose
 - Wear/Cracks → Replace.

Coupling inspection

1. Inspect:
 - Coupling flange
 - Coupling rubber
 - Wear/Damage → Replace.



Oil seal installation

1. Install:

- Oil seal [T = 8 mm (0.31 in)]




Distance (a):
6.8 ~ 7.2 mm (0.27 ~ 0.28 in)



Driver rod:
YB-06071/90890-06606
Bearing outer race attachment:
YB-06016/90890-06628

NOTE:

Fill the with water resistant grease clip inner circumference before installing the oil seal.




2. Install:

- Shaft



Distance (a):
14.5 ~ 15.5 mm (0.57 ~ 0.61 in)



3. Install:

- Oil seal [T = 10 mm (0.38 in)]



Distance (a):
1.5 ~ 2.0 mm (0.06 ~ 0.08 in)

NOTE:

Fill the with water resistant grease clip inner circumference before installing the oil seal.

4. Fill:




- Shaft




Water resistant grease:
8 cm³ (0.5 cu. in)




ELECTRICAL COMPONENTS



- | | |
|---------------------------------|--|
| ① Oil level sensor lead | ⓫ Handle switch and meter extension lead |
| ② Multi function meter lead | ⓬ Fuel level sensor lead |
| ③ High tension cord | ⓭ 2P connector (Black) |
| ④ Thermo sensor lead | ⓮ 2P connector (White) |
| ⑤ Handle switch lead | ⓯ 3P connector (White) |
| ⑥ Speed sensor lead | ⓰ 4P connector (White) |
| ⑦ Battery (positive) lead | ⓱ 2P connector (Green) |
| ⑧ Flywheel magneto base lead | ⓲ 2P connector (White) |
| ⑨ Battery (negative) lead | |
| ⑩ Starter motor (positive) lead | |




**IGNITION SYSTEM
WIRING DIAGRAM**



- ① Pulser coil
- ② Charge coil
- ③ CDI unit
- ④ Stop switch
- ⑤ Engine stop switch
- ⑥ Thermo switch
- ⑦ Ignition coil


- B : Black
- Br : Brown
- L : Blue
- O : Orange
- P : Pink
- W : White
- W/B : White/Black
- W/R : White/Red



CHARGE COIL

1. Measure:
 - Charge coil resistance
 Out of specification → Replace.

Charge coil resistance:
 Brown (Br) – Blue (L)
 316.8 ~ 387.2 Ω at 20°C (68°F)



PULSER COIL

1. Measure:
 - Pulser coil resistance
 Out of specification → Replace.

Pulser coil resistance:
 White/Red (W/R) –
 White/Black (W/B)
 445.5 ~ 544.5 Ω at 20°C (68°F)

CDI UNIT

1. Measure:
 - CDI unit resistance
 Out of specification → Replace.

Pocket fester:
 YU-03112/90890-03112

NOTE:

- The resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, the polarity of the leads is reversed.
- The needle swings once to the “∞” mark and then returns to the home position.
- The “∞” mark stands for discontinuity.


- B : Black
- Br : Brown
- L : Blue
- O : Orange
- P : Pink
- W : White
- W/B : White/Black
- W/R : White/Red

64X00

Unit: kΩ

| ⊕ | ⊖ | W | P | W/B | W/R | O | Br | L | B |
|-----|---|----------|---|----------|-----------|----------|------------|----------|----------|
| W | | ∞ | ∞ | 3.8 ~ 16 | 9.5 ~ 4.0 | 11 ~ 45 | 80 ~ 400 | 3.4 ~ 14 | 3.8 ~ 16 |
| P | | 7.5 ~ 35 | ∞ | 17 ~ 70 | 22 ~ 100 | 40 ~ 300 | 70 ~ 1,000 | 16 ~ 70 | 17 ~ 80 |
| W/B | | 10 ~ 45 | ∞ | ∞ | 4.4 ~ 18 | 2 ~ 9 | 70 ~ 400 | 6 ~ 28 | 0 ~ 0.6 |
| W/R | | 16 ~ 70 | ∞ | 4 ~ 17 | ∞ | 8 ~ 35 | 70 ~ 400 | 13 ~ 60 | 4 ~ 17 |
| O | | ∞ | ∞ | ∞ | ∞ | ∞ | ∞ | ∞ | ∞ |
| Br | | 26 ~ 150 | ∞ | 2.4 ~ 11 | 9 ~ 40 | 7.5 ~ 35 | ∞ | 16 ~ 70 | 2.4 ~ 11 |
| L | | 26 ~ 150 | ∞ | 2.4 ~ 11 | 9 ~ 40 | 7.5 ~ 35 | 80 ~ 500 | ∞ | 2.4 ~ 11 |
| B | | 10 ~ 45 | ∞ | 0 ~ 0.6 | 4.4 ~ 19 | 2 ~ 8.5 | 70 ~ 400 | 6 ~ 28 | ∞ |


**EXHAUST SYSTEM
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|-------------------------------|------|--|
| | EXHAUST SYSTEM REMOVAL | | Follow the left "Step" for removal. Refer to "SEAT, STORAGE BOX, FIRE EXTINGUISHER BOX AND BATTERY CASE". |
| | Fire extinguisher box | | |
| 1 | Band | 2 | |
| 2 | Exhaust hose | 1 | |
| 3 | Exhaust hose | 1 | |
| 4 | Water outlet hose | 1 | |
| 5 | Bolt (with washer) | 6 | |
| 6 | Exhaust guide | 1 | |
| | | | Reverse the removal steps for installation. |

**FLUSHING AND VENTILATION SYSTEM
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

| Step | Procedure/Part name | Q'ty | Service points |
|------|--|------|---|
| | FLUSHING AND VENTILATION SYSTEM REMOVAL | | Follow the left "Step" for removal. |
| 1 | Nut | 1 | |
| 2 | Cap | 1 | |
| 3 | Flushing hose joint | 1 | |
| 4 | Water inlet hose | 2 | |
| 5 | Hose joint | 1 | |
| 6 | Ventilation hose (front) | 2 | |
| 7 | Ventilation hose (rear) | 2 | |
| 8 | Guide plate | 4 | |
| | | | Reverse the removal steps for installation. |