

YAMAHA

Marine

Water Vehicles

Wave Venture

WVT700

WVT1100

SERVICE MANUAL 

460031

PREFACE

This manual has been prepared by the Yamaha Motor Company primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because the Yamaha Motor Company Ltd. has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

HOW TO USE THIS MANUAL

MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g. ,

- Bearings
Pitting/Damage → Replace.

To assist you to find your way about this manual, the Section Title and Major Heading is given at the head of every page.

An Index to contents is provided on the first page of each Section.

MODEL INDICATION

Multiple models are shown in this manual. These indications are noted as follows.

Model name	WaveVenture	
	WV700	WV1100
indication	WV700	WV1100

THE ILLUSTRATIONS


Some illustrations in this manual may differ from the model you have. This is because a procedure described may relate to several models, though only one may be illustrated. (The name of model described will be mentioned in the description).

REFERENCES

These have been kept to a minimum, however, when you are referred to another section of the manual, you are told the page number to go to.

WARNINGS, CAUTIONS AND NOTES

Attention is drawn to the various Warnings, Cautions and Notes which distinguish important information in this manual in the following ways

 The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

WARNING

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the water vehicle.

CAUTION

A **CAUTION** indicates special precautions that must be taken to avoid damage to the water vehicle.

NOTE:


A **NOTE** provides key information to make procedures easier or clearer.
























IMPORTANT:

This part has been subjected to **change of specification** during production.

HOW TO READ DESCRIPTIONS

1. A disassembly installation job mainly consists of the exploded diagram ①.
2. The numerical figures represented by the number ② indicates the order of the job steps.
3. The symbols represented by the number ③ indicates the contents and notes of the job. For the meanings of the symbols, refer to the next page(s).
4. The REMOVAL AND INSTALLATION CHART ④ is attached to the exploded diagram and explains the job steps, part names, notes for the jobs, etc.
5. The SERVICE POINTS, other than the exploded diagram, explains in detail the items difficult to explain in the exploded diagram or REMOVAL AND INSTALLATION CHART, the Service points requiring the detailed description ⑤, etc.



① GEN INFO 	② SPEC 
③ INSP ADJ 	④ FUEL 
⑤ POWR 	⑥ JET PUMP 
⑦ ELEC 	⑧ HULL HOOD 
⑨ TRBL ANLS ?	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 

SYMBOLS

Symbols ① to ⑧ are designed as thumb-tabs to indicate the content of a chapter:

- ① General Information
- ② Specifications
- ③ Periodic Inspection and Adjustment
- ④ Fuel System
- ⑤ Power Unit
- ⑥ Jet pump Unit
- ⑦ Electrical System
- ⑧ Hull and Hood

Symbols ⑩ to ㉔ indicate specific data:

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical valve
(Resistance (Ω), Voltage (V), Electric current (A))

Symbol ⑯ to ㉑ in an exploded diagram indicate grade of lubricant and location of lubrication point:

- ⑯ Apply Yamaha 2-stroke outboard motor oil
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply molybdenum disulfide grease

Symbols ㉒ to ㉔ in an exploded diagram indicate grade of sealing or locking agent, and location of application point:

- ㉒ Apply Gasket maker[®]
- ㉓ Apply Yamabond #4 (Yamaha bond No.4)
- ㉔ Apply LOCTITE[®] No. 271 (Red LOCTITE)
- ㉕ Apply LOCTITE[®] No. 242 (Blue LOCTITE)
- ㉖ Apply LOCTITE[®] No. 572
- ㉗ Apply Silicon sealant

NOTE: _____
 In this manual, the above symbols may not be used in every case.

INDEX

GENERAL INFORMATION

SPECIFICATIONS

**PERIODIC INSPECTION AND
ADJUSTMENT**

FUEL SYSTEM

POWER UNIT

JET PUMP UNIT


ELECTRICAL SYSTEM

HULL AND HOOD

TROUBLE-ANALYSIS

CHAPTER 1 GENERAL INFORMATION

IDENTIFICATION NUMBERS	1-1
PRIMARY I.D. NUMBER	1-1
ENGINE SERIAL NUMBER	1-1
PUMP SERIAL NUMBER	1-1
HULL IDENTIFICATION NUMBER (H.I.N.)	1-1
SAFETY WHILE WORKING	1-2
FIRE PREVENTION	1-2
VENTILATION	1-2
SELF-PROTECTION	1-2
OILS, GREASES AND SEALING FLUIDS	1-2
GOOD WORKING PRACTICES	1-3
DISASSEMBLY AND ASSEMBLY	1-4
SPECIAL TOOLS	1-5
MEASURING	1-5
REMOVAL AND INSTALLATION	1-6




463100 c

**IDENTIFICATION NUMBERS
PRIMARY I.D. NUMBER**

The primary I.D. number is stamped on a label attached to the inside of the engine compartment.


Starting primary I.D. number:
 GJ3: 800101 ~, 800101 ~ (FRA)
 GL3: 900101 ~
 GH3: 800101 ~, 600101 (FRA)
 GR1: 900101 ~



ENGINE SERIAL NUMBER

The engine serial number is stamped on a label attached to the crankcase.


Starting serial number:
 63N: 000101 ~
 64T: 000101 ~



PUMP SERIAL NUMBER


The jet pump unit serial number is stamped on a label attached on the intermediate housing.

Starting serial number:
 63N: 500101 ~
 64T: 500101 ~



**HULL IDENTIFICATION NUMBER
(H.I.N.)**

The H.I.N. is stamped on a plate attached to the rear end of the footrest floor.





SAFETY WHILE WORKING

The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.



FIRE PREVENTION

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline (petrol), and keep it away from heat, sparks, and open flames.

VENTILATION

Petroleum vapor is heavier than air and if inhaled in large quantities will not support life. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.



SELF-PROTECTION

Protect your eyes with suitable safety spectacles or safety goggles when using compressed air, when grinding or when doing any operation which may cause particles to fly off.

Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.



OILS, GREASES AND SEALING FLUIDS

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.



Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized. A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping rag in one's pocket.
4. Hands, and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.



GOOD WORKING PRACTICES

1. The right tools
Use the special tools that are designed to protect parts from damage. Use the right tool in the right manner — don't improvise.
2. Tightening torque
Follow the torque tightening instructions. When tightening bolts, nuts and screws, tighten the larger sizes first, and tighter inner-positioned fixings before outer-positioned ones.



3. Non-reusable items

Always use new gaskets, packings, O-rings, oil seals, split-pins and circlips etc. on reassembly.

DISASSEMBLY AND ASSEMBLY

1. Clean parts with compressed-air on disassembling them.
2. Oil the contact surfaces of moving parts on assembly.

3. After assembly, check that moving parts operate normally.

4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.

CAUTION:

Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.

5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.



SPECIAL TOOLS


Use of the correct special tools recommended by Yamaha will aid the work and enable accurate assembly and tune-up. Improvisations and use of improper tools can cause damage to the equipment.


NOTE:

- For U.S.A. and Canada, use part numbers starting with "YB-", "YU-" or "YW-".
- For other countries, use part numbers starting with "90890-".

MEASURING

1. Dial gauge and stand
P/N. YU-03097, YU-01256
90890-01252
2. Digital multi meter
P/N. YU-34899-A
90890-06752
3. Pocket tester
P/N. YU-03112
90890-03112
4. Compression gauge
P/N. YU-33223
90890-06751
5. Cylinder gauge set
P/N. YU-03017
90890-06759
6. Engine tachometer
P/N. YU-08036-A
90890-06760
7. Spark gap tester
P/N. YM-34487
90890-06754





REMOVAL AND INSTALLATION

1. Coupler wrench
P/N. YW-38741
90890-06425
2. Flywheel holder
P/N. YB-06139
90890-06522
3. Flywheel puller
P/N. YB-06117
90890-06621
4. Shaft holder (intermediate shaft)
P/N. YW-38742
90890-06069
5. Driver rod
(Intermediate shaft and jet pump)
P/N. YB-06071, YB-06229
90890-06605
90890-06606
6. Bearing outer race attachment
(Intermediate shaft)
P/N. YB-06016
90890-06628
7. Bearing attachment:
(Jet pump bushing and oil seal)
P/N. YB-06021
90890-06638
8. Needle bearing attachment
(Jet pump oil seal)
P/N. YB-06349
90890-06613
9. Drive shaft holder (Impeller)
P/N. YB-06049
90890-06518
10. Slide hammer set (Jet pump bearing)
P/N. YB-06095
90890-06523
90890-06531
11. Ball bearing attachment
(Jet pump oil seal)
P/N. YB-06155
90890-06634
12. Bearing inner race attachment
(Jet pump bearing)
P/N. YB-34474
90890-06652

CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-2
ENGINE	2-2
ELECTRICAL	2-4
TIGHTENING TORQUE	2-5
SPECIFIED TORQUE	2-5
GENERAL TORQUE	2-6



GENERAL SPECIFICATIONS

Item	Unit	Model	
		WVT700	WVT1100
MODEL CODE:			
Hull		GJ3	GH3
Engine		63N	64T
DIMENSIONS:			
Length	mm (in)	3,150 (124.0)	
Width	mm (in)	1,250 (49.2)	
Height	mm (in)	1,050 (41.3)	
Dry weight	kg (lb)	245 (540)	271 (597)
PERFORMANCE:			
Maximum speed	km/h (mph)	73.0 (45.4)	83.0 (51.6)
Minimum turning radius	m (ft)	0	
Maximum output	kW (hp)@ r/min	58.8 (80)@6,250	80.9 (110)@6,500
Maximum fuel consumption	L (US gal, Imp gal/h)	34 (9.0, 7.5)	46 (12.2, 10.1)
Cruising range	hr.	1.5	1.1
ENGINE:			
Type		2 stroke - L	
Number of cylinder		2	3
Displacement	cm ³ (cu. in)	701 (42.78)	1,051 (64.14)
Bore x Stroke	mm (in)	81.0 x 68.0 (3.19 x 2.68)	
Compression ratio		7.2	5.8
Carburetor type		Floatless	
Number of carburetor		2	3
Starting enrichment			
Intake system		Choke valve	
Induction system		Reed valve	
Lubrication system		Loop charge	
Starting system		Oil injection	
Spark plug (NGK)		Electric	
Battery capacity	V/kc. (Ah)	BR8HS	
		12/68.4 (19)	
JET PUMP:			
Jet pump type		Axial flow, single stage	
Impeller rotating direction		Counterclockwise	
Nozzle angle	Degree	28	
FUEL AND OIL:			
Fuel		Regular gasoline	
Fuel tank capacity	L (US qt, Imp qt)	50 (13.2, 11.0)	
reserve	L (US qt, Imp qt)	8.8 (2.3, 1.9)	12 (3.2, 2.6)
Oil tank capacity	L (US qt, Imp qt)	3.8 (1.0, 0.8)	


MAINTENANCE SPECIFICATIONS
ENGINE

Item	Unit	Model	
		WVT700	WVT1100
CYLINDER HEAD: Warpage limit	mm (in)	0.1 (0.004)	
CYLINDER: Bore size	mm (in)	81.00 - 81.02 (3.189 - 3.190)	
Wear limit	mm (in)	81.10 (3.193)	
Taper limit	mm (in)	0.08 (0.003)	
Out of round limit	mm (in)	0.05 (0.002)	
PISTON: Piston clearance	mm (in)	0.080 - 0.085 (0.0031 - 0.0033)	0.110 - 0.115 (0.0043 - 0.0045)
Limit	mm (in)	0.13 (0.005)	
Diameter	mm (in)	80.925 - 80.950 (3.186 - 3.187)	80.885 - 80.890 (3.184 - 3.185)
Offset	mm (in)	0.5 (0.02)	
Measuring point H	mm (in)	10 (0.4)	
PISTON PIN: Diameter	mm (in)	19.995 - 20.000 (0.7872 - 0.7874)	
PISTON RING: Type		Keystone	
Dimensions (B × T)	mm (in)	1.2 × 2.9 (0.047 × 0.114)	
End gap (installed)	mm (in)	0.2 - 0.4 (0.008 - 0.016)	
Ring side clearance	mm (in)	0.02 - 0.06 (0.001 - 0.002)	
CRANK SHAFT: Crank width "A"	mm (in)	61.95 - 62.00 (2.439 - 2.441)	
Runout limit "B"	mm (in)	0.05 (0.002)	
Big end side clearance "C"	mm (in)	0.25 - 0.75 (0.010 - 0.030)	
Small end free play limit "D"	mm (in)	2.0 (0.08)	
REED VALVE: Valve stopper height	mm (in)	9.0 ± 0.2 (0.35 ± 0.01)	
Valve warpage limit	mm (in)	0.2 (0.01)	

SPEC

MAINTENANCE SPECIFICATIONS
F

Item	Unit	Model	
		WVT700	WVT1100
CARBURETOR:			
Identification mark	No.1	62T01F	64T00F
	No.2	62T01R	64T00C
	No.3	—	64T00R
Main jet 2 (M.J.2)	No.1	#	120
	No.2	#	130
	No.3	#	—
Pilot jet (P.J.)	#	67.5	75
Low speed screw	Turns out	5/8 ± 1/4	1-1/8 ± 1/4
High speed screw	No.1	Turns out	5/8 ± 1/4
	No.2	Turns out	1-1/8 ± 1/4
	No.3	Turns out	—
Trolling speed	r/min	1250 ± 50	
JET PUMP:			
Impeller clearance	mm (in)	0.3 - 0.4 (0.01 - 0.02)	
Service limit	mm (in)	0.5 (0.024)	
Impeller shaft runout	mm (in)	0.3 (0.012)	



ELECTRICAL

Item	Unit	Model	
		WVT700	WVT1100
IGNITION SYSTEM:			
Ignition timing	Degree	15	
1,200 r/min (BTDC)	Degree	15	
5,500 r/min (BTDC)	Degree	21	19
Charge coil resistance	Ω	497.7 - 608.3	—
(B/W-B)			
(Br/R-Br)	Ω	—	172 - 258
(Br/R-L)	Ω	—	656 - 984
Pulser coil resistance	Ω	12.6 - 15.4	748 - 372
(W/R-B)			
(W/B-B)	Ω	—	248 - 372
(W/G-B)	Ω	—	248 - 372
Ignition coil resistance	Ω		
Primary coil (O-B)	Ω	0.078 - 0.108	—
(B/W-B)	Ω	—	0.18 - 0.24
Secondary coil	k Ω	14.3 - 30.5	2.7 - 4.1
Spark plug gap	mm (in)	0.6 - 0.7 (0.024 - 0.027)	
IGNITION CONTROL SYSTEM:			
Thermo switch	$^{\circ}\text{C}$ ($^{\circ}\text{F}$)	66 - 74 (150.8 - 165.2)	90 - 96 (194 - 204.8)
(OFF \rightarrow ON)			
(ON \rightarrow OFF)	$^{\circ}\text{C}$ ($^{\circ}\text{F}$)	57 - 43 (134.6 - 109.4)	90 - 76 (194 - 168.8)
STARTING SYSTEM:			
Fuse 1	A	10	
STARTING MOTOR:			
Output	kW	0.8	
Rating	Sec.	30	
Brush length	mm (in)	0.49	
Wear limit	mm (in)	6.5 (0.26)	
Commutator diameter	mm (in)	28.0 (1.10)	
Limit	mm (in)	27.0 (1.06)	
Commutator under cut	mm (in)	0.7 (0.03)	
Limit	mm (in)	0.15 (0.006)	
CHARGING SYSTEM:			
Lighting coil			
Resistance (G-G)	Ω	1.14 - 1.40	0.56 - 0.84
Charging current	A @ r/min	3 \pm 1 @ 5,500	7 \pm 1 @ 6,500


**TIGHTENING TORQUE
SPECIFIED TORQUE**


Part to be tightened	Part name	Size	Q'ty		Tightening torque			Remarks	
			700	1100	Nm	m·kg	ft·lb		
ENGINE:									
Electric box	Bolt	M8	3	—	16	1.6	11		
Mounting bolt	Bolt	M8	4	—	17	1.7	12		
Reed valve	Screw	M4	16	24	1	0.1	0.7		
Exhaust ring	Bolt	M8	4	—	30	3.0	22		
Exhaust chamber	Bolt	M10	2	—	40	4.0	29		
Muffler stay	Bolt	M10	4	—	40	4.0	29		
Exhaust chamber - Muffler stay	1st	Bolt	M10	2	2	0.2	1.4		
	2nd				47	4.7	34		
Exhaust outer cover	1st	Bolt	M8	—	6	15	1.5	11	
	2nd					30	3.0	22	
Muffler 1	1st	Bolt	M10	8	—	22	2.2	16	
	2nd					40	4.0	29	
	1st	Bolt	M10	—	12	15	1.5	11	
	2nd					30	3.0	22	
Cylinder body	1st	Bolt	M10	6	8	23	2.3	17	
	2nd					40	4.0	29	
Cylinder head cover	1st	Bolt	M8	—	13	15	1.5	11	
	2nd					30	3.0	22	
	1st	Bolt	M6	—	2	4	0.4	2.9	
	2nd					8	0.8	5.8	
Cylinder head	1st	Bolt	M8	10	14	15	1.5	11	
	2nd					36	3.6	25	
Spark plug	Bolt	M14	2	3	20	2.0	14		
Flywheel bolt	Bolt	M10	1	—	70	7.0	50		
Coupling	Nut	M27	1	—	37	3.7	27		
Crankcase	1st	Bolt	M8	8	12	15	1.5	11	
	2nd					28	2.8	20	
Mount bracket	1st	Bolt	M10	7	9	23	2.3	17	
	2nd					53	5.3	38	
Flame arrester cover	Bolt	M6	6	8	2	0.2	1.4		
Starter motor terminal nut	Nut	M6	1	—	5	0.5	3.6		
JET UNIT:									
Mounting bolt	Bolt	M10	4	—	34	3.4	24		
		M6	2	—	7	0.7	5.1		
Ride plate	Bolt	M8	4	6	17	1.7	12		
Speed sensor	Screw	M5	4	—	4	0.4	2.9		
Impeller (left-hand threads)	Bolt	M20	1	—	18	1.8	13		
Coupling	Nut	M27	1	—	37	3.7	27		
Intermediate housing	Bolt	M8	3	—	17	1.7	12		



Nut Ⓐ	Bolt Ⓑ	General torque specifications		
		Nm	m·kg	ft·lb
8 mm	M6	5.0	0.5	3.6
10 mm	M6	8.0	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

GENERAL TORQUE

This chart specifies the torques for tightening standard fasteners with standard clean dry ISO threads at room temperature. Torque specifications for special components or assemblies are given in applicable sections of this manual. To avoid causing warpage, tighten multifastener assemblies in a criss-cross fashion, in progressive stages until the specified torque is reached.



CHAPTER 3

PERIODIC INSPECTION AND ADJUSTMENT

MAINTENANCE INTERVAL CHART	3-2
PERIODIC SERVICE.....	3-3
CONTROL SYSTEM	3-3
Pivot shaft bearing inspection.....	3-3
Steering cable inspection and adjustment.....	3-3
Throttle cable inspection and adjustment.....	3-4
Choke cable inspection and adjustment	3-5
Shift cable inspection and adjustment	3-5
FUEL SYSTEM	3-7
Fuel filter inspection.....	3-7
Trolling speed inspection and adjustment.....	3-7
Carburetor adjustment	3-8
OIL INJECTION SYSTEM	3-9
Oil filter inspection	3-9
Oil injection pump air bleeding.....	3-9
POWER UNIT.....	3-10
Spark plug inspection	3-10
ELECTRICAL	3-11
Battery inspection.....	3-11
JET PUMP UNIT	3-13
Impeller inspection.....	3-13
Bilge strainer inspection	3-13
GENERAL	3-14
Drain plug inspection	3-14
Greasing point	3-14

MAINTENANCE INTERVAL CHART


The following chart should be considered strictly as a guide to general maintenance intervals.

Depending on operating conditions, the intervals of maintenance should be changed.

Item	Remarks	Initial		Every		Refer to page
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
CONTROL SYSTEM:						
Steering cable	Inspection/Adjustment			○		3-3
Throttle cable	Inspection/Adjustment			○		3-4
Carburetor throttle shaft	Inspection			○		—
Choke cable	Inspection/Adjustment			○		3-5
Shift cable	Inspection/Adjustment			○		3-5
Shift system	Inspection/Adjustment			○		3-5
FUEL SYSTEM:						
Fuel tank	Cleaning				○	4-7
Fuel filter	Cleaning/Replacement	○			○	3-7
Fuel line	Inspection			○		4-1
Trolling speed	Inspection/Adjustment			○		3-7
Carburetor setting	Inspection/Adjustment	○		○		3-8
OIL INJECTION SYSTEM:						
Oil injection system	Inspection/Cleaning	○			○	3-9
POWER UNIT:						
Spark plug	Inspection/Cleaning/Adjustment	○	○	○		3-10
Cooling-water passage	Cleaning/Flashing		○			—
Coupling rubber	Inspection				○	—
ELECTRICAL:						
Battery	Inspection	○				3-11
JET PUMP UNIT:						
Impeller	Inspection		○	○		3-13
Bilge strainer	Cleaning		○	○		3-13
GENERAL:						
Bolt and nut	Retightening	○		○		—
Drain plug	Inspection/Replacement				○	3-14
Greasing point	Greasing			○		3-14
Bearing housing	Greasing	○ *1		○ *2		3-14






*1: Grease capacity 33.0 ~ 35.0 cm³ (1.11 ~ 1.18 oz.)

*2: Grease capacity 6.0 ~ 8.0 cm³ (0.20 ~ 0.27 oz.)



CAUTION

Kink the pilot hose ① when running the engine at full throttle for more than 15 seconds as the water vehicle is moored or is in a test tank.



**PERIODIC SERVICE
CONTROL SYSTEM**

Pivot shaft bearing inspection

1. Inspect:
- Pivot shaft bearing
- Excessive play → Replace bearings.
Refer to the "STEERING SYSTEM" section in chapter 8.

- Inspection steps:**
- Move the handlebar up and down.
 - Move the handlebar back and forth.
- NOTE:** _____

Check that the pivot shaft support bolt ① is secured first.

- If the pivot shaft becomes loose, retighten the clamp ② until a satisfactory feel is obtained.

Steering cable inspection and adjustment

1. Inspect:
- Jet nozzle clearance ③, ④

- Inspection steps:**
- Turn the handlebar lock to lock.
 - Measure the clearances ③ and ④.
 - If the ③ and ④ clearances are not even, adjust the clearances.

2. Adjust:
- Cable joint (handle side) ①

- Adjustment steps:**
- Loosen the lock nut ②.
 - Disconnect the cable joint from the ball joint ③.
 - Turn the cable joint to adjust.


Turn in	Clearance ③ is increased.
Turn out	Clearance ④ is increased.

⚠ WARNING _____

The cable joint must be screwed in more than 8 mm (0.31 in).

- Connect the cable joint and tighten the lock nut.

	Lock nut: 4 Nm (0.4 m - kg, 2.9 ft - lb)
--	----------------------------------------------------




NOTE:
If correct adjustment cannot be obtained using the cable joint at the handlebar end adjust the cable joint at the steering nozzle end

Throttle cable inspection and adjustment

NOTE:
Before adjusting the throttle lever free play, the trolling speed should be adjusted.

1. Measure:
 - Throttle lever free play ③
 - Out of specification → Adjust.



Throttle lever free play:
7 ~ 10 mm (0.28 ~ 0.39 in)

2. Adjust:
 - Throttle lever free play


Adjustment steps:

- Loosen the lock nut ①.
- Turn the adjuster ② in/out until the specified free play is obtained.

Turn in	Free play is increased.
Turn out	Free play is decreased.

- Tighten the lock nut.

⚠ WARNING
After adjusting the free play, turn the handlebar to right and left, and make sure that the trolling speed does not increase.




Choke cable inspection and adjustment

1. Measure:
 - Choke cable free play ②
 - Out of specification → Adjust.



Choke cable free play:
1 - 6 mm (0.04 - 0.24 in)



2. Adjust:
 - Choke cable free play

Adjustment steps:


- Loosen the lock nut ①.
- Turn the adjuster ② in/out until the specified free play is obtained.

Turn in	Free play is increased.
Turn out	Free play is decreased.

- Tighten the lock nut.




Lock nut:
8 Nm (0.8 m - kg, 6.0 ft - lb)



3. Inspect:
 - Pull knob farthest toward
 - Knob automatically returns → Adjust.
4. Adjust:
 - Adjust nut ③
 - Turn in to stop automatic return.



Shift cable inspection and adjustment

1. Check:
 - Reverse gate collar head ② position
 - Out of specification → Adjust.



Checking steps:

- Set the shift lever to the reverse position.
- Turn the steering fully to the right or left.
- Check to make sure that the collar head position should be inside of two marking lines ② of the shift rod lever.



2. Adjust:

- Shift cable joint

Adjustment steps:

- Loosen the lock nut ①.
- Disconnect the cable joint ② from the ball joint ③.
- Turn the cable joint for adjusting.

Turn in	Clearance is increased.
Turn out	Clearance is decreased.

⚠ WARNING

The cable joint must be screwed in more than 8 mm (0.31 in).

- Connect the cable joint and tighten the lock nut.



Lock nut:
4 Nm (0.4 m · kg, 2.9 ft · lb)



FUEL SYSTEM

▲ WARNING

- ◆ Stop the engine, set the fuel cock to "OFF" and loosen the fuel filler cap before a fuel system service.
- ◆ When removing fuel system parts, hold them in a cloth and take care that no fuel spills into the engine compartment.

Fuel filter inspection

1. Inspect:
 - Filter element
Contamination → Replace.
 - Filter body
Cracks/Damage → Replace.
 - Filter assembly
Water contamination → Replace and check the fuel tank

Trolling speed inspection and adjustment

1. Check.
 - Trolling speed
Out of specification → Adjust.


	Trolling speed: 1,250 ± 50 r/min
--	--------------------------------------------




Checking steps: (vehicle on water)	
<ul style="list-style-type: none"> ● Start the engine and allow it to warm up for a few minutes. ● Attach the engine tachometer to the spark plug lead. 	

	Engine tachometer: YU-8036-A/90890-06760
<ul style="list-style-type: none"> ● Measure the engine trolling speed. 	

2. Adjust:
 - Trolling speed

Adjustment steps:	
<ul style="list-style-type: none"> ● Screw in the low speed screws ① until they are lightly seated. 	





- Back the screws out by the specified number of turns.



Low speed screw:

WVT700

5/8 ± 1/4 (turns out)

WVT1100

1-1/8 ± 1/4 (turns out)

- Start the engine and allow it to warm up for a few minutes.
- Turn the throttle stop screw(s) ② in or out until the specified speed is obtained.

Turning in

Increase trolling speed.

Turning out

Decrease trolling speed.

Carburetor adjustment

1. Adjust:

- High speed screw

Adjustment steps:

- Screw in the high speed screws ① until they are lightly seated.
- Back the screws out by the specified number of turns.



High speed screw:

WVT700

5/8 (#1), 1-1/8 (#2) ± 1/4 (turns out)

WVT1100

7/8 ± 1/4 (turns out)



OIL INJECTION SYSTEM

Oil filter inspection

1. Inspect:
 - Oil filter
 - Fray/Tear → Replace.
 - Muddy/Dirt → Clean.
 - Seal rubber
 - Wear/Crack → Replace.

Oil injection pump air bleeding

NOTE:

Bleed the oil injection system if:

- The system has been disassembled.
- The oil has been completely used up during operation.



1. Bleed:
 - Air


Air bleeding steps:

- a. Make sure the oil hose is connected.
- b. Refill the oil tank with oil.
- c. Hold a rag under the oil pump to catch any oil that spills out.
- d. To bleed, loosen the air bleeding screw ① on the oil injection pump. Oil will flow into the pump.
- e. Keep letting oil run out into the rag until there are no bubbles in the oil. If oil does not run out, squeeze the oil hose near the pump inlet several times.
- f. Tighten the screw firmly and wipe up any spilled oil.



Screw:
5 Nm (0.5 m · kg, 3.6 ft · lb)





POWER UNIT


Spark plug inspection:

1. Inspect:

- Electrode ①
Wear/Damage: → Replace.
- Insulator color ②
Discolor → Check the engine condition.



Color guide:
Medium to light tan color:
 Normal
Whitish color:
 Lean fuel mixture
 Plugged fuel mixture
 Air leak
 Incorrect settings
Blackish color:
 Overly rich mixture
 Electrical malfunction
 Excess oil used
 Defective spark plug



2. Clean:

- Spark plug
Clean the spark plug with a spark plug cleaner or wire brush.

3. Measure:

- Spark plug gap ③
Out of specification → Alter gap.
Use a wire gauge.




Spark plug gap:
 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

4. Tighten:

- Spark plug



Spark plug:
 25 Nm (2.5 m · kg, 18 ft · lb)



NOTE:

- Before installing a spark plug, clean the gasket surface and plug surface. Also it is advisable to apply a thin film of Anti Seize Compound to the spark plug threads to prevent future thread seizure.
- If a torque wrench is not available, a good estimate of the correct torque for the spark plug is a further 1/4 to 1/2 turns ④ on from finger tightness ③



ELECTRICAL
Battery inspection

CAUTION

Be careful not to place the battery on its side. Before adding the battery fluid or recharging, be sure to remove it from the engine compartment. When checking the battery, make sure the breather hose is connected to the battery and is not pinched shut anywhere in the engine compartment.

WARNING


- Battery electrolyte is poisonous and dangerous, causing severe burns, etc. Contains sulfuric acid.
- Avoid contact with skin, eyes or clothing.
- Antidote: EXTERNAL-Flush with water.
- INTERNAL-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call a physician immediately.
- Eyes: Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases.
- Keep sparks, flame, cigarettes, etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.
- KEEP OUT OF REACH OF CHILDREN.

1. Remove:
 - Battery

WARNING

- When removing the battery, disconnect the negative lead first.
- Remove the battery to prevent acid loss during the impeller service.

2. Inspect
 - Battery fluid level
Battery fluid level low -> Top up with distilled water.
Fluid level should be between upper ① and lower ② level marks.





Filling steps:

- Remove each filler cap using pliers.
- Fill with distilled water using a jug.
- When the acid is up to the **UPPER LEVEL**, allow the cell to stand for 20 minutes. If the acid level has dropped, add more acid up to the **UPPER LEVEL** once again.

CAUTION:

Water other than distilled water contains minerals which are harmful to a battery; top up only with distilled water.

3. Inspect:

- Battery fluid specific gravity
Out of specification → Charge.




Specific gravity at 20°C (68°F):
1.28
Charging current:
68.4 kc. (1.9 Amps × 10 hrs)

4. Install:

- Filler cap

CAUTION:

Rinse off any acid from the battery case and wipe the battery dry prior to installation.








5. Install:

- Breather hose ①
- Battery
- Positive lead ②
- Negative lead ③
- Battery band

CAUTION:

- Connect the positive red lead ⊕ to the battery terminal first.
- Make sure the battery leads are connected properly. Reversing the leads can seriously damage the electrical system.
- Make sure the breather hose is properly connected and is not obstructed.
- Coat the terminals with a water resistant grease to minimize terminal corrosion.



JET PUMP UNIT

Impeller inspection

1. Remove:
 - Battery
Refer to "BATTERY" section.
2. Remove:
 - Bolt ①
 - Intake screen ②
3. Check:
 - Impeller ①
Wear/Damage → Replace.
Scratch/Nick → File/Grind.
4. Measure:
 - Impeller clearance ②
Out of specification → Replace.

Measure at all four points.
Impeller clearance limit:
0.6 mm (0.024 in)

5. Install:
 - Intake screen ①
 - Bolt ②

Bolt:
11 Nm (1.1 m • kg, 8.0 ft • lb)

6. Install:
 - Battery
Refer to the "BATTERY" section.


Bilge strainer inspection

1. Remove:
 - Bilge strainer ①
(located under the coupling)

Removal steps:

- Remove the coupling cover.
- Disconnect the bilge strainer from the strainer holder

2. Inspect:
 - Strainer ①
Contamination → Clean.
Crack/Damage → Replace.



GENERAL

Drain plug inspection

1. Inspect:
 - Drain plug
Crack/Damage → Replace.
 - O-ring
Crack/Wear → Replace.
 - Screw threads
Dirt/Sandy → Clean.

Greasing point

1. Apply:
 - Throttle cable inner wire

NOTE:

Squeeze the throttle lever and remove the seal. Spray a rust-inhibitor into the outer cable.

	Recommended fluid: Rust-inhibitor
--	----------------------------------------------

- Throttle cable inner wire
- Choke cable inner wire
- Cable joint
- Steering cable

NOTE:


Remove the cable joint and apply a small amount of grease to the following parts.

- Steering pivot shaft bearing
- Choke knob shaft
- Bearing housing

	Recommended grease: Water resistant grease
--	-------------------------------------------------------

NOTE:

- Fill in the bearing housing with water resistant grease from a nipple.
- Fill the grease slowly and carefully, as it can damage the hose and the joints
- Refer to the "MAINTENANCE INTERVAL CHART".



CHAPTER 4 FUEL SYSTEM

AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER	4-1
EXPLODED DIAGRAM (WVT700).....	4-1
REMOVAL AND INSTALLATION CHART.....	4-2
SERVICE POINTS	4-2
Fuel filter inspection.....	4-2
Fuel cock inspection.....	4-2
EXPLODED DIAGRAM (WVT1100).....	4-3
REMOVAL AND INSTALLATION CHART.....	4-4
SERVICE POINTS	4-4
Fuel filter inspection.....	4-4
Fuel cock inspection.....	4-4
OIL TANK AND FUEL TANK REMOVAL.....	4-5
EXPLODED DIAGRAM	4-5
REMOVAL AND INSTALLATION CHART.....	4-6
OIL TANK AND FUEL TANK.....	4-7
EXPLODED DIAGRAM	4-7
REMOVAL AND INSTALLATION CHART.....	4-8
SERVICE POINTS	4-8
Check valve inspection.....	4-8
Oil level sensor and fuel level sensor inspection.....	4-9
Oil tank and fuel tank inspection.....	4-9
Pipe joint inspection.....	4-9
Pipe joint installation.....	4-9
CARBURETOR REMOVAL.....	4-10
EXPLODED DIAGRAM	4-10
REMOVAL AND INSTALLATION CHART.....	4-11
EXPLODED DIAGRAM (WVT1100).....	4-12
REMOVAL AND INSTALLATION CHART.....	4-13




CARBURETOR	4-14
EXPLODED DIAGRAM	4-14
REMOVAL AND INSTALLATION CHART.....	4-15
EXPLODED DIAGRAM (WVT1100).....	4-16
REMOVAL AND INSTALLATION CHART.....	4-17
SERVICE POINTS	4-18
Diaphragm inspection.....	4-18
Float arm inspection.....	4-18
Body assembly inspection.....	4-18
Fuel pump inspection (WVT700).....	4-18
Filter inspection	4-18
Needle valve inspection.....	4-19
Jet and carburetor body inspection.....	4-19
High and low speed screws inspection.....	4-19
High and low speed screws adjustment.....	4-19
Throttle valve synchronization inspection and adjustment.....	4-20
Choke valve synchronization inspection and adjustment.....	4-21
Carburetor assembly.....	4-21
FUEL PUMP (WVT1100)	4-22
EXPLODED DIAGRAM	4-22
REMOVAL AND INSTALLATION CHART.....	4-23
SERVICE POINTS	4-23
Fuel pump inspection	4-23
OIL PUMP	4-24
EXPLODED DIAGRAM	4-24
REMOVAL AND INSTALLATION CHART.....	4-25
SERVICE POINTS	4-25
Oil pump inspection	4-25
Oil hose inspection.....	4-25



AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER

E

AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER EXPLODED DIAGRAM (WVT700)





AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER REMOVAL		Follow the left "Step" for removal.
1	Hose tie	2	
2	Clamp	3	
3	Air ventilation hose	1	
4	Fuel hose (OUT)	1	
5	Fuel filter	1	
6	Fuel hose	1	
7	Choke cable	1	
8	Fuel hose (return)	1	
9	Fuel hose (ON)	1	
10	Fuel hose (RES)	1	
11	Screw	2	
12	Cock lever	1	
13	Nut	1	
14	Plane washer	1	
15	Fuel cock body	1	
			Reverse the removal steps for installation.

SERVICE POINTS

Fuel filter inspection

Refer to the "FUEL SYSTEM" section in chapter 3.


Fuel cock inspection

1. Check:

- Fuel cock

Unsmooth movement → Replace.

Clog → Clean.

**EXPLODED DIAGRAM (WVT1100)**



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	AIR VENTILATION HOSE, FUEL COCK AND FUEL FILTER REMOVAL		Follow the left "Step" for removal.
1	Hose tie	2	
2	Clamp	3	
3	Air ventilation hose	1	
4	Fuel hose (OUT)	1	
5	Fuel filter	1	
6	Fuel hose	1	
7	Choke cable	1	
8	Fuel hose (return)	1	
9	Fuel hose (ON)	1	
10	Fuel hose (RES)	1	
11	Screw	1	
12	Cock lever	1	
13	Nut	1	
14	Plane washer	1	
15	Fuel cock body	1	
			Reverse the removal steps for installation.

SERVICE POINTS

Fuel filter inspection

Refer to the "FUEL SYSTEM" section in chapter 3.


Fuel cock inspection

1. Check:

- Fuel cock
Unsmooth movement → Replace.
Clog → Clean.



**OIL TANK AND FUEL TANK REMOVAL
EXPLODED DIAGRAM**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	OIL TANK AND FUEL TANK REMOVAL		Follow the left "Step" for removal.
			⚠ WARNING Gasoline (Petrol) is highly flammable and explosive. Handle with special care.
1	Oil sensor lead coupler	1	
2	Hose tie	2	
3	Air ventilation hose	1	
4	Clamp	1	
5	Oil filler hose	1	
6	Tank band	2	
7	Oil hose	1	
8	Oil tank assembly	1	
9	Fuel level sensor lead coupler	1	
10	Clamp	2	
11	Fuel filler hose	1	
12	Hose tie	3	
13	Fuel hose (ON)	1	
14	Fuel hose (RES)	1	
15	Fuel hose (return)	1	
16	Hose tie	3	
17	Air ventilation hose	2	
18	Check valve	1	
19	Fuel tank assembly	1	
20	Fuel tank damper	4	
21	Bolt (with washer)	4	
22	Tank band	2	
			Reverse the removal steps for installation.




**OIL TANK AND FUEL TANK
EXPLODED DIAGRAM**





REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name		Service points
OIL TANK DISASSEMBLY			Follow the left "Step" for removal.
1	Clamp	1	
2	Oil filler hose	1	
3	Oil level sensor	1	
4	Oil filter	1	
5	Packing	1	
6	Oil tank	1	
FUEL TANK DISASSEMBLY			
7	Clamp	2	
8	Pipe joint assembly	1	
9	Fuel level sensor	1	
10	Fuel tank	1	
PIPE JOINT DISASSEMBLY			
①	Circlip	1	
②	Plate washer	1	
③	Pin	1	
④	Clip	1	
⑤	Hose	1	
⑥	Clip	2	
⑦	Clamp	2	
⑧	Pipe	2	
⑨	Pipe joint	1	
			Reverse the removal steps for installation.



SERVICE POINTS

Check valve inspection

1. Check:
 - Check valve
 - Out of specification → Replace.



Oil level sensor and fuel level sensor inspection



Refer to the "INDICATION SYSTEM" section in chapter 7.

Oil tank and fuel tank inspection

1. Inspect.
 - Oil tank
 - Fuel tank
 Crack/Damage → Replace.


Pipe joint inspection

1. Inspect.
 - Pipe
 - Bending/Damage → Replace.
 - Contamination → Clean.
 - Pipe joint
 - Wear/Crack → Replace.




Pipe joint installation

1. Install:
 - Pipe joint ①
 - Pipe ②
 - Hose ③
 - Clamp

	Length ③: 320 ± 2 mm (12.6 ± 0.08 in)
	Length ⑥: 245 ± 2 mm (9.7 ± 0.08 in)


NOTE: _____
Connect the hose for "RES" on the pipe side.

**CARBURETOR REMOVAL
EXPLODED DIAGRAM**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	CARBURETOR REMOVAL		Follow the left "Step" for removal
	Fuel cock		NOTE: _____ Turn the fuel cock to "OFF".
	High tension cord		
1	Bolt	6	
2	Cover 1	1	
3	Flame arrester	2	
4	Hose tie	2	
5	Oil delivery hose	2	
6	Bolt (with washer)	2	
7	Cord clamp	1	
8	Plate washer	1	
9	Bolt (with washer)	6	
10	Cover 2	1	
11	Cover gasket	1	
12	Plate	1	
13	Cover gasket	1	
14	Choke cable	1	
15	Throttle cable	1	
			 Cable guide set position ③: 17 mm (0.67 in) Between cable guide top and plate top.
16	Hose tie	3	
17	Fuel hose (fuel filter - fuel pump)	1	
18	Pulse hose (fuel pump - crank case)	1	
19	Fuel hose (carburetor - fuel tank)	1	
20	Nut	4	
21	Plate washer	4	
22	Carburetor assembly	1	
23	Gasket	1	
			Reverse the removal steps for installation.



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	CARBURETOR REMOVAL		Follow the left "Step" for removal.
	Fuel cock		NOTE: Turn the fuel cock to "OFF".
	High tension cord		
1	Bolt (with washer)	8	
2	Cover 1	1	
3	Flame arrester	3	
4	Hose tie	3	
5	Oil delivery hose	3	
6	Bolt (with washer)	1	
7	Bolt (with washer)	1	
8	Collar	1	
9	Bolt (with washer)	9	
10	Cover 2	1	
11	Cover gasket	1	
12	Choke cable	1	
13	Throttle cable	1	
			 Choke cable guide set position (a): 17 mm (0.67 in) Throttle cable guide set position (a): 14 mm (0.55 in)
14	Hose tie	3	
15	Fuel hose (fuel filter - fuel pump)	1	
16	Pulse hose (fuel pump - crank case)	1	
17	Fuel hose (carburetor - fuel tank)	1	
18	Nut	6	
19	Carburetor assembly	1	
20	Gasket	1	
			Reverse the removal steps for installation.



CARBURETOR



CARBURETOR EXPLODED DIAGRAM






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	CARBURETOR DISASSEMBLY		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
	Carburetor assembly		
1	Bolt	4	
2	Collar	2	
3	Screw	8	
4	Cover 3	2	
5	Diaphragm assembly	2	
6	Screw	2	
7	Float arm	2	
8	Spring	2	
9	Pin	2	
10	Screw	2	
11	Plate	2	
12	Needle valve assembly	2	
13	Screw	4	
14	Body assembly	2	
15	Packing	2	
16	Main jet	2	
17	Pilot jet	2	
18	Screw	8	
19	Pump cover	2	
20	Pump cover gasket	1	
21	Diaphragm	1	
22	O-ring	1	
23	Diaphragm body assembly	1	
24	Diaphragm	1	
25	O-ring	2	
26	Filter	2	
27	High speed screw	2	
28	Low speed screw	2	
29	Spring	4	
30	Plate washer	4	
31	O-ring	4	
			Reverse the removal steps for installation.



EXPLODED DIAGRAM (WVT1100)





REMOVAL AND INSTALLATION CHART




Step	Procedure/Part name	Q'ty	Service points
	CARBURETOR DISASSEMBLY		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
	Carburetor assembly		
1	Bolt	6	
2	Collar	1	
3	Cover gasket	3	
4	Screw	12	
5	Cover 3	3	
6	Diaphragm assembly	3	
7	Screw	3	
8	Float arm	3	
9	Spring	3	
10	Pin	3	
11	Screw	3	
12	Plate	3	
13	Needle valve assembly	3	
14	Screw	6	
15	Body assembly	3	
16	Packing	3	
17	Main jet	3	
18	Pilot jet	3	
19	Screw	12	
20	Pump cover	3	
21	Pump cover gasket	1	
22	Diaphragm	1	
23	O-ring	1	
24	Diaphragm body assembly	1	
25	Diaphragm	1	
26	O-ring	3	
27	Filter	3	
28	High speed screw	3	
29	Low speed screw	3	
30	Spring	6	
31	Plate washer	6	
32	O-ring	6	
			Reverse the removal steps for installation.



SERVICE POINTS

CAUTION

Do not use steel wire for cleaning the jets as this may enlarge the jet diameters and seriously affect performance.



Diaphragm Inspection

- Inspect:
 - Diaphragm assembly
Damage → Replace.

Float arm inspection

- Inspect:
 - Float arm ①
Bend/Damage → Repair or replace.
- Measure:
 - Float arm height ②



Float arm height:
0 - 0.2 mm (0 - 0.008 in)

NOTE:

- Measure the distance between the surface ③ of the carburetor body and the top surface of the float arm.
- The float arm should be resting on the needle valve, but not compressing the needle valve.

Body assembly inspection


- Inspect:
 - Body assembly ①
Contamination → Clean.
 - Valve ②
Damage → Replace.

Fuel pump inspection (WVT700)

- Inspect:
 - Diaphragm
 - Diaphragm body assembly
Damage → Replace.

Filter inspection

- Inspect:
 - Filter
Contamination → Clean.
Damage → Replace.



Needle valve inspection

1. Inspect:
 - Needle valve
 - Valve seat
- Grooved wear (a) → Replace.
Dust (b) → Clean.


NOTE: _____
Always replace the needle valve and valve seat as a set.

Jet and carburetor body inspection

1. Inspect:
 - Main jet
 - Pilot jet
 - Carburetor body
- Contamination → Clean.

High and low speed screws inspection

1. Inspect:
 - High speed screw
 - Low speed screw
- Bend/Wear → Replace.



High and low speed screws adjustment

1. Adjust:
 - High speed screw
 - Low speed screw

Adjustment steps:

- Screw in the high speed screw (1) or lower speed screw (2) until it is lightly seated.
- Back out by the specified number of turns.






High speed screw:

- WVT700
5/8 (#1), 1-1/8 (#2) = 1/4 turns out
- WVT1100
7/8 (#1) ± 1/4 turns out

Low speed screw:

- WVT700
5/8 (#1) ± 1/4 turns out
- WVT1100
1-1/8 (#1) ± 1/4 turns out



Throttle valve synchronization inspection and adjustment

1. Check:

- Throttle valve synchronization
Out of specification → Adjust.

Checking steps:

- While turning the throttle lever, check the opening of all throttle valves.

2. Adjust:

- Throttle valve synchronization

Adjustment steps: WVT700

- Turn out the idle adjust screws (1) until their tips are apart from the throttle lever (2).

NOTE:

Record the set position of the idle adjust screw.

- Check that the #2 throttle valve (3) is fully closed.
- Turn the synchronization screw (4) in or out until the #1 throttle valve (5) is fully closed.
- Turn in the idle adjust screws to the set position.

Adjustment steps: WVT1100

- Turn out the idle adjust screws (1) until its tip is apart from the throttle lever (2).

NOTE:




Record the set position of the idle adjust screw.

- Turn out the synchronization screws (3) and (4) until their tips are apart from the connecting lever.
- Turn in the synchronization screw (3) until the #2 and #3 throttle valves are fully closed.

NOTE:

Turning in the screw (3) further causes the #3 throttle valve to open again.

- Turn in the synchronization screw (4) until the #1 throttle valve is fully closed.
- Check that the all throttle valves are fully closed. If not, do step a through e again.
- Turn in the idle adjust screw to the set position.



Choke valve synchronization inspection and adjustment

1. Check:

- Choke valve synchronization
- Out of specification → Adjust.

Checking steps:

- While turning the choke lever, check the opening of all choke valves.

2. Adjust:

- Choke valve synchronization

Adjustment steps: WVT700

- a. Turn in or out the synchronization screw (1) to bring all the choke valves into a fully closed position when the choke lever is turned on the closed side.

Adjustment steps: WVT1100

- a. Turn out the synchronization screws (1) and (2) until their tips are apart from the synchronization lever.
- b. Turn in the synchronization screw (1) to bring #3 and #2 choke valves into a fully closed position when the choke lever is turned on the closed side.
- c. Turn in the synchronization screw (2) to bring #1 choke valve into a fully closed position when the choke lever is turned on the closed side.
- d. Check that the all choke valves are fully closed. If not, do step a through d again.

Carburetor assembly


1. Adjust:

- Trolling speed
- Refer to the "FUEL SYSTEM" section in chapter 3.





OIL PUMP
EXPLODED DIAGRAM

WVT700



WVT1100





REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty		Service points
	OIL PUMP REMOVAL			Follow the left "Step" for removal.
1	Hose tie	1	1	
2	Oil hose	1	1	
3	Hose tie	2	3	
4	Oil delivery hose	2	3	
5	Hose tie	-	1	
6	Oil return hose	-	1	
7	Bolt (with washer)	2	2	
8	Oil pump	1	1	
9	Oil pump gasket	1	1	
10	Air bleeding screw	1	-	
11	Gasket	1	-	
12	Air bleeding hose	-	1	
				Reverse the removal steps for installation.

SERVICE POINTS

Oil pump inspection

- 1. Inspect:
 - Oil pump
Clog → Clean.
 - Driving tooth
Wear/Damage → Replace.

Oil hose inspection

- 1. Inspect:
 - Oil hose
Wear/Crack → Replace.

CAUTION


After installing the oil injection system, bleed the system of air.

CHAPTER 5 POWER UNIT

ENGINE UNIT REMOVAL	5-1
EXPLODED DIAGRAM (WVT700)	5-1
REMOVAL AND INSTALLATION CHART	5-2
EXPLODED DIAGRAM (WVT1100)	5-3
REMOVAL AND INSTALLATION CHART	5-4
SERVICE POINTS	5-5
Mount bracket inspection	5-5
Coupling clearance inspection	5-5
REED VALVE	5-6
EXPLODED DIAGRAM	5-6
REMOVAL AND INSTALLATION CHART	5-7
SERVICE POINTS	5-7
Reed valve inspection	5-7
EXHAUST RING	5-8
EXPLODED DIAGRAM (WVT700)	5-8
REMOVAL AND INSTALLATION CHART	5-9
EXPLODED DIAGRAM (WVT1100)	5-10
REMOVAL AND INSTALLATION CHART	5-11
EXHAUST CHAMBER	5-12
EXPLODED DIAGRAM (WVT700)	5-12
REMOVAL AND INSTALLATION CHART	5-13
EXPLODED DIAGRAM (WVT1100)	5-14
REMOVAL AND INSTALLATION CHART	5-15
MUFFLER	5-16
EXPLODED DIAGRAM (WVT700)	5-16
REMOVAL AND INSTALLATION CHART	5-17
EXPLODED DIAGRAM (WVT1100)	5-18
REMOVAL AND INSTALLATION CHART	5-19
CYLINDER HEAD, CYLINDER AND PISTON	5-20
EXPLODED DIAGRAM (WVT700)	5-20
REMOVAL AND INSTALLATION CHART	5-21
EXPLODED DIAGRAM (WVT1100)	5-22
REMOVAL AND INSTALLATION CHART	5-23
SERVICE POINTS	5-24
Cylinder head inspection	5-24
Cylinder inspection	5-24
Piston inspection	5-25
Piston ring inspection	5-26
Piston pin and bearing inspection	5-27

FLYWHEEL MAGNETO AND BASE (WVT700) ...	5-28
EXPLODED DIAGRAM	5-28
REMOVAL AND INSTALLATION CHART	5-29
FLYWHEEL COVER AND FLYWHEEL MAGNETO (WVT1100)	5-30
EXPLODED DIAGRAM	5-30
REMOVAL AND INSTALLATION CHART	5-31
SERVICE POINTS	5-32
Coupling flange removal and installation	5-32
Flywheel magneto removal and installation	5-32
Coupling flange inspection	5-32
Flywheel magneto inspection	5-32
Idle gear assembly inspection	5-33
ELECTRICAL UNIT	5-34
EXPLODED DIAGRAM (WVT700)	5-34
REMOVAL AND INSTALLATION CHART	5-35
EXPLODED DIAGRAM (WVT1100)	5-36
REMOVAL AND INSTALLATION CHART	5-37
EXPLODED DIAGRAM (WVT1100)	5-38
REMOVAL AND INSTALLATION CHART	5-39
CRANKCASE AND CRANKSHAFT	5-40
EXPLODED DIAGRAM (WVT700)	5-40
REMOVAL AND INSTALLATION CHART	5-41
EXPLODED DIAGRAM (WVT1100)	5-42
REMOVAL AND INSTALLATION CHART	5-43
SERVICE POINTS	5-44
Crankshaft inspection	5-44
Crankcase inspection	5-45
INTERMEDIATE SHAFT AND HOUSING	5-46
EXPLODED DIAGRAM	5-46
REMOVAL AND INSTALLATION CHART	5-47
SERVICE POINTS	5-48
Coupling removal and installation	5-48
Bearing removal and installation	5-48
Bearing inspection	5-48
Coupling inspection	5-48
Oil seal installation	5-48

ENGINE UNIT REMOVAL
EXPLODED DIAGRAM (WVT700)




REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	ENGINE UNIT REMOVAL		Follow the left "Step" for removal.
	Engine hood assembly		Refer to the "ENGINE HOOD REMOVAL" section in chapter 8.
	Oil tank assembly		Refer to the "OIL TANK AND FUEL TANK REMOVAL" section in chapter 4.
	Fuel tank assembly		
	Ventilation hose		Refer to the "DECK" section in chapter 8.
1	Battery negative lead	1	
2	Battery positive lead	1	
3	Wire clamp	4	
4	Bolt (with washer)	2	
5	Electrical box	1	
6	Fuel filter	1	
7	Housing grease nipple plate	1	
8	Bolt (with washer)	2	
9	Coupling cover	1	
10	Collar	2	
11	Clamp	1	
12	Water inlet hose	1	
13	Hose tie	1	
14	Water outlet hose	1	
15	Clamp	1	
16	Exhaust hose	1	
17	Hose tie	2	
18	Water hose	1	
19	Engine mounting bolt	4	
20	Shim	*	NOTE: Before removing the mounting bolt, mark the engine mounting shim packs for ease of reassembly and coupling alignment.
21	Engine unit	1	
22	Bolt (with washer)	8	
23	Mount bracket	4	
24	Mount bracket spacer	2	
			Reverse the removal steps for installation.

*: As required

EXPLODED DIAGRAM (WVT1100)



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Qty	Service points
	ENGINE UNIT REMOVAL		Follow the left "Step" for removal.
1	Negative lead	1	NOTE: Clamp the handle switch leads and meter leads with the band.
2	Positive lead	1	
3	Spiral tube	1	
4	Band	1	
5	Wire clamp	1	NOTE: Before removing the mounting bolt, mark the engine mounting shim packs for ease of reassembly and coupling alignment.
6	Handle switch lead coupler	2	
7	Meter lead coupler	1	
8	Fuel hose	1	
9	Fuel hose (return)	1	
10	Oil hose	2	
11	Choke cable	1	
12	Throttle cable	1	
13	Bolt (with washer)	2	
14	Plate	1	
15	Bolt (with washer)	2	
16	Coupling cover	1	
17	Collar	2	
18	Clamp	1	
19	Water inlet hose	1	
20	Hose tie	1	
21	Water outlet hose	1	
22	Clamp	1	
23	Exhaust hose	1	
24	Hose tie	1	
25	Pilot water hose	1	
26	Engine mounting bolt	4	
27	Shim	*	
28	Engine unit	1	
29	Bolt (with washer)	8	
30	Mount bracket	4	
31	Mount bracket spacer	3	
			Reverse the removal steps for installation.

*: As required

SERVICE POINTS

Mount bracket inspection

- 1. Inspect:
 - Mount bracket
 - Crack/Damage → Replace.




Coupling clearance inspection

- 1. Measure:
 - Clearance **a**
 - Clearance **b**
 - Out of specification → Adjust using shim.


NOTE: _____

- Before measuring the clearance, remove the coupling rubber.
- Attach a straight edge and a thickness gauge.

	Clearance a:
	0 ~ 0.5 mm (0 - 0.020 in)
	Clearance b:
	2 ~ 4 mm (0.079 - 0.157 in)





REED VALVE
EXPLODED DIAGRAM



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty		Service points
REED VALVE REMOVAL				Follow the left "Step" for removal. Refer to the "CARBURETOR REMOVAL" section in chapter 4. 6 × 35 mm 6 × 25 mm <hr/> CAUTION: Tighten the bolts in sequence. <hr/> 6 × 16 mm 5 × 16 mm
	Carburetor assembly	1	1	
1	Bolt (with washer)	3	4	
2	Plate	1	-	
3	Bolt (with washer)	8	12	
4	Intake manifold assembly	1	1	
5	Bolt (with washer)	2	2	
6	Cable bracket	1	1	
7	Screw	4	6	
8	Reed valve assembly	2	3	
9	Gasket	2	1	
10	Plate	1	-	
REED VALVE DISASSEMBLY				Reverse the removal steps for installation.
①	Screw	8		
②	Valve stopper	4		
③	Reed valve	4		
④	Reed valve body	1		



SERVICE POINTS

Reed valve inspection


1. inspect:
 - Reed valve
Crack/Damage → Replace.
2. Measure:
 - Valve bending ①
Out of specification → Replace.

 **Valve bending limit:**
0.2 mm (0.008 in)

3. Measure:
 - Valve stopper height ②
Out of specification → Adjust or replace.

 **Valve stopper height:**
9.0 ± 0.2 mm (0.35 ± 0.01 in)


**EXHAUST RING
EXPLODED DIAGRAM (WVT700)**



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
EXHAUST RING REMOVAL			Follow the left "Step" for removal.
1	Hose tie	1	NOTE: ● Pull and slide the exhaust joint. ● Loosen the clamp on the chamber side.
2	Pilot water hose	1	
3	Clamp	2	
4	Exhaust joint	1	
5	Clamp	1	
6	Bolt (with washer)	4	
7	Ring assembly	1	
8	Gasket	1	
9	Pin dowel	2	
RING DISASSEMBLY			
①	Clamp	1	CAUTION: Tighten the clamp before installing the ring on the muffler.
②	Joint	1	Reverse the removal steps for installation.
③	Exhaust joint	1	
④	Ring	1	

EXPLODED DIAGRAM (WVT1100)






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
EXHAUST RING REMOVAL			Follow the left "Step" for removal.
1	Hose tie	3	<p>NOTE:</p> <ul style="list-style-type: none"> ● Pull and slide the exhaust joint. ● Loosen the clamp on the chamber side.
2	Pilot water hose	1	
3	Water hose	2	
4	Clamp	2	
5	Exhaust joint	1	
6	Clamp	1	
7	Bolt (with washer)	4	
8	Ring assembly	1	
9	Gasket	1	
10	Pin dowel	2	
RING DISASSEMBLY			<p>CAUTION:</p> <p>Tighten the clamp before installing the ring on the muffler.</p>
①	Clamp	1	
②	Joint	1	
③	Exhaust joint	1	
④	Ring	1	Reverse the removal steps for installation.

**EXHAUST CHAMBER
EXPLODED DIAGRAM (WVT700)**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	EXHAUST CHAMBER REMOVAL		Follow the left "Step" for removal. Refer to the "EXHAUST HING" section.
	Ring assembly		
1	Clamp	1	
2	Exhaust hose	1	
3	Hose tie	1	
4	Water outlet hose	1	
5	Bolt (exhaust chamber)	2	
6	Bolt (muffler stay)	4	
7	Muffler stay	1	
8	Bolt	2	
9	Exhaust chamber assembly	1	
	CHAMBER DISASSEMBLY		
①	Bolt (with washer)	6	
②	Exhaust outer cover 1	1	
③	Gasket	1	
④	Exhaust inner cover	1	
⑤	Seal	1	
⑥	Gasket	1	
⑦	Bolt (with washer)	6	
⑧	Exhaust outer cover 2	1	
⑨	Gasket	1	
⑩	Exhaust chamber	1	
			Reverse the removal steps for installation.

EXPLODED DIAGRAM (WVT1100)






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
EXHAUST CHAMBER REMOVAL			Follow the left "Step" for removal. Refer to the "EXHAUST RING" section.
	Ring assembly		
1	Clamp	1	
2	Exhaust hose	1	
3	Hose tie	1	
4	Water outlet hose	1	
5	Bolt (exhaust chamber)	2	
6	Bolt (muffler stay)	4	
7	Muffler stay	1	
8	Bolt	2	
9	Exhaust chamber assembly	1	
CHAMBER DISASSEMBLY			Reverse the removal steps for installation.
①	Hose tie	2	
②	Water hose	1	
③	Bolt (with washer)	6	
④	Exhaust outer cover 1	1	
⑤	Gasket	1	
⑥	Muffler 2	1	
⑦	Gasket	1	
⑧	Exhaust inner cover	1	
⑧	Gasket	1	
⑩	Seal	1	
⑪	Exhaust chamber	1	



MUFFLER
EXPLODED DIAGRAM (WVT700)
SILENCIEUX
VUE EN ECLATE (WVT700)





MUFFLER SILENCIEUX

(E)

(F)

REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	MUFFLER REMOVAL		Follow the left "Step" for removal. Refer to the "EXHAUST CHAMBER" section. Reverse the removal steps for installation.
	Exhaust chamber		
1	Bolt (with washer)	8	
2	Muffler	1	
3	Gasket	1	
4	Bolt (with washer)	4	
5	Protector	1	
6	Gasket	2	
7	Inner cover	1	

TABLEAU DE DÉPÔSE ET D'INSTALLATION

Étape	Procédure/nom de pièce	Qté	Remarques particulières d'entretien
	DÉPÔSE DU SILENCIEUX		Suivre "l'étape" de gauche pour la dépose. Voir la section "CHAMBRE D'ÉCHAPPEMENT". Pour l'installation, inverser les étapes de la dépose.
	Chambre d'échappement		
1	Boulon (avec rondelle)	8	
2	Silencieux	1	
3	Joint	1	
4	Boulon (avec rondelle)	4	
5	Protection	1	
6	Joint	2	
7	Cache interne	1	




**MUFFLER
SILENCIEUX**

(E)

(F)

EXPLODED DIAGRAM (WVT1100)

VUE EN ECLATE (WVT1100)





REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	MUFFLER REMOVAL		Follow the left "Step" for removal. Refer to the "EXHAUST CHAMBER" section.
	Exhaust chamber		
1	Clamp	1	
2	Water inlet hose	1	
3	Bolt (with washer)	12	CAUTION: Tighten the bolts in sequence and in two steps of torque.
4	Muffler assembly	1	
5	Gasket	1	
6	Pin	2	
7	Bolt (with washer)	1	
8	Clamp	1	
9	Collar	1	
10	Bolt (with washer)	4	
11	Muffler 1	1	
12	Gasket	1	
13	Muffler cover	1	
			Reverse the removal steps for installation.

TABLEAU DE DEPOSE ET D'INSTALLATION

Etape	Procédé/nom de pièce	Q'té	Remarques particulières d'entretien
	DEPOSE DU SILENCIEUX		Suivre "l'étape" de gauche pour la dépose. Voir la section "CHAMBRE D'ÉCHAPPEMENT".
	Chambre d'échappement		
1	Bride	1	
2	Flexible d'admission d'eau	1	
3	Boulon (avec rondelle)	12	ATTENTION: Serrer les boulons dans l'ordre et en deux étapes de couple.
4	Ensemble de silencieux	1	
5	Joint	1	
6	Goujon	2	
7	Boulon (avec rondelle)	1	
8	Bride	1	
9	Coller	1	
10	Boulon (avec rondelle)	4	
11	Silencieux 1	1	
12	Joint	1	
13	Capuchon de silencieux	1	
			Pour l'installation, inverser les étapes de la dépose.



**CYLINDER HEAD, CYLINDER AND PISTON
EXPLODED DIAGRAM (WVT700)**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	CYLINDER HEAD, CYLINDER AND PISTON REMOVAL		Follow the left "Step" for removal.
	Muffler		Refer to the "MUFFLER" section.
1	Spark plug cap	2	
2	Spark plug	2	
3	Bolt (with washer)	2	
4	Thermo switch assembly	1	
5	Bolt (with washer)	10	CAUTION: Tighten the bolts in sequence and in two steps of torque.
6	Cylinder head	1	
7	Cylinder head gasket	1	
8	Bolt (with washer)	6	CAUTION: Tighten the bolts in two steps of torque.
9	Cylinder	1	CAUTION: After installing, check that the piston moves smoothly.
10	Cylinder gasket	1	
11	Pin	2	
12	Piston pin clip	4	NOTE: Before installing the piston pin clip, cover the crankcase with a clean rag to prevent the piston pin clip from falling into the crankcase cavity. CAUTION: Do not allow the open ends of the clip to touch the piston pin slot (A).
13	Piston pin	2	
14	Piston	2	NOTE: Be sure that the arrow (B) is positioned on the exhaust side.
15	Washer	4	
16	Bearing	2	
17	Piston ring	4	CAUTION: Align each end gap with the locating pin. Reverse the removal steps for installation.







EXPLODED DIAGRAM (WVT1100)





REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	CYLINDER HEAD, CYLINDER AND PISTON REMOVAL		Follow the left "Step" for removal.
	Muffler		Refer to the "MUFFLER" section
1	Spark plug cap	3	
2	Spark plug	3	
3	Bolt (with washer)	14	CAUTION: Tighten the bolts in sequence and in two steps of torque.
4	Cylinder head cover	1	
5	Cylinder head gasket	1	
6	Bolt (with washer)	15	CAUTION: Tighten the bolts in sequence and in two steps of torque.
7	Cylinder head cover	1	
8	Bolt (with washer)	1	
9	Bolt (with washer)	8	CAUTION: Tighten the bolts in two steps of torque.
10	Cylinder	1	CAUTION: After installing, check that the piston moves smoothly.
11	Cylinder gasket	1	
12	Pin	2	
13	Piston pin clip	6	NOTE: Before installing the piston pin clip, cover the crankcase with a clean rag to prevent the piston pin clip from falling into the crankcase cavity. CAUTION: Do not allow the open ends of the clip to touch the piston pin slot (a).
14	Piston pin	3	
15	Piston	3	NOTE: Be sure that the arrow (b) is positioned on the exhaust side.
16	Washer	6	
17	Bearing	3	
18	Piston ring	6	CAUTION: Align each end gap with the locating pin. Reverse the removal steps for installation.



SERVICE POINTS

Cylinder head inspection

1. Eliminate:
 - Carbon deposits
Use a rounded scraper ①.

NOTE:

Take care to avoid damaging the spark plug threads. Do not use a sharp instrument. Avoid scratching the aluminum.

2. Inspect:
 - Cylinder head water jacket
Mineral deposits/Corrosion → Clean.
3. Measure:
 - Cylinder head warpage
Out of specification → Resurface.




Warpage limit:
0.1 mm (0.004 in)

Warpage measurement and resurfacing steps:

- Attach a straight edge and a thickness gauge to the cylinder head.
- Measure the warpage.
- If the warpage is out of specification, resurface the cylinder head.
- Place a piece of 400 - 600 grit wet sandpaper on the surface plate, and resurface the head using a figure-eight sanding pattern.

Cylinder inspection

1. Eliminate:
 - Carbon deposits
Use a rounded scraper ①.
2. Inspect:
 - Cylinder water jacket
Mineral deposits/Corrosion → Clean
 - Cylinder inner surface
Score marks → Repair or replace.
Use #600 - 800 grit wet sandpaper.





3. Measure:

- Cylinder bore "D"
Use cylinder gauge.
Out of specification → Replace.

NOTE:

Measure the cylinder bore "D" in several different directions. Then find the average of the measurements.



	Standard	Limit
Cylinder bore "D"	81.00 - 81.02 mm (3.189 - 3.190 in)	81.10 mm (3.193 in)
Taper "T"	—	0.08 mm (0.003 in)
Out of round "R"	—	0.05 mm (0.002 in)
D = Maximum (D ₁ - D ₆) T = (Maximum D ₁ or D ₂) - (Maximum D ₅ or D ₆) R = (Maximum D ₁ , D ₃ or D ₅) - (Minimum D ₂ , D ₄ or D ₆)		


Piston inspection

1. Eliminate:

- Carbon deposits
From the piston crown and ring groove.

2. Inspect:

- Piston wall
Score marks → Repair or replace.
Use #600 - 800 grit wet sandpaper.





NOTE:

Sand in a criss-cross pattern. Do not sand excessively.

3. Measure:

- Piston skirt diameter
Use micrometer.
Out of specification → Replace.




	Piston diameter	Distance (ø)
	80.925 - 80.950 mm (3.186 - 3.187 in) WVT1100:	10 mm (0.39 in)
	80.885 - 80.890 mm (3.184 - 3.185 in)	



4. Calculate:

- Piston clearance
Out of specification → Replace piston, piston rings as a set.

PISTON CLEARANCE	=	CYLINDER BORE	-	PISTON DIAMETER
---------------------	---	------------------	---	--------------------




	Piston clearance: 0.080 ~ 0.085 mm (0.0031 ~ 0.0033 in) WVT1100: 0.110 ~ 0.115 mm (0.0043 ~ 0.0045 in)
--	-------------------------------------------------------------------------------------------------------------------------------------

Piston ring inspection

1. Measure:


- Side clearance
Out of specification → Replace piston and/or ring.
Use a thickness gauge ①.



	Side clearance: Top 2nd 0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in)
--	--------------------------------------------------------------------------------

2. Measure:

- End gap
Out of specification → Replace rings as a set.
Use a thickness gauge ①.



	End gap: Top 2nd 0.2 ~ 0.4 mm (0.008 ~ 0.016 in)
--	------------------------------------------------------------------

NOTE: _____


- Install the piston ring in the cylinder.
- Push the ring with the piston crown.



Piston pin and bearing inspection

1. Inspect:


- Piston pin
 - Bearing
- Signs of heat discoloration → Replace.



2. Measure:


- Piston pin outside diameter
- Use micrometer.
Out of limit → Replace.

	Piston pin outside diameter:
	Standard
	19.995 - 20.000 mm (0.7872 - 0.7874 in)
	Limit
	19.98 mm (0.786 in)



3. Check:

- Free play (when the piston pin is in place in the piston)
- There should be no noticeable free play.
Free play is noticeable → Replace piston pin and/or piston.



4. Check:


- Free play
- There should be no noticeable free play.
Free play is noticeable → Inspect the connecting rod for wear/Replace the pin and/or connecting rod as required.



FLYWHEEL MAGNETO AND BASE



FLYWHEEL MAGNETO AND BASE (WVT700) EXPLODED DIAGRAM






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	FLYWHEEL MAGNETO AND BASE REMOVAL		Follow the left "Step" for removal.
	Engine unit		Refer to the "ENGINE UNIT REMOVAL" section.
1	Bolt (with washer)	2	
2	Oil pump	1	
3	Gasket	1	
4	Bolt (with washer)	1	
5	Clamp	1	
6	Bolt (with washer)	6	
7	Flywheel cover	1	
8	Flywheel cover gasket	1	
9	Pin	1	
10	Plate washer	2	NOTE: _____
11	Spring	1	Fill the flywheel cover groove with water resistant grease.
12	Coupling flange	1	
13	Flange bolt	1	
14	Flywheel magneto	1	NOTE: _____ When installing the flywheel magneto make sure that the woodruff key is properly seated in the keyway of the crankshaft.
15	Woodruff key	1	
16	Screw	2	
17	Base assembly	1	NOTE: _____ Align the punch mark on the crankcase with the punch mark on the base assembly.
18	Idle gear assembly	1	Reverse the removal steps for installation.



FLYWHEEL COVER AND FLYWHEEL MAGNETO (WVT1100)
EXPLODED DIAGRAM








FLYWHEEL COVER AND FLYWHEEL MAGNETO



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	FLYWHEEL COVER AND FLYWHEEL MAGNETO REMOVAL		Follow the left "Step" for removal.
	Engine unit		Refer to the "ENGINE UNIT REMOVAL" section
1	Spark plug cap	3	
2	Bolt (with washer)	2	
3	Thermo switch	1	
4	Nut	1	
5	Spring washer	1	
6	Starter motor positive lead	1	
7	Battery positive lead	1	
8	Bolt (with washer)	2	
9	Oil pump	1	
10	Gasket	1	
11	Bolt (with washer)	1	8 x 25 mm
12	Bolt (with washer)	1	8 x 55 mm
13	Bolt (with washer)	7	8 x 30 mm
14	Flywheel cover assembly	1	
15	Flywheel cover gasket	1	
16	Pin	2	
17	Plate washer	2	NOTE: _____
18	Spring	1	Fill the flywheel cover groove with water resistant grease.
19	Coupling flange	1	
20	Flange bolt	1	
21	Flywheel magneto	1	NOTE: _____ When installing the flywheel magneto make sure that the woodruff key is properly seated in the keyway of the crankshaft.
22	Woodruff key	1	
23	Idle gear assembly	1	
			Reverse the removal steps for installation.



SERVICE POINTS

Coupling flange removal and installation

1. Remove and install:
 - Coupling flange



Coupler wrench:
 WVT700
 YW-38741/90890-06425
 WVT1100
 YW-06545/90890-06546
Flywheel holder:
 WVT700
 YB-06139/90890-06522
 WVT1100
 YW-41528/90890-06545

Flywheel magneto removal and installation

1. Remove and install:
 - Bolt



Flywheel holder:
 YB-06139/90890-06522
 WVT1100:
 YW-41528/90890-06545

2. Remove:
 - Flywheel magneto



Flywheel puller:
 YB-06117/90890-06521
Bolt:
 M8 x 80 mm

A: For USA and CANADA

B: Except for USA and CANADA

CAUTION


To prevent damage to the engine or tools, screw in the flywheel puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel.

Coupling flange inspection

1. Inspect:
 - Coupling flange
 Wear/Damage → Replace.

Flywheel magneto inspection

1. Inspect:
 - Flywheel gear
 Wear/Damage → Replace.

**Idle gear assembly inspection**


1. Inspect:

- Pinion gear ③
 - inner gear ⑤
- Wear/Damage → Replace.

2. Check:

- Clutch movement
- Unsmooth movement → Replace.

ELECTRICAL UNIT
EXPLODED DIAGRAM (WVT700)






ELECTRICAL UNIT



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	ELECTRICAL UNIT REMOVAL		Follow the left "Step" for removal. Refer to the "ENGINE UNIT REMOVAL" section. Refer to the "FLYWHEEL MAGNETO AND BASE" section.
	Electrical box		
	Base assembly		
1	Spark plug cap	2	
2	Bolt (with washer)	2	
3	Thermo switch	1	
4	Nut	1	
5	Spring washer	1	
6	Starter motor negative lead	1	
	ELECTRICAL UNIT DISASSEMBLY		Reverse the removal steps for installation.
①	Screw	14	
②	Case cover	1	
③	Screw	2	
④	Ignition coil	1	
⑤	Screw	3	
⑥	Clamp	1	
⑦	Rectifier-regulator	1	
⑧	Screw	3	
⑨	Clamp bracket	1	
⑩	CDI unit	1	
⑪	Nut	2	
⑫	Spring washer	2	
⑬	Starter relay	1	
⑭	Housing	1	

EXPLODED DIAGRAM (WVT1100)



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Qty	Service points
	ELECTRICAL UNIT DISASSEMBLY		Follow the left "Step" for removal.
	Flywheel cover assembly		Refer to the "FLYWHEEL COVER AND FLYWHEEL MAGNETO" section.
1	Bolt (with washer)	5	
2	Ignition coil cover	1	
3	Collar	5	
4	Packing	1	
5	Bolt (with washer)	3	
6	Grommet	6	
7	Washer	6	
8	Collar	3	
9	Bolt (with washer)	1	6 × 12 mm
10	Rectifier-regulator	1	
11	Lead tie	2	
12	Bolt	2	6 × 12 mm
13	Plate	1	
14	Nut	2	
15	Spring washer	2	
16	Starter motor positive lead	1	
17	Battery positive lead	1	
18	Bolt (with washer)	2	
19	Bracket	1	
20	Damper (ignition coil)	1	
21	Bolt	3	6 × 12 mm
22	Plate (ignition coil and thermo switch)	1	
23	Lead tie	3	
24	Thermo switch	1	
25	Rectifier-regulator	1	
26	Bolt (with washer)	2	6 × 16 mm
27	Starter relay assembly	1	
28	Bolt	2	6 × 12 mm
29	Plate (extension wire and fuse holder lead)	1	
30	Fuse holder lead	1	
31	Extension wire	1	
32	Bolt (with washer)	2	6 × 14 mm



ELECTRICAL UNIT
SYSTEME ELECTRIQUE

(E)
(F)

EXPLODED DIAGRAM (WVT1100)
VUE EN ECLATE (WVT1100)





ELECTRICAL UNIT SYSTEME ELECTRIQUE

(E)

(F)


REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
33	Wire holder	1	Reverse the removal steps for installation.
34	Grommet	1	
35	Clamp	2	
36	CDI unit	1	
37	Socket bolt	2	
38	Clamp	1	
39	Grommet	1	
40	Socket bolt	3	
41	Base assembly	1	
42	Socket bolt	3	
43	Pulser coil ground lead	3	
44	Clamp	3	
45	Socket bolt	6	
46	Pulser coil assembly	1	
47	Flywheel cover	1	

TABEAU DE DEPOSE ET D'INSTALLATION

Etape	Procédé/nom de pièce	Q'té	Remarques particulières d'entretien
33	Serre-fil	1	Pour l'installation, inverser les étapes de la dépose.
34	Oeillet	1	
35	Bride	2	
36	Unité C.D.I.	1	
37	Boulon de douille	2	
38	Bride	1	
39	Oeillet	1	
40	Boulon de douille	3	
41	Ensemble de base	1	
42	Boulon de douille	3	
43	Fil de terre de la bobine d'impulsion	3	
44	Bride	3	
45	Boulon de douille	6	
46	Ensemble de bobine d'impulsion	1	
47	Capuchon de volant magnétique	1	

**CRANKCASE AND CRANKSHAFT
EXPLODED DIAGRAM (WVT700)**



1st	15 Nm (1.5 m • kg, 11 ft • lb)
2nd	28 Nm (2.8 m • kg, 20 ft • lb)


1st	23 Nm (2.3 m • kg, 17 ft • lb)
2nd	53 Nm (5.3 m • kg, 38 ft • lb)



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Qty	Service points
	CRANKCASE AND CRANKSHAFT DISASSEMBLY		Follow the left "Step" for removal.
	Base assembly		Refer to the "FLYWHEEL MAGNETO AND BASE" section.
	Carburetor assembly		Refer to the "CARBURETOR REMOVAL" section in chapter 4.
	Reed valve assembly		Refer to the "REED VALVE" section.
	Piston		Refer to the "CYLINDER HEAD, CYLINDER AND PISTON" section.
1	Bolt (with washer)	2	
2	Starter motor	1	
3	Bolt (with washer)	7	NOTE: _____ Tighten the bolts in two steps of torque.
4	Engine mount bracket	2	
5	Bolt (with washer)	8	NOTE: _____ Tighten the bolts in sequence and in two steps of torque.
6	Mount rubber	1	NOTE: _____ Be sure that the "F" mark Ⓢ is on the fly-wheel side.
7	Crankcase	1	
8	Pin	2	
9	Crankshaft assembly	1	NOTE: _____ After installing, check the smooth movement of the crankshaft.
			CAUTION: _____ <ul style="list-style-type: none"> ● Do not allow the open ends of the bearing clip to meet the crankcase contacting surface. ● Place the locating pins on the bearing in the crankcase body groove.
10	Dowel pin	4	
11	Oil seal	3	
12	Case body	1	
			Reverse the removal steps for installation.

EXPLODED DIAGRAM (WVT1100)



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	CRANKCASE AND CRANKSHAFT DISASSEMBLY		Follow the left "Step" for removal.
	Base assembly		Refer to the "FLYWHEEL MAGNETO AND BASE" section.
	Carburetor assembly		Refer to the "CARBURETOR REMOVAL" section in chapter 4.
	Reed valve assembly		Refer to the "REED VALVE" section.
	Piston		Refer to the "CYLINDER HEAD, CYLINDER AND PISTON" section.
1	Bolt (with washer)	2	
2	Starter motor	1	
3	Bolt (with washer)	2	
4	Mount rubber	1	NOTE: Be sure that the "F" mark (F) is on the flywheel side.
5	Bolt (with washer)	9	
6	Engine mount bracket	2	
7	Bolt (with washer)	12	NOTE: Tighten the bolts in sequence and in two steps of torque.
8	Crankcase	1	
9	Pin	2	
10	Crankshaft assembly	1	NOTE: After installing, check the smooth movement of the crankshaft.
			CAUTION: <ul style="list-style-type: none"> • Do not allow the open ends of the bearing clip to meet the crankcase contacting surface. • Place the locating pins on the bearing in the crankcase body groove.
11	Dowel pin	8	
12	Oil seal	3	
13	Case body	1	Reverse the removal steps for installation.



SERVICE POINTS

Crankshaft inspection


1. Measure:

- Crank width (A)

Out of specification → Replace.



Crank width:
61.95 - 62.00 mm
(2.439 - 2.441 in)



2. Measure:


- Deflection (B)

Use a dial gauge.

Out of specification → Replace.



Maximum deflection:
0.05 mm (0.002 in)



3. Measure:


- Big end side clearance (C)

Use a thickness gauge.

Out of specification → Replace.



Big end side clearance:
0.25 - 0.75 mm
(0.010 - 0.030 in)



4. Measure:


- Small end free play (D)

Use a dial gauge.

Out of specification → Replace.



Small end free play:
2.0 mm (0.08 in)



5. Inspect:

- Crankshaft bearing

Pitting/Damage → Replace.

NOTE:

Lubricate the bearings immediately after examining them to prevent rusting.


6. Inspect:

- Crankshaft oil seal
Wear/Damage → Replace.

Crankcase inspection**1. Inspect:**





- Contacting surface
Scratch → Replace.
- Crankcase
Crack/Damage → Replace.

**INTERMEDIATE SHAFT AND HOUSING
EXPLODED DIAGRAM**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	INTERMEDIATE SHAFT AND HOUSING REMOVAL Engine unit		Follow the left "Step" for removal. Refer to the "ENGINE UNIT REMOVAL" section.
1	Coupling rubber	1	
2	Bolt (with washer)	3	
3	Bearing housing assembly	1	
4	Pin	2	
5	Bolt (with washer)	3	
6	Shim	*	
7	Housing	1	
8	Rubber seal	1	
9	O-ring	1	
	HOUSING DISASSEMBLY		
①	Hose tie	1	
②	Grease hose	1	
③	Coupling	1	
④	Washer	1	
⑤	Oil seal	1	NOTE: Fill the with water resistant grease clip inner circumference before installing the oil seal.
			 Distance ②: 1.6 - 2.0 mm (0.06 - 0.08 in)
⑥	Spacer	1	
⑦	Shaft	1	
			 Distance ①: WVT700 14.5 - 15.5 mm (0.57 - 0.61 in) WVT1100 9.5 - 10.5 mm (0.37 - 0.41 in)
⑧	Oil seal	1	NOTE: Fill the with water resistant grease clip inner circumference before installing the oil seal.
			 Distance ③: 6.6 - 7.2 mm (0.27 - 0.28 in)
⑨	Clip	1	
⑩	Bearing	1	
			 Distance ④: 17.6 - 17.7 mm (0.69 - 0.70 in)
⑪	Clip	1	
⑫	O-ring	2	
⑬	Housing	1	
			Reverse the removal steps for installation.


*: As required

**SERVICE POINTS****Coupling removal and installation**

1. Remove and install:
 - Coupling




Coupler wrench:
 YW-38741/90890-06425
 WVT1100.
 YW-06546/90890-06546
Shaft holder:
 YW-38742/90890-06089

**Bearing removal and installation**

1. Remove and install.
 - Bearing



Driver rod:
 YB-06071/90890-06606
Bearing outer race attachment:
 YB-06016/90890-06626

**Bearing inspection**

1. Inspect.
 - Bearing
 - Rotate inner race by hand.
 - Rough spots/Seizure → Replace.
 - Shaft
 - Pitting/Damage → Replace.
 - Hose
 - Wear/Cracks → Replace.

Coupling inspection


1. Inspect:
 - Coupling flange
 - Coupling rubber
 - Wear/Damage → Replace.

Oil seal installation

1. Install:
 - Oil seal [T = 10 mm (0.39 in)]



Driver rod:
 YB-06071/90890-06606
Bearing outer race attachment:
 YB-06016/90890-06626


**NOTE:**


Install the oil seal with the manufacturer's numbers facing outward.

CHAPTER 6 JET PUMP UNIT

JET PUMP UNIT REMOVAL	6-1
EXPLODED DIAGRAM	6-1
REMOVAL AND INSTALLATION CHART	6-2
NOZZLE DEFLECTOR AND REVERSE GATE	6-3
EXPLODED DIAGRAM	6-3
REMOVAL AND INSTALLATION CHART	6-4
NOZZLE, DUCT AND INTAKE	6-5
EXPLODED DIAGRAM	6-5
REMOVAL AND INSTALLATION CHART	6-6
SERVICE POINTS	6-7
Oil seal and bushing removal	6-7
Housing inspection	6-7
Seal rubber inspection	6-7
Bushings and oil seal installation	6-7
IMPELLER AND DRIVE SHAFT	6-8
EXPLODED DIAGRAM	6-8
REMOVAL AND INSTALLATION CHART	6-9
SERVICE POINTS	6-10
Impeller removal	6-10
Drive shaft and bearing removal	6-10
Impeller inspection	6-10
Drive shaft inspection	6-10
Bearing inspection	6-10
Oil seal and bearing installation	6-11
Impeller installation	6-11
COOLING AND BILGE SYSTEM	6-12
EXPLODED DIAGRAM (WVT 700)	6-12
REMOVAL AND INSTALLATION CHART	6-13
SERVICE POINTS	6-13
Bilge strainer inspection	6-13
Hose inspection	6-13
EXPLODED DIAGRAM (WVT 100)	6-14
REMOVAL AND INSTALLATION CHART	6-15
SERVICE POINTS	6-15
Bilge strainer inspection	6-15
Hose inspection	6-15

**JET PUMP UNIT REMOVAL
EXPLODED DIAGRAM**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
JET PUMP UNIT REMOVAL			Follow the left "Step" for removal.
1	Screw	4	
2	Speed sensor cover	1	
3	Speed sensor	1	
4	Bolt (with washer)	2	
5	Valve body assembly	1	
6	Bolt (with washer)	6	
7	Ride plate	1	
8	Clamp	1	
9	Strainer	1	
10	Hose tie	1	
11	Shift cable joint	1	
12	Steering cable joint	1	
13	Hose tie	1	
14	Spout hose	1	
15	Clamp	1	
16	Engine cooling hose	1	
17	Bolt (with washer)	2	
18	Bolt (with washer)	4	
19	Jet pump unit	1	
			NOTE:
			● Pull the jet pump unit straight back ward.
			● When installing the jet pump unit, align the drive shaft spline (male) with the intermediate shaft spline (female).
20	Bolt (with washer)	12	
21	Ride plate nut	6	
			Reverse the removal steps for installation.

*: As required



**NOZZLE DEFLECTOR AND REVERSE GATE
EXPLODED DIAGRAM**






REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	NOZZLE DEFLECTOR AND REVERSE GATE REMOVAL		Follow the left "Step" for removal.
	Jet pump unit		Refer to the "JET PUMP UNIT REMOVAL" section.
1	Bolt (with washer)	2	
2	Collar	2	
3	Nozzle deflector assembly	1	
	NOZZLE DEFLECTOR DISASSEMBLY		
①	Spring	2	
②	Bolt (with washer)	2	8 × 25 mm
③	Collar	2	
④	Pin bolt	2	
⑤	Plane washer	2	
⑥	Collar	2	
⑦	Plate	2	
⑧	Pin bolt	2	
⑨	Collar	2	
⑩	Shift lever	1	
⑪	Bolt (with washer)	2	8 × 25 mm
⑫	Collar	2	
⑬	Reverse gate	1	
⑭	Ball joint	1	
⑮	Bolt (with washer)	2	6 × 12 mm
⑯	Collar	2	
⑰	Lever	1	
⑱	Nut	1	M5
⑲	Plane washer	2	
⑳	Ball joint	1	M5
㉑	Nozzle deflector	1	
			Reverse the removal steps for installation.

NOZZLE, DUCT AND INTAKE
EXPLODED DIAGRAM

TUYERE, CONDUITE ET ADMISSION
VUE EN ECLATE





REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	NOZZLE, DUCT AND INTAKE DISASSEMBLY		Follow the left "Step" for removal.
	Jet pump unit		Refer to the "JET PUMP UNIT REMOVAL" section.
	Reverse gate assembly		Refer to the "REVERSE GATE" section.
1	Bolt	4	
2	Intake duct	1	
3	Pin	2	
4	Housing	1	
5	Pin	2	
6	Impeller duct assembly	1	
7	Pin	2	
8	Nozzle	1	
9	Bolt (with washer)	1	
10	Spacer	1	
11	Oil seal	2	
12	Bushing	1	
13	Bolt (with washer)	6	
14	Intake screen	1	
			Reverse the removal steps for installation.

TABLEAU DE DEPOSE ET D'INSTALLATION

Etape	Procédé/nom de pièce	Qté	Remarques particulières d'entretien
	DEMONTAGE DE LA TUYERE, DE LA CONDUITE ET DE L'ADMISSION		Suivre "l'étape" de gauche pour la dépose.
	Pompe de propulsion		Voir la section "DEPOSE DE LA POMPE DE PROPULSION"
	Ensemble d'efflecteur d'eau de marche arrière		Se référer à la section "DEFLECTEUR D'EAU DE MARCHE ARRIERE".
1	Conduite d'admission	4	
2	Tuyère d'admission	1	
3	Goupille	2	
4	Logement	1	
5	Goupille	2	
6	Ensemble de tuyère de turbine	1	
7	Goupille	2	
8	Tuyère	1	
9	Boulon (avec rondelle)	1	
10	Rondelle	1	
11	Bague d'étanchéité	2	
12	Douille	1	
13	Boulon (avec rondelle)	6	
14	Critile d'admission	1	
			Pour l'installation, inverser les étapes de la dépose.




SERVICE POINTS

Oil seal and bushing removal

1. Remove:
 - Oil seal ①
 - Bushing ②



Driver rod:
 YB-06229/90890-06605
Ball bearing attachment:
 YB-06021/90890-06638



Housing inspection


1. Inspect:
 - Housing inner surface
 Wear/Damage → Replace.

Seal rubber inspection


1. Inspect:
 - Seal rubber
 Crack/Wear → Replace.

Bushing and oil seal installation

1. Install:
 - Bushing




Driver rod:
 YB-06229/90890-06605
Needle bearing attachment:
 YB-06349/90890-06613




2. Install:
 - Oil seal




Driver rod:
 YB-06229/90890-06605
Needle bearing attachment:
 YB-06349/90890-06613



**IMPELLER AND DRIVE SHAFT
EXPLODED DIAGRAM**






SERVICE POINTS

Impeller removal

1. Remove:
 - Impeller



Drive shaft holder
YB-06049/90890-06518




Drive shaft and bearing removal

1. Remove:
 - Drive shaft and bearing (rear) ①
 - Bearing (rear) ②

NOTE: _____

Use a press.



2. Remove:
 - Bearing (front)



Slide hammer set:
90890-06523
YB-06096/90890-06531

Impeller inspection

Refer to the "JET PUMP UNIT" section in chapter 3.

Drive shaft Inspection


1. Inspect:
 - Drive shaft

Wear/Damage → Replace.

Bearing Inspection

1. Inspect:
 - Bearing (front and rear)

Rotate inner race by hand.
Rough spot/Seizure → Replace.




Oil seal and bearing installation

1. Install:
 - Oil seal



Driver rod:
YB-06071/90890-06606
Ball bearing attachment:
YB-06156/90890-06634



2. Install:
 - Bearing (front)
 - Drive shaft and bearing


NOTE: _____

Use a press.

3. Fill:
 - Between the drive shaft and duct



Water resistant grease:
24 cm³ (1.45 cu. in)



4. Install:
 - Bearing (rear)




Bearing inner race attachment:
YB-34474/90890-06662

5. Fill:
 - Into the cap



Water resistant grease:
21 cm³ (1.3 cu. in)




Impeller installation


1. Install:
 - Impeller



Drive shaft holder:
YB-06049/90890-06518



**COOLING AND BILGE SYSTEM
EXPLODED DIAGRAM (WVT700)**




REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	COOLING AND BILGE SYSTEM REMOVAL		Follow the left "Step" for removal.
	Jet pump unit		Refer to the "JET PUMP UNIT REMOVAL" section.
1	Clamp	1	
2	Water inlet hose	1	
3	Connection nut	1	
4	Packing	2	
5	Connection bolt	1	
6	Tapping screw	1	
7	Strainer bracket	1	
8	Hose tie	1	
9	Bilge strainer	1	
10	Clamp	1	
11	Hose tie	2	
12	Bilge hose	1	
13	Hose joint	1	
14	Hose tie	1	
15	Bilge hose	1	
16	Connection nut	1	
17	Packing	2	
18	Connection bolt	1	
19	Hose tie	1	
20	Hose	1	
21	Clamp	2	
22	Presser hose	1	
23	Selection hose	1	
24	Valve body	1	
			Reverse the removal steps for installation.

SERVICE POINTS
Bilge strainer inspection


Refer to the "BILGE SYSTEM" section
in chapter 3.


Hose inspection
1. Inspect:

- Hose

Crack/Wear/Damage → Replace.

EXPLODED DIAGRAM (WVT1100)




REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	COOLING AND BILGE SYSTEM REMOVAL		Follow the left "Step" for removal.
	Jet pump unit		Refer to the "JET PUMP UNIT REMOVAL" section.
1	Clamp	1	
2	Water inlet hose	1	
3	Connection nut	1	
4	Packing	2	
5	Connection bolt	1	
6	Tapping screw	1	
7	Strainer bracket	1	
8	Hose tie	1	
9	Bilge strainer	1	
10	Clamp	1	
11	Hose tie	2	
12	Bilge hose	1	
13	Hose joint	1	
14	Hose tie	1	
15	Bilge hose	1	
16	Connection nut	1	
17	Packing	2	
18	Connection bolt	1	
	HOSE JOINT DISASSEMBLY		WVT1100
①	Joint bolt	1	
②	O-ring	1	
③	Valve	1	
④	Joint body	1	
			Reverse the removal steps for installation.


SERVICE POINTS
Bilge strainer inspection

Refer to the "BILGE SYSTEM" section
in chapter 3.

Hose inspection
1. Inspect:

- Hose


Crack/Wear/Damage → Replace.



CHAPTER 7 ELECTRICAL SYSTEM


ELECTRICAL COMPONENTS	7-1
WVT700	7-1
WVT1100	7-2
ELECTRICAL UNIT	7-3
WVT1100	7-3
ELECTRICAL ANALYSIS	7-5
INSPECTION	7-5
Low resistance measurement	7-5
IGNITION SYSTEM	7-6
WIRING DIAGRAM	7-6
WVT700	7-6
WVT1100	7-7
IGNITION SPARK GAP	7-8
SPARK PLUG	7-9
SPARK PLUG CAP	7-9
IGNITION COIL	7-9
ENGINE STOP SWITCH	7-10
CHARGE COIL	7-10
PULSER COIL	7-11
THERMO SWITCH	7-11
CDI UNIT	7-12
STARTING SYSTEM	7-13
WIRING DIAGRAM	7-13
BATTERY	7-14
WIRING CONNECTION	7-14
FUSE	7-14
STARTER SWITCH	7-14
STARTER RELAY	7-14
STARTER MOTOR	7-15
EXPLODED DIAGRAM	7-15
REMOVAL AND INSTALLATION CHART	7-16
SERVICE POINTS	7-17
Pinion inspection	7-17
Armature inspection	7-17
Brush holder inspection	7-18
Cover inspection	7-18

CHARGING SYSTEM	7-19
WIRING DIAGRAM	7-19
FUSE	7-20
BATTERY	7-20
LIGHTING COIL	7-20
RECTIFIER REGULATOR	7-20
INDICATION SYSTEM	7-21
WIRING DIAGRAM	7-21
OIL LEVEL SENSOR	7-22
FUEL LEVEL SENSOR	7-22
MULTI FUNCTION METER	7-23
FUSE	7-25
BATTERY	7-25
LIGHTING COIL	7-25
RECTIFIER REGULATOR	7-25



ELECTRICAL COMPONENTS

WVT700




- ① Throttle cable
- ② Fuel level sensor lead
- ③ Oil level sensor lead
- ④ Battery (positive) lead
- ⑤ Battery (negative) lead
- ⑥ Speed sensor lead
- ⑦ Flywheel magneto base lead
- ⑧ Handle switch lead
- ⑨ Thermo sensor lead
- ⑩ Starter motor (positive) lead

- ⊙ High tension cord
- ⊙ Pilot water hose
- ⊙ Ventilation hose
- Ⓐ 2P connector (Black)
- Ⓑ 2P connector (White)
- Ⓒ 3P connector (White)
- Ⓓ 4P connector (White)
- Ⓔ 2P connector (Green)
- Ⓛ 2P connector (White)



WVT1100




- ① Throttle cable
- ② Fuel level sensor lead
- ③ Oil level sensor lead
- ④ Battery (positive) lead
- ⑤ Battery (negative) lead
- ⑥ Speed sensor lead
- ⑦ Flywheel magneto base lead
- ⑧ Handle switch lead
- ⑨ Thermo sensor lead
- ⑩ Starter motor (positive) lead

- ⑪ High tension cord
- ⑫ Pilot water hose
- ⑬ Ventilation hose
- A: 2P connector (Black)
- B: 2P connector (White)
- C: 3P connector (White)
- D: 4P connector (White)
- E: 2P connector (Green)
- F: 2P connector (White)




ELECTRICAL UNIT

WVT1100



- ① Thermo switch
- ② Handle switch and meter
- ③ Battery (positive)
- ④ Starter motor (positive)

- B: Black
- Br: Brown
- G: Green
- P: Pink
- R: Red
- W: White



- ① Rectifier-regulator ground
- ② Ignition coil #3 ground
- ③ Handle switch and meter ground
- ④ CDI ground

- ⑤ Thermo switch ground
- ⑥ Ignition coil #2 ground
- ⑦ Ignition coil #1 ground
- ⑧ Starter relay ground
- ⑨ CDI unit



ELECTRICAL ANALYSIS INSPECTION

CAUTION

All measuring instruments should be handled with special care, or correct measurement is impossible.

On an instrument powered by dry batteries, the batteries' voltage should be checked periodically and the batteries replaced, if necessary.

NOTE:

"○ · ○" indicates the terminals between which there is electrical continuity; i.e., a closed circuit in the given switch position.

Low resistance measurement

When measuring resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.


To obtain the correct value, subtract this internal resistance from the displayed measurement.




**Correct value =
Displayed measurement –
Internal resistance**

NOTE:

The internal resistance of the tester can be obtained by connecting both of its terminals.




IGNITION SYSTEM WIRING DIAGRAM WVT700




- ① Pulser coil
- ② Charge coil
- ③ CDI unit
- ④ Stop switch
- ⑤ Engine stop switch
- ⑥ Thermo switch
- ⑦ Ignition coil

- B : Black
- Br/W: Brown/White
- O : Orange
- P : Pink
- W : White
- W/R : White/Red








WVT1100



- ① Ignition coil
- ② Thermo switch
- ③ Stop switch
- ④ Engine stop switch
- ⑤ Pulser coil
- ⑥ Charge coil
- ⑦ CDI unit

- B : Black
- B/O : Black/Orange
- B/R : Black/Red
- B/W : Black/White
- B/Y : Black/Yellow
- Br : Brown
- L : Blue
- P : Pink
- W : White
- W/B : White/Black
- W/G : White/Green
- W/R : White/Red



IGNITION SPARK GAP

⚠ WARNING

- While making a spark check be careful not to touch any of the "Ignition spark gap tester" lead wires.
- When doing the spark test, take special care not to allow leakage from the removed plug cap.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.

1. Check:

- Ignition spark gap
Out of specification → Replace.



Spark gap:
9 mm (0.35 in)

Checking steps:

- Adjust the spark gap to specification by turning the adjusting knob.



Spark gap tester:
YM-34487/90890-06754

- Connect the spark plug cap to the spark gap tester.
- Remove the spark plugs from the engine.
- Crank the engine and check the sparks from the ignition system through the discharge window

**SPARK PLUG**

Refer to the "GENERAL" section in CHAPTER 3




SPARK PLUG CAP

1. Inspect:

- Spark plug cap
Loosen → Tighten.
Crack/Damage → Replace.

2. Measure: (For WVT1100)

- Spark plug cap resistance
Out of specification → Replace.

**Replacement steps: (For WVT1100)**

- Remove the spark plug cap by turning the cap counterclockwise.
- Install the spark plug cap by turning the cap clockwise until it stops.




IGNITION COIL

1. Inspect:


- High tension cord
Cracks/Damage → Replace.

2. Measure:

- Primary coil resistance
Out of specification → Replace.

**NOTE:**

When measuring the resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained. Refer to "Lower resistance measurement".



3. Measure:

- Secondary coil resistance
Out of specification → Replace.

**Secondary coil resistance:**

WVT700


High tension cords

14.3 ~ 30.5 k Ω at 20°C (68°F)

WVT1100

Black/White (B/W) - High
tension cord2.7 ~ 4.1 k Ω at 20°C (68°F)**NOTE:**

Remove the spark plug cap from the high tension cord.

**ENGINE STOP SWITCH**

1. Check:

- Continuity
Out of specification → Replace.


**Engine stop continuity:
(Black coupler)**

Lock plate	Position	Leads	
		White	Black
Installed	Free		
	Push	○—○	○—○
Removed	Free	○—○	○—○
	Push	○—○	○—○

CHARGE COIL

1. Measure:

- Charge coil resistance
Out of specification → Replace.

**Charge coil resistance:**

WVT700

Brown/White (Br/W) - Black (B)

497.7 ~ 608.3 Ω at 20°C (68°F)


WVT1100

Black/Red (B/R) - Brown (Br)

172 ~ 258 Ω at 20°C (68°F)

Blue (L) - Black/Red (B/R)

656 ~ 984 Ω at 20°C (68°F)

**PULSER COIL**

1. Measure:

- Pulser coil resistance
- Out of specification → Replace.

**Pulser coil resistance:****WVT700**



White/Red (W/R) – Black (B)

12.6 ~ 15.4 Ω at 20°C (68°F)**WVT1100**

White/Red (W/R) – Black (B)

White/Black (W/B) – Black (B)

White/Green (W/G) – Black (B)

248 ~ 372 Ω at 20°C (68°F)**THERMO SWITCH**

1. Measure:

- Thermo switch continuity
- Out of specification → Replace.

**Thermo switch continuity temperature:****WVT700**

Pink (P) – Black (B)

Ⓐ 66 ~ 74°C (100.4 ~ 125.6°F)

Ⓑ 57 ~ 43°C (93.2 ~ 78.8°F)

WVT1100

Pink (P) – Black (B)

Ⓐ 90 ~ 98°C (194 ~ 204.8°F)

Ⓑ 90 ~ 76°C (194 ~ 168.8°F)

Ⓐ Discontinuity

Ⓑ Continuity

Ⓒ Discontinuity

Ⓐ Temperature

Ⓑ Time

Measurement steps:

- Suspend thermostat in a vessel.
- Place known reliable thermometer in water.
- Heat water slowly.
- Observe thermometer, while stirring water continually.



CDI UNIT

1. Measure:

- CDI unit resistance
- Out of specification → Replace.



Pocket tester:
YU-03112/90890-03112

NOTE:

- The resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, the polarity of the leads is reversed.
- The needle swings once to the “*” mark and then returns to the home position.
- The “∞” mark stands for discontinuity.

62T00 WVT700 Unit: kΩ

⊕ ⊖	B	Br/W	D	P	W	W/R
B	∞	2-6	∞	3-11	10-40	150-600
Br/W	20-80	∞	∞	50-200	15-60	500
O	∞	∞	∞	∞	∞	∞
P	∞	∞	∞	∞	∞	∞
W	∞	∞	∞	∞	∞	∞
W/R	9-36	17-70	∞	10-40	50-200	∞


63M00 WVT1100 Unit: kΩ

⊕ ⊖	B	B/O	B/R	B/W	B/Y	Br	L	P	W	W/B	W/G	W/R
B	∞	280-420	14.4-21.6	280-420	280-420	∞	2.9-4.3	280-420	280-420	60-90	60-90	60-90
B/O	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
B/R	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
B/W	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
B/Y	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
Br	76-114	120-180	200-300	120-180	120-180	∞	144-216	120-180	120-180	184-276	184-276	184-276
L	19.2-28.8	48-72	240-360	48-72	48-72	∞	∞	56.0-84.0	45.6-68.4	168-252	168-252	168-252
P	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
W	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞	∞
W/B	200-300	280-420	400-600	280-420	280-420	∞	280-420	280-420	280-420	∞	320-480	320-480
W/G	200-300	280-420	400-600	280-420	280-420	∞	280-420	280-420	280-420	320-480	∞	320-480
W/R	200-300	280-420	400-600	280-420	280-420	∞	280-420	280-420	280-420	320-480	320-480	∞

- B : Black
- B/O : Black/Orange
- B/R : Black/Red
- B/W : Black/White
- B/Y : Black/Yellow
- Br : Brown
- Br/W : Brown/White
- O : Orange
- L : Blue
- P : Pink
- W : White
- W/B : White/Black
- W/G : White/Green
- W/R : White/Red



**STARTING SYSTEM
WIRING DIAGRAM**



- ① Fuse
- ② Engine stop switch
- ③ Starter switch
- ④ Battery
- ⑤ Starter motor
- ⑥ Starter relay

- B : Black
- B_r : Brown
- R : Red

**BATTERY**

Refer to the "GENERAL" section in chapter 3.

WIRING CONNECTION

- Check:
 - Wiring connection
 - Poor connection → Correct.

FUSE


- Check:
 - Fuse
 - Blown → Replace.



Fuse rating:
12 V/10 A

STARTER SWITCH

- Check:
 - Continuity
 - Out of specification → Replace.




Starter continuity:
(White coupler)

Lock plate	Position	Leads	
		Red	Brown
Installed	Free		
	Push	○	○
Removed	Free		
	Push		

STARTER RELAY



- Inspect:
 - Brown lead terminal
 - Black lead terminal
 - Loose → Tighten
- Check:
 - Relay operation
 - Does not function → Replace

**Checking steps:**

- Connect the tester between the terminals of the starter relay as shown.
- Connect a 12 V battery.

Brown lead ① → Positive terminal
Black lead ② → Negative terminal


- Check that there is continuity between the starter relay terminals.

**STARTER MOTOR
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	STARTER MOTOR DISASSEMBLY		Follow the left "Step" for removal.
	Starter motor assembly		Refer to the "CRACKCASE AND CRANK-SHAFT" section in chapter 5.
1	O-ring	1	
2	Through bolt	2	
3	Front bracket	1	
4	Thrust supporter	1	
5	Insulator washer	1	
6	Washer	1	0.2 mm
7	Washer	1	0.5 mm
8	Armature assembly	1	
9	Washer	2	0.2 mm
10	Washer	1	0.8 mm
11	Rear bracket	1	
12	Nut	1	
13	Spring washer	1	
14	Plate washer	1	
15	Insulator washer	1	
16	Insulator washer	2	
17	O-ring	1	
18	Bolt	1	
19	Terminal insulator	1	
20	Brush holder	1	
21	Plate cover	1	
22	York assembly	1	
23	Packing	2	
			Reverse the removal steps for installation.

**SERVICE POINTS****Pinion inspection**

1. Inspect:
 - Pinion teeth ①
 - Wear/Damage → Replace.

**Armature inspection**


1. Inspect:
 - Commutator
 - Dirty → Clean with #600 abrasive paper.



2. Measure:
 - Commutator diameter
 - Out of specification → Replace.




Commutator diameter:
Limit 27 mm (1.06 in)



3. Check:
 - Commutator undercut
 - Clog/Dirt → Clean

NOTE:


Remove all particles of mica and metal using compressed air.



4. Measure:
 - Commutator undercut
 - Out of specification → Replace.





Commutator undercut:
Limit 0.2 mm (0.01 in)



5. Inspect:

- Armature coil continuity
Out of specification → Replace.


 Armature coil continuity:	
Commutator segments ①	Continuity
Segment - Laminations ②	Discontinuity
Segment - Shaft	Discontinuity




Brush holder inspection

1. Measure:


- Brush length ②
Out of specification → Replace.


 Brush length:
Limit 5.0 mm (0.20 in)
WVT1100:
Limit 6.5 mm (0.26 in)



2. Check:

- Brush holder continuity
Out of specification → Replace.


 Brush holder continuity:	
Brush holder - Base	Discontinuity



Cover inspection

1. Inspect:


- Cover bushing
Wear/Damage → Replace the cover.

**FUSE**

Refer to the "STARTING SYSTEM" section.

BATTERY

Refer to the "ELECTRICAL" section in chapter 3.

**LIGHTING COIL**

1. Measure:

- Lighting coil resistance
Out of specification → Replace.



Lighting coil resistance:

WVT700

Green (G) – Green (G)

1.14 ~ 1.40 Ω at 20°C (68°F)

WVT100

Green (G) – Green (G)

0.56 ~ 0.84 Ω at 20°C (68°F)

NOTE:

When measuring the resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained. Refer to "Lower resistance measurement".

RECTIFIER REGULATOR

1. Check:

- Continuity
Out of specification → Replace



Pocket tester:

YU-03112/90890-03112


∞: Discontinuity

Unit: kΩ

⊖	⊕	R	B	G	G
R			∞	∞	∞
B		2~20		1~10	1~10
G		1~10	2~15		3~30
G		1~10	2~15	3~30	




INDICATION SYSTEM WIRING DIAGRAM



- ① Thermo switch
- ② Oil level sensor
- ③ Fuel level sensor
- ④ Multi function meter
- ⑤ Speed sensor (Except for WWT700)
- ⑥ Battery
- ⑦ Fuse
- ⑧ Lighting coil
- ⑨ Rectifier regulator



- B : Black
- G : Green
- L : Blue
- P : Pink
- R : Red
- R/W : Red/White
- W/L : White/Blue
- Y : Yellow




OIL LEVEL SENSOR

1. Measure:
- Oil level sensor resistance
 - Out of specification → Replace.

- ① Blue lead → Positive terminal.
 ② Black lead → Negative terminal.



	Float position	Resistance (Ω)
③, ④	:ON	0 ~ 2
③ ④	:OFF :ON	97 ~ 103
③, ④	:OFF	292 ~ 308
	Float distance: ②: 2 ~ 6 mm (0.08 ~ 0.24 in) ③: 37 ~ 41 mm (1.46 ~ 1.61 in)	








FUEL LEVEL SENSOR

1. Measure:
- Fuel level sensor resistance
 - Out of specification → Replace.

- ① White/Blue lead → Positive terminal.
 ② Black lead → Negative terminal.

	Float position	Resistance (Ω)
③, ④, ⑤	:ON	0 ~ 2
③ ④, ⑤	:OFF :ON	97 ~ 103
③, ④ ⑤	:OFF :ON	292 ~ 308
③, ④, ⑤	:OFF	667 ~ 713
	Float distance: ②: 91 ~ 96 mm (3.58 ~ 3.78 in) ③: 175 ~ 180 mm (6.89 ~ 7.09 in) ④: 260 ~ 283 mm (10.24 ~ 10.35 in)	



MULTI FUNCTION METER

1. Check:

- Display function
Not working → Replace.

Checking steps:

- Connect the battery.



Voltage range:
10 - 16 V

- ① Red lead → Positive terminal.
- ② Green lead → Positive terminal.
- ③ Black lead → Negative terminal.

- After the battery is connected all segments light up for 2 seconds.
- Disconnect the green lead.
- After the lead is disconnected, the fuel meter only will continue to operate for 30 seconds, and all the other segments will disappear.

2. Check:

- Overheat segment:
Not working → Replace.

Checking steps:

- Connect the battery.

- ① Red lead → Positive terminal.
- ② Green lead → Positive terminal.
- ③ Black lead → Negative terminal.

- Connect the pink and black terminals and check that the overheat segment starts blinking.

3. Check:


- Fuel meter
Not working → Replace.

Checking steps:

- Connect the battery.

- ① Red lead → Positive terminal.
- ② Green lead → Positive terminal.
- ③ Black lead → Negative terminal.

- Connect the fuel level sensor.

**NOTE:**

The fuel meter should be checked properly before checking the fuel level sensor resistance.

- Slide the float of fuel level sensor.
- Check the fuel meter and warning segments.




Float position

Display

①, ②, ③ :ON	F0, F1, F2, F3: ON
① :OFF ②, ③ :ON	F0, F1, F2: ON
①, ② :OFF ③ :ON	F0, F1: ON
①, ②, ③ :OFF	F0, F-AL: Blinking

NOTE:

The fuel meter display remains unchanged for 20 seconds after the float is slid.



4. Check:

- Oil meter
- Not working → Replace.

Checking steps:

- Connect the battery.



- ① Red lead → Positive terminal.
- ② Green lead → Positive terminal.
- ③ Black lead → Negative terminal.


- Connect the oil sensor.

NOTE:

The oil meter should be checked properly before checking the oil level sensor resistance.

- Slide the float of oil sensor.
- Check the oil meter and warning segments.



	Float position	Display
①, ②	:ON	00, 01, 02: ON
①	:OFF	00, 01: ON
②	:ON	00, 01: ON
①, ②	:OFF	00, 0-AL: Blinking

NOTE:
The oil meter display remains unchanged for 20 seconds after the float is slid.

- Connect the blue and black terminals and check that the oil warning segment stops blinking.

FUSE

Refer to the "STARTING SYSTEM" section.

BATTERY

Refer to the "CHARGING SYSTEM" section.

LIGHTING COIL

Refer to the "CHARGING SYSTEM" section.

RECTIFIER REGULATOR


Refer to the "CHARGING SYSTEM" section.

CHAPTER 8 HULL AND HOOD

ENGINE HOOD REMOVAL	8-1
EXPLODED DIAGRAM	8-1
REMOVAL AND INSTALLATION CHART.....	8-2
HANDLE	8-3
EXPLODED DIAGRAM	8-3
REMOVAL AND INSTALLATION CHART.....	8-4
SERVICE POINTS	8-4
Handle inspection.....	8-4
HANDLE COLUMN	8-5
EXPLODED DIAGRAM	8-5
REMOVAL AND INSTALLATION CHART.....	8-6
SERVICE POINTS	8-6
Handle column inspection.....	8-6
Bearing inspection.....	8-6
SHIFT LEVER	8-7
EXPLODED DIAGRAM	8-7
REMOVAL AND INSTALLATION CHART.....	8-8
SERVICE POINTS	8-8
Bushing inspection.....	8-8
ENGINE HOOD	8-9
EXPLODED DIAGRAM	8-9
REMOVAL AND INSTALLATION CHART.....	8-10
STEERING CABLE	8-11
EXPLODED DIAGRAM	8-11
REMOVAL AND INSTALLATION CHART.....	8-12
SERVICE POINTS	8-12
Cable inspection.....	8-12
THROTTLE CABLE AND CHOKE CABLE	8-13
EXPLODED DIAGRAM	8-13
REMOVAL AND INSTALLATION CHART.....	8-14
SERVICE POINTS	8-14
Cable inspection.....	8-14
SHIFT CABLE	8-15
EXPLODED DIAGRAM	8-15
REMOVAL AND INSTALLATION CHART.....	8-16
SERVICE POINTS	8-16
Cable inspection.....	8-16


SEAT, STORAGE BOX AND BATTERY CASE	8-17
EXPLODED DIAGRAM	8-17
REMOVAL AND INSTALLATION CHART.....	8-18
SERVICE POINTS	8-18
Seat inspection	8-18
Storage box inspection	8-18
EXHAUST SYSTEM	8-19
EXPLODED DIAGRAM	8-19
REMOVAL AND INSTALLATION CHART.....	8-20
SERVICE POINTS	8-20
Exhaust system inspection.....	8-20
DECK	8-21
EXPLODED DIAGRAM	8-21
REMOVAL AND INSTALLATION CHART.....	8-22
GUNWALE AND MAT	8-23
EXPLODED DIAGRAM	8-23
REMOVAL AND INSTALLATION CHART.....	8-24
SERVICE POINTS	8-24
Gunwale and mat inspection.....	8-24
HULL	8-25
EXPLODED DIAGRAM	8-25
REMOVAL AND INSTALLATION CHART.....	8-26
HULL REPAIR	8-26
Light scratching	8-26
Deep scratching	8-26
Hull damage (punctured)	8-27
Insert nut	8-28
Removing a graphic	8-30
Applying a graphic	8-30

**ENGINE HOOD REMOVAL
EXPLODED DIAGRAM**




REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	ENGINE HOOD REMOVAL		Follow the left "Step" for removal.
	Fuel cock assembly		Refer to the "FUEL COCK AND FUEL FILTER" section in chapter 4.
1	Spiral tube	1	
2	Band	1	NOTE: _____ Clamp the handle switch leads and meter leads with the band.
3	Band	1	NOTE: _____ Clamp the meter breather hose and ventilation hose with the band.
4	Handle switch lead coupler	2	
5	Speed sensor lead coupler	1	
6	Oil sensor lead coupler	1	
7	Fuel sender lead coupler	1	
8	Meter lead coupler	1	
9	Cable joint (steering cable)	1	
10	Nylon nut	3	
11	Plane washer	3	
12	Steering cable bracket	1	
13	Cable joint (shift cable)	1	
14	Nylon nut	2	
15	Plane washer	2	
16	Shift cable bracket	1	
17	Throttle cable	1	NOTE: _____
18	Choke cable	1	Disconnect the cables from the carburetor.
19	Oil breather hose	1	
20	Clamp	1	
21	Oil filler hose	1	
22	Clamp	1	
23	Fuel filler hose	1	
24	Nylon nut	4	
25	Plane washer	4	
26	Bolt (with washer)	2	8 × 30 mm
27	Bolt (with washer)	2	
28	Plane washer	2	3.4 × 25 mm
29	Engine hood assembly	1	
30	Packing	1	NOTE: _____ Mate packing ends (a) at center line rear and apply instantaneous adhesive.
			Reverse the removal steps for installation.



**HANDLE
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	HANDLE REMOVAL		Follow the left "Step" for removal.
1	Screw	4	5 × 16 mm
2	Screw	4	4 × 8 mm
3	Steering pad	1	
4	Throttle cable	1	NOTE: _____ Disconnect the throttle cable from the throttle lever.
5	Screw	2	NOTE: _____ Tighten the screw at the stop button side first.
6	Handle switch assembly	1	
7	Bolt (with washer)	4	8 × 55 mm NOTE: _____ When tightening the bolt, clearance ③ should be narrower than clearance ④.
8	Handlebar holder (upper)	2	NOTE: _____
9	Handlebar holder (lower)	2	A-type ● Position the punched mark ⑤ just between the upper holders and vertically from the steering column. B-type ■ Align the punched mark ⑥ on the handlebar with the top surface of the handlebar holder (lower).
10	Handlebar assembly	1	
	HANDLEBAR DISASSEMBLY		
①	Screw	2	
②	Plane washer	2	
③	Handle grip	2	NOTE: _____ Apply adhesive to the handlebar and the inner surface of the grip.
④	Spacer	2	
⑤	Screw	1	
⑥	Throttle lever assembly	1	
⑦	Handlebar	1	
			Reverse the removal steps for installation.

SERVICE POINTS
Handle inspection
1. Inspect:

- Handlebar

Bend/Crack/Damage → Replace.

**HANDLE COLUMN
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	HANDLE COLUMN REMOVAL		Follow the left "Step" for removal. Refer to the "HANDLE" section.
	Handlebar assembly		
1	Steering cable	1	
2	Throttle cable	1	
3	Handle switch lead	2	
4	Seal packing	1	NOTE: ● Adjust the throttle cable length (a) and handle switch lead length (b) to 200 mm (7.9 in). ● Seal the steering shaft with the seal packing at a point 20 mm (0.79 in) from the end of the steering column.
5	Bolt (with washer)	2	NOTE: Check for smooth action of the handle column when tightening the bolt.
6	Bushing joint	1	
7	Bushing	2	
8	Clamp	1	
9	Nut	4	
10	Flange washer	4	
11	Bolt	4	
12	Column bushing	2	
13	Handle column	1	
14	Seal rubber	1	
15	Nut	1	
16	Ball joint	1	
			Reverse the removal steps for installation

SERVICE POINTS
Handle column inspection

1. Inspect:

- Handle column

Bend/Crack/Damage → Replace.

Bearing inspection


1. Inspect:

- Bushing

Wear/Damage → Replace.



SHIFT LEVER
EXPLODED DIAGRAM



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	SHIFT LEVER REMOVAL		Follow the left "Step" for removal.
	Shift cable		NOTE: _____ Disconnect the shift cable at the shift lever.
1	Cap	1	
2	Bolt	1	6 × 35 mm
3	Plane washer	1	
4	Shift lever	1	
5	Screw	3	5 × 25 mm
6	Washer	1	
7	Base assembly	1	
8	Nylon nut	1	
9	Ball joint	1	
	BASE DISASSEMBLY		
①	Bolt	1	6 × 18 mm
②	Plane washer	1	
③	Lever	1	
④	Screw	2	5 × 12 mm
⑤	Plate	1	
⑥	Shaft	1	
⑦	Roller	1	
⑧	Actuator	1	
⑨	Spring	1	
⑩	Wave washer	1	
⑪	Bushing	2	
⑫	Base	1	
			Reverse the removal steps for installation.

SERVICE POINTS
Bushing Inspection


1. Inspect:

- Bushing

Wear/Crack/Damage → Replace.




**ENGINE HOOD
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	ENGINE HOOD DISASSEMBLY		Follow the left "Step" for removal.
	Engine hood assembly		Refer to the "ENGINE HOOD REMOVAL" section.
	Handle column		Refer to the "HANDLE COLUMN" section.
1	Screw	2	6 x 14 mm
2	Engine hatch	1	
3	Spring nut	2	
4	Nylon nut	2	
5	Plane washer	2	
6	Screw	2	
7	Hinge	1	
8	Nylon nut	2	
9	Plane washer	2	
10	Meter bracket	1	
11	Meter assembly	1	
12	Bolt (with washer)	6	
13	Adjustable mirror assembly	2	
14	Collar	6	
15	Screw (with washer)	4	
16	Hood cover	1	
17	Spring nut	4	
18	Tapping screw	4	
19	Ventilation hose joint	1	
20	Ventilation hose	1	
21	Tapping screw	12	
22	Oil filler	1	
23	Fuel filler	1	
24	Filler packing	2	
25	Band	1	
26	Check valve	1	
27	Bolt (with washer)	2	
28	Steering shaft bracket	1	
29	Engine hood	1	
30	Screw	2	5 x 16 mm
31	Plane washer	2	
32	Lock	1	
33	Packing	1	NOTE: _____
34	Packing	1	Mate packing ends (a) at center line rear and apply instantaneous adhesive.
35	Storage box	1	Reverse the removal steps for installation.

**STEERING CABLE
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	STEERING CABLE REMOVAL		Follow the left "Step" for removal.
	Ride plate		Refer to the "JET PUMP UNIT REMOVAL" section in chapter 6.
1	Cable joint	1	NOTE: Screw the steering cable end 13.8 mm (0.54 in) into the cable joint and tighten the lock nut.
2	Lock nut	1	
3	Cap	1	
4	Washer	1	
5	Stopper	1	
6	Seal	1	
7	Lock nut	1	
8	Cable joint	1	⚠ WARNING The cable joint must be screwed in more than 8 mm (0.31 in).
9	Nut	3	
10	Plane washer	3	
11	Steering cable bracket	1	
12	Nut	2	
13	Cable stopper	1	⚠ WARNING Be sure to fit the projection on the cable stopper into the slit in the outer cable.
14	Packing	1	
15	Steering cable	1	NOTE: Insert the cable into the clamp.
			Reverse the removal steps for installation.

SERVICE POINTS
Cable inspection



1. Inspect:

- Steering cable
- Kink/Fray/Stick → Replace.

**THROTTLE CABLE AND CHOKE CABLE
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART


Step	Procedure/Part name	Q'ty	Service points
	THROTTLE CABLE REMOVAL		Follow the left "Step" for removal. Refer to the "HANDLE" section.
	Steering pad		
1	Throttle cable lock nut	1	
2	Throttle cable adjusting bolt	1	
3	Throttle cable barrel	1	
4	Spiral tube	1	NOTE: <ul style="list-style-type: none"> ● Give 7 windings of the spiral tube to the throttle cable and handle switch leads and insert them into the steering shaft by 3 windings. ● Secondly, include the fuel sensor lead and oil sensor lead. Give another 7 windings to them. ● Thirdly, further include all leads except the meter breather hose. Give them one winding. ● Finally, excepting the throttle cable ⑥, continue wiring all through the rest of the spiral tube.
5	Packing	1	
6	Throttle cable lock nut	1	 Cable guide set position ⑥: 17 mm (0.67 in)
7	Throttle cable adjusting nut	1	
8	Throttle cable	1	
	CHOKE CABLE REMOVAL		
9	Screw	1	
10	Choke knob	1	
11	Adjuster	1	
12	Lock nut	1	
13	Plate	1	
14	Choke cable lock nut	1	 Cable guide set position ⑥: 17 mm (0.67 in)
15	Choke cable adjusting nut	1	
16	Choke cable	1	Reverse the removal steps for installation.

SERVICE POINTS
Cable inspection
1. Inspect:

- Throttle cable
 - Choke cable
- Kink/Fray/Stick → Replace.



SHIFT CABLE
EXPLODED DIAGRAM



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	SHIFT CABLE REMOVAL		Follow the left "Step" for removal. Refer to the "JET PUMP UNIT REMOVAL" section in chapter 6.
	Ride plate		
1	Cable joint	1	NOTE: Screw the steering cable end 13.8 mm (0.54 in) into the cable joint and tighten the lock nut.
2	Lock nut	1	
3	Cap	1	
4	Washer	1	
5	Stopper	1	
6	Seal	1	
7	Cable joint	1	⚠ WARNING The cable joint must be screwed in more than 8 mm (0.31 in).
8	Lock nut	1	
9	Cap nut	2	
10	Plane washer	2	
11	Bolt	2	
12	Cable stopper	1	⚠ WARNING Be sure to fit the projection on the cable stopper into the slit in the outer cable.
13	Shift cable	1	NOTE: Insert the cable into the clamp.
14	Packing	1	Reverse the removal steps for installation.

SERVICE POINTS
Cable inspection


1. Inspect.

- Shift cable



Kink/Fray/Stick → Replace.



SEAT, STORAGE BOX AND BATTERY CASE
EXPLODED DIAGRAM



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
SEAT DISASSEMBLY			Follow the left "Step" for removal.
1	Bolt (with washer)	6	
2	Seat lock	3	
3	Seat stopper	6	
4	Double seat	1	
5	Band	1	
6	Case	1	
7	Single seat	1	
STORAGE BOX DISASSEMBLY			
8	Packing	1	NOTE: _____ Mate packing ends  at center line rear and apply instantaneous adhesive.
9	Packing	1	
10	Storage box	1	NOTE: _____ Apply instantaneous adhesive to shaded area  .
BATTERY CASE REMOVAL			
11	Band	2	6 x 20 mm
12	Breather hose	1	
13	Battery	1	
14	Bolt (with washer)	4	
15	Battery case	1	
16	Tapping screw	3	
17	Case base	1	
			Reverse the removal steps for installation.


SERVICE POINTS
Seat inspection

1. Inspect.
 - Seat lock
Wear/Damage → Replace.

Storage box inspection

1. Inspect:
 - Packing
Flat/Damage → Replace.
 - Storage box
Crack/Damage → Replace.

**EXHAUST SYSTEM
EXPLODED DIAGRAM**





REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	EXHAUST SYSTEM REMOVAL		Follow the left "Step" for removal.
	Storage box		
1	Band	2	
2	Clamp	2	
3	Exhaust hose	1	
4	Exhaust hose	1	
5	Water lock	1	
6	Flange bolt	4	
7	Hook	2	
8	Hook assembly	2	
9	Clamp	2	
10	Exhaust hose	1	
11	Hose tie	1	
12	Water outlet hose	1	
13	Bolt (with washer)	3	
14	Exhaust guide	1	
15	Packing	1	
			Reverse the removal steps for installation.

SERVICE POINTS
Exhaust system inspection


1. Inspect:
 - Band
Crack → Replace.
2. Inspect:
 - Exhaust hose
Crack/Wear/Burn → Replace.
3. Inspect:
 - Water lock
 - Muffler
Crack/Leak → Replace.
Collected water → Drain.

**DECK
EXPLODED DIAGRAM**


REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Qty	Service points
	DECK DISASSEMBLY		Follow the left "Step" for removal.
1	Seat storage box Seat packing	1	NOTE: ● Clean the seat packing groove in the deck. ● Apply cyano-acrylate adhesive to the seat packing.
2	Nylon nut	4	
3	Plane washer	4	
4	Screw	4	
5	Grip	2	
6	Nylon nut	3	
7	Plane washer	6	
8	Seat lock pin	3	
9	Nylon nut	4	
10	Plane washer	4	
11	Bolt (with washer)	4	
12	Seat hook	2	
13	Grip handle cover	4	
14	Nylon nut	4	
15	Plane washer	4	
16	Screw	4	
17	Plane washer	4	
18	Collar	4	
19	Grip handle	1	
20	Nylon nut	2	
21	Plane washer	2	
22	Cleat	1	
23	Tapping screw	4	
24	Plate	1	
25	Ventilation hose	1	
			Reverse the removal steps for installation.

**GUNWALE AND MAT
EXPLODED DIAGRAM**



REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
GUNWALE REMOVAL			Follow the left "Step" for removal.
1	Nylon nut	2	
2	Plane washer	2	
3	Gunwale joint	2	
4	Nylon nut	4	
5	Plane washer	4	
6	Nut	1	
7	Rope hole bolt	1	
8	Bow gunwale	1	
9	Cap	10	
10	Rivet	10	
11	Stern gunwale	2	
12	Inner gunwale	1	
13	Rivet	9	
14	Cover gunwale	1	
15	Inner gunwale	2	
16	Tapping screw	28	
17	Side gunwale	2	
MAT REMOVAL			NOTE: ● Clean the step surface before installing the mat. ● Apply cyano-acrylate adhesive to the mat. <hr/> Reverse the removal steps for installation.
18	Upper mat	7	
19	Rivet	8	
20	Mat rubber	2	
21	Nut	1	
22	Rope hole bolt	1	
23	Clamp	1	
24	Nut	1	
25	Spout	1	
26	Step mat	1	


SERVICE POINTS
Gunwale and mat inspection
1. Inspect:

- Bow gunwale
- Stern gunwale
- Side gunwale
- Cover gunwale
- Upper mat
- Step mat

Wear/Damage → Replace.



**HULL
EXPLODED DIAGRAM**





REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	HULL DISASSEMBLY		Follow the left "Step" for removal.
1	Nylon nut	2	
2	Plane washer	2	
3	Bow eye	1	
4	Hose tie	1	
5	Nut	1	
6	Plane washer	1	
7	Pilot water outlet	1	
8	Nylon nut	8	
9	Plane washer	8	
10	Stabilizer	2	
11	Nylon nut	4	
12	Plane washer	4	
13	Screw	4	
14	Plane washer	4	
15	Drain plug socket	2	
16	Socket packing	2	
			Reverse the removal steps for installation.

HULL REPAIR
Light scratching





1. Sand the scratched area smooth with #400 grit wet or dry paper, and then with #600 grit wet or dry paper.
2. Polish the area with rubbing compound and buff to a high gloss using a wool pad and automotive wax.


Deep scratching

1. Remove any sharp/rough edges from the surface.
2. Sand the area smooth for about one inch all around the scratch with #80 grit wet or dry paper.
3. Clean the area with acetone and dry it.
4. Mix gel-coat with gel-coat thickener to make gel-coat putty and then add the catalyst to make.
5. Apply and spread the catalyzed putty with a squeegee, then cover the putty with a piece of waxed paper.
6. When the putty has set, sand the area catalyzed putty. Smooth using #80 grit to #400 grit wet or dry paper and a sanding block.
7. Clean the area with a dry cloth and polish it.

⚠ WARNING



Resin, catalyst and solvent are flammable and toxic. Use only in a well-ventilated area and keep away from open flames and sparks. Observe all warnings given by the manufacturer.



Hull damage (punctured)

1. Remove any damaged fiberglass.
2. Cut and open the crack approximately 1/4 inch.
3. Grind the opened edge less than 30° on the outside.
4. Grind the area from inside the hull approximately 4 inches beyond it.
5. Clean the area with acetone, apply BP-1 or an equivalent primer on both sides of the area and cure for 1/2 hour.
6. Tape a piece of cardboard covered with waxed paper ① over the damaged area.
7. Mix polyester resin and catalyst and apply it to the hull.
8. Apply a glass mat ② (2 inches smaller than the ground area).
9. Apply catalyzed resin.
10. Apply a 20 oz fiberglass cloth ③ (1 inch smaller than the glass mat).
11. Apply catalyzed resin.
12. Apply a final glass mat ④ (1 inch smaller than the ground area).
13. When the resin has hardened, remove the piece of cardboard.
14. Finish the outer surface using steps 3 - 7 in the "Deep scratching" section.

NOTE: Refer to the "WATER VEHICLE FRP REPAIR MANUAL".



Insert nut

NOTE:

When a pop nut clinched to a hull slipped off or when a bolt fastened to an insert nut or pop nut was broken, use this insert nut.



Part No.	Part Name	Remarks
EW2-62733-09	Nut	Stainless steel, M6

- Nut ①
- Direction of thread ②
- Slot to be threaded ③

NOTE:

Drilling size

Material	Pilot hole diameter
FRP or SMC	9.1 - 9.2 mm (0.36 in.)
Brass	9.4 mm (0.37 in.)



Example 1:

The nut is used to repair the pop nut designed for plate 2.

(by repairing the FRP portion, the new-type nut can be used for all models)

For details of repairs to the FRP portion, refer to the "Water Vehicle FRP Repair Manual".


1. Remove:
 - Pop nut
2. Scarf the shaded portion.
3. Clean the surface to be scarfed and the inside of the hull with acetone.
4. As shown, first tape up the inner surface of the hull and then laminate fiber glass mats over the tape using a resin.

NOTE:

When it is possible to work inside the hull, the mats should be laminated from the inside.



5. Smooth out the out surface by sanding it.
6. Install plate 2. Then, using a 9.2 mm (0.36 in) diameter drill, make a hole of depth 20 mm (0.79 in) in the center of the laminated fiberglass layers.
7. Pass the bolt ① through the insert nut, as shown, and lock the bolt with the nut ②. Screw in the insert nut so that the top is flush with the FRP surface. Loosen the lock nut and remove the bolt.



CAUTION:

- The bolt should be made of steel and its strength should be 8T or more.
- If the bolt is inferior in strength, or is made of stainless steel, it may break.

- Bolt ① <Strength is 8T or more>
- Lock nut ②


Example 2:

The brass insert nut designed for the Super Jet Plate 2 or the screen intake is used:


1. If the bolt is broken, remove it using drills.

NOTE:

Use a small-diameter drill first, followed by drills of gradually increasing diameter.



2. Use a 9.4 mm (0.37 in) drill for the final drilling.
3. Apply silicone sealant to the inside of the hole so that no water can enter the urethane foam.
4. As in Example 1 above, screw in the insert nut.
 - Brass insert ①
 - Hull ②
 - Urethane foam ③
 - Silicone sealant ④



Removing a graphic

1. Remove:
 - Graphic ①

NOTE:

- Using a hair dryer, start at one corner and blow heat the graphic, holding the heat source at least 1-1/2" above the graphic.
- Slowly peel off the heated part and continue working towards the other side.

2. Clean:

Once the graphic is removed, clean the entire bow area with Isopropyl Alcohol to remove any residual adhesive.


Applying a graphic

1. Preparation:

Mix 1 tablespoon of liquid washing-up detergent with water in a 1qt spray bottle. Remove the backing from the new graphic and spray both sides and the area of the hull to which it is to be fitted.

NOTE:

Spraying the front of the graphic will protect it from being scratched during application.



2. Apply:

Align the graphic on the fitting area and smooth it into position with a small rubber squeegee, removing all air bubbles in the process. Begin at the top of the graphic and work down and outwards from the center line of the graphic area.

3. Dry:

Let the graphic dry in place prior to waxing or using the vehicle.

**CHAPTER 9
TROUBLE ANALYSIS**

TROUBLE ANALYSIS 9-1
TROUBLE ANALYSIS CHART 9-1

TROUBLE ANALYSIS
NOTE:

Following items should be obtained before "trouble analysis".

1. Battery is charged and its specified gravity is in specification.
2. There is no incorrect wiring connection.
3. Wiring connections are surely engaged and without any rust.
4. Lanyard is installed to the engine stop switch.
5. Fuel is coming to the carburetor.

TROUBLE ANALYSIS CHART

Trouble mode										Check elements	
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	BILGE INCREASE	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference Chapter
										FUEL SYSTEM	
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Fuel tank	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Air vent hose	4
<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Fuel hose	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Fuel filter	4
<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Fuel pump	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Carburetor	4
	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Low speed screw setting	4
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						High speed screw setting	4
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Carburetor synchronization	4
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>						Trolling speed	3
										POWER UNIT	
<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Compression	5
<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Reed valve	5
<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Cylinder head gasket	5
<input type="radio"/>			<input type="radio"/>							Piston ring	5
<input type="radio"/>			<input type="radio"/>							Cylinder block	5
<input type="radio"/>			<input type="radio"/>							Seal	5
<input type="radio"/>			<input type="radio"/>							Crank case	5
<input type="radio"/>			<input type="radio"/>							Piston	5
<input type="radio"/>			<input type="radio"/>							Bearing	5
<input type="radio"/>			<input type="radio"/>							Intermediate housing	5
			<input type="radio"/>							Coupling	5
			<input type="radio"/>							Coupling rubber	5

Trouble mode								Check elements			
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	BILGE INCREASE	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference Chapter
					<input type="checkbox"/>		<input type="checkbox"/>			Pilot water hose	5
					<input type="checkbox"/>		<input type="checkbox"/>			Water hose	5
					<input type="checkbox"/>		<input type="checkbox"/>			Water passage	5
JET PUMP UNIT											
			<input type="checkbox"/>	<input type="checkbox"/>			<input type="checkbox"/>			Duct	6
			<input type="checkbox"/>							Impeller	6
			<input type="checkbox"/>							Intake screen	6
			<input type="checkbox"/>							Bearing	6
			<input type="checkbox"/>							Duct intake	6
				<input type="checkbox"/>			<input type="checkbox"/>			Water inlet hose	6
							<input type="checkbox"/>			Bilge hose	6
							<input type="checkbox"/>			Bilge strainer	6
							<input type="checkbox"/>			Bilge hose joint	6
							<input type="checkbox"/>			Valve body	6
ELECTRICAL											
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					Ignition system	7
<input type="checkbox"/>										Starting system	7
								<input type="checkbox"/>		Indication system	7
									<input type="checkbox"/>	Charging system	7
HULL AND HOOD											
						<input type="checkbox"/>				Column bearing	8
			<input type="checkbox"/>				<input type="checkbox"/>			Water lock	8
			<input type="checkbox"/>				<input type="checkbox"/>		<input type="checkbox"/>	Exhaust hose	8
			<input type="checkbox"/>				<input type="checkbox"/>			Muffler	8
							<input type="checkbox"/>			Drain plug	8